

INOSP-152-RE series INOSP-192-RE series

Industrial All-in-One Panel PC

User's Manual

Version 1.0
(Jan. 2021)



Copyright

© 2018 IBASE Technology, Inc. All rights reserved.

No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of IBASE Technology, Inc. (hereinafter referred to as "IBASE").

Disclaimer

IBASE reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, IBASE does not guarantee this document is error-free. IBASE assumes no liability for incidental or consequential damages arising from misapplication or inability to use the product or the information contained herein, nor for any infringements of rights of third parties, which may result from its use.

Trademarks

All the trademarks, registrations and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Compliance



This is a class A product. In a domestic environment, this product may cause radio interference in which case users may be required to take adequate measures.



This product has been tested and found to comply with the limits for a Class B device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications.

Operation is subject to the following two conditions:

- This product may not cause harmful interference
- This product must accept any interference received including interference that may cause undesired operation.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception which can be determined by turning the equipment off and on, you may correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the distributor or an experienced radio/TV technician for help.

WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive of for waste electrical and electronic equipment (WEEE - 2012/19/EU). Instead, it should be disposed of by returning it to a municipal recycling collection point. Check local regulations for disposal of electronic products.



This product is compliant with the current RoHS restrictions and prohibits use of the following substances in concentrations exceeding 0.1% by weight (1000 ppm) except for cadmium, limited to 0.01% by weight (100 ppm).

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent chromium (Cr6+)
- Polybrominated biphenyls (PBB)
- Polybrominated diphenyl ether (PBDE)

Important Safety Information

Carefully read the precautions before using the device.

Environmental conditions:

- Lay the device horizontally on a stable and solid surface during installation in case the device may fall, causing serious damage.
- Leave plenty of space around the device for ventilation.
- Use this product in environments with ambient temperatures between 0°C and 50°C.
- DO NOT LEAVE THIS DEVICE IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY BE BELOW -20° C OR ABOVE 60° C. To prevent from damages, the device must be used in a controlled environment.
- Keep the device away from humidity to avoid fog or condensation from accumulating on the inner surface of the panel.

Care for your iBASE products:

- Before cleaning the device, turn it off and unplug all cables such as power in case a small amount of electrical current may still flow.
- Use neutral cleaning agents or diluted alcohol to clean the device chassis with a cloth. Then wipe the chassis with a dry cloth.
- Vacuum the dust with a computer vacuum cleaner to prevent the air vent or slots from being clogged.



WARNING

Attention during use:

- Operate with fingers on the panel. Sharp-pointed articles are prohibited.
- Do not use this product near water.
- Do not spill water or any other liquids on your device.
- Do not place heavy objects on the top of the device.
- Operate this device from the type of power indicated on the marking label. If you are not sure of the type of power available, consult your distributor or local power company.
- Ensure that you apply correctly the power supply voltage.
- Do not walk on the power cord or allow anything to rest on it.
- If you use an extension cord, make sure that the total ampere rating of the product plugged into the extension cord does not exceed its limits.

Avoid Disassembly

You are not suggested to disassemble, repair or make any modification to the device. Disassembly, modification, or any attempt at repair could generate hazards and cause damage to the device, even bodily injury or property damage, and will void any warranty.



CAUTION

Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Warranty Policy

- **IBASE standard products:**
24-month (2-year) warranty from the date of shipment. If the date of shipment cannot be ascertained, the product serial numbers can be used to determine the approximate shipping date.
- **3rd-party parts:**
12-month (1-year) warranty from delivery for the 3rd-party parts that are not manufactured by IBASE, such as CPU, CPU cooler, memory, storage devices, power adapter, panel and touchscreen.
- ◆ Products, however, that fail due to misuse, accident, improper installation or unauthorized repair shall be treated as out of warranty and customers shall be billed for repair and shipping charges.

Technical Support & Services

1. Visit the IBASE website at www.ibase.com.tw to find the latest information about the product.
2. If you need any further assistance from your distributor or sales representative, prepare the following information of your product and elaborate upon the problem.
 - Product model name
 - Product serial number
 - Detailed description of the problem
 - The error messages in text or in screenshots if there is any
 - The arrangement of the peripherals
 - Software in use (such as OS and application software, including the version numbers)
3. If repair service is required, you can download the RMA form at <http://www.ibase.com.tw/english/Supports/RMAService/>. Fill out the form and contact your distributor or sales representative.

Table of Contents

Compliance.....	iii
Important Safety Information	iv
WARNING	v
Warranty Policy	v
Technical Support & Services	vi
Chapter 1 General Information.....	1
Chapter 2 Hardware Installation	10
Chapter 3 Driver Installation	13
Chapter 4 BIOS Setup	21
Appendix	36

Chapter 1

General Information

The information provided in this chapter includes:

- Features
- Packing List
- Specifications
- Overview
- Dimensions

1.1 Introduction

INOSP series, a stainless-steel panel PC, utilizes the qual-core 1.91GHz Intel® Processor E3845 providing high computing performance and low power consumption. It includes 15- and 19-inch size.

The INOSP series supports a wide range 10V~30V DC power input with optional 24V DC IP56 stainless steel power adaptor, which makes it ideal for food, livestock, chemical, mining, petrol and factory automation or any other industrial applications.



1.2 Features

- Totally IP65 and IP69K certificated
- Sealed resistive touch screen
- Durable stainless-steel housing
- Providing USB3.0 interface with M12 connector
- Wide-range DC power input 10V to 30V

1.3 Packing List

Your product package should include the items listed below. If any of the items below is missing, contact the distributor or the dealer from whom you purchased the product.

- INOSP-xx2-RE or INOSP-xx2-RE-F
 - M12 connector dust cover for INOSP-xx2-RE or
M12 connector dust cover for INOSP-xx2-RE-F
 - Motherboard User manual and driver CD

x 1

x 5

x 7

x 1

1.4 Optional Accessories

IBASE provides optional accessories as follows. Please contact us or your dealer if you need any.

- SSPA-24: IP56 stainless steel power adapter
 - M12 power cable
 - M12 USB 2.0 cable
 - M12 USB 3.0 cable
 - M12 GbE LAN cable
 - M12 DSUB cable

C501PW35203A21000P

C501USB1804A32000P

C501USB1540A22000P

A012CB01200101000P

A012CB01210101000P

1.5 Specifications

Product Name	INOSP-152-RE(-F)	INOSP-192-RE(-F)
System		
Motherboard	IB897	
Operating System	Windows 7, Windows 10, Linux kernel 3.X+	
CPU	Intel E3845	
Chipset	Integrated	
Memory	1 x DDR3L SO-DIMM 4 GB, up to 8 GB	
Storage	2.5" HDD/SSD	
Graphics	Intel® HD graphics	
Power Supply	DC-In 10~ 30V	
BIOS	AMI BIOS	
Watchdog	Watchdog Timer 256 segments, 0, 1, 2...255 sec/min	
iSmart	Yes (auto-scheduler / power resume)	
Chassis	Stainless steel with hairline	
Membrane Control	None	
Mounting	VESA 100 x 100 mm	
Dimensions (W x H x D)	425 x 330x 62.5 mm (16.73" x 12.99" x 2.46")	470 x 390x 62.5 mm (18.50" x 15.35" x 2.46")
Net Weight	8.5 kg (16.52 lb)	10.5 kg (23.13 lb)
Ingress Protection	IP65 and IP69K	
Certificate	CE, FCC Class B, LVD	

Product Name	INOSP-152-RE(-F)	INOSP-192-RE(-F)
Display & Touchscreen		
Display Type	15" TFT-LCD	19" TFT-LCD
Resolution	Max. 1024 x 768	Max. 1280 x 1024
Color	Max. 16.2M	Max. 16.7M
Viewing Angle	H/V: 160° / 160°	H/V: 170° / 160°
Luminance	500 cd/m2	350 cd/m2
Contrast	800:1	1000:1
Backlight Lifetime	50000 hrs	50000 hrs
Touch Type	Resistive touch	
Touch Interface	USB	
Light Transmission	80%	
Point of Touch	1	
System I/O Ports and functions		
Power	1 x M12 4 pin	
LAN	1 x M12 8 pin for GbE LAN Second LAN as an option	
Serial	1 x M12 8 pin for RS-232/422/485 COM1 1 x M12 8 pin for RS-232 COM2	
USB	1 x M12 4 pin for USB 2.0 1 x M12 8 pin for USB 3.0 for option	
Display	None addition graph output	
Storage	1 x 2.5" SATA 64GB SSD	
Audio	None	
Internal Expansion Bus	<ul style="list-style-type: none">1 x Mini-PCle (x1) slot (full/half-size) with USB1 x Mini-PCle (x1) slot (half-size) with USB	
Expansion Slot	N/A	

Product Name	INOSP-152-RE(-F)	INOSP-192-RE(-F)
Environment		
Temperature	<ul style="list-style-type: none">• Operating: 0 ~ 50 °C (32 ~ 122 °F)• Storage: -20 ~ 60 °C (-4 ~ 140 °F)	
Relative Humidity	10 ~ 90% (non-condensing)	


All specifications are subject to change without prior notice.

1.6 Overview – INOSP-152/192-RE series

1.6.1 Oblique & Rear View for INOSP-152/192-RE




1.6.2 I/O View for INOSP-152/192-RE



No.	Name	No.	Name
1	Power input	5	COM2 RS232
2	USB 2.0		
3	LAN (GbE)		
4	COM1 RS232/422/485		

1.6.3 I/O View for INOSP-152/192-RE-F







No.	Name	No.	Name
1	Power input	5	LAN2(GbE)
2	USB 2.0	6	COM1 RS232/422/485
3	USB 3.0	7	COM2 RS232
4	LAN1(GbE)		

1.7 Dimensions

Unit: mm

INOSP-152-RE series





Chapter 2

Hardware Installation & Motherboard Information

The information provided in this chapter includes:

- Information and locations of connectors


2.1 Hardware Installation

This section is all illustrated by the example of INOSP-152/192-RE

Avoid device disassembly: Because INOSP-152/192-RE systems are totally IP65 and IP69K. You are not suggested to disassemble, repair or make any modification to the device. Disassembly, modification, or any attempt at repair could generate hazards and cause damage to the device. If you need to make any change to the device, please contact iBASE.


2.1.1 I/O Pin definition

Power input




Pin	Subject
1	V+
2	FG
3	NC
4	V-

LAN port




Pin	Subject
1	White/Orange
2	White/Blue
3	Blue
4	Brown
5	Green
6	White/Brown
7	Orange
8	White/Green

USB 2.0




Pin	Subject
1	+5V
2	D-
3	D+
4	GND

USB 3.0



Pin	Subject
1	VCC1
2	TX-
3	RX+
4	RX-
5	GND
6	D1+
7	D1-
8	TX+

Serial port




Pin	Subject
1	DCD
2	RXD
3	TXD
4	DTR
5	GROUND
6	DSR
7	RTS
8	CTS

2.1.2 VESA Mount & Wall Mount Installation

1. VESA Mount

You will need to prepare the VESA mount bracket in advance.

Tighten 4 screws(4-M4) as below to attach the device to the bracket.



Chapter 3

Driver Installation for INOSP152/192-RE

The information provided in this chapter includes:

- Intel Chipset Software Installation Utility
- VGA Drivers Installation
- Realtek High Definition Audio Driver Installation
- Intel Trusted Execution Engine Installation

3.1 Introduction

This section describes the installation procedures for software drivers. The software drivers are in a disk enclosed with the product package. If you find anything missing, please contact the distributor where you made the purchase.

Note: After installing your Windows operating system, you must install the Intel® Chipset Software Installation Utility first before proceeding with the drivers installation.

3.2 Intel® Chipset Drivers

The Intel Chipset Drivers should be installed first before the software drivers to enable Plug & Play INF support for Intel chipset components. Follow the instructions below to complete the installation.

1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Baytrail Chipset**. Click **Intel(R) Chipset Software Installation Utility**.



3. When the Welcome screen to the Intel® Chipset Device Software appears, click **Next** to continue.
4. Click **Yes** to accept the software license agreement and proceed with the installation process.
5. The Setup process is now complete. Click **Finish** to restart the computer and for changes to take effect.

3.3 VGA Drivers Installation


1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Baytrail Chipset**. Click **Intel(R) Baytrail Graphics Driver**.



2. When the Welcome screen appears, click **Next** to continue.

3. Click **Yes** to accept the license agreement and continue the installation.

4. Setup complete. Click **Finish** to restart the computer and for changes to take effect.




3.4 Realtek High Definition Audio Driver Installation

1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Baytrail Chipset**. Click **Realtek High Definition Audio Driver**.



2. On the Welcome screen, click **Next** to proceed with the installation.



3. InstallShield Wizard is complete. Click **Finish** to restart the computer and for changes to take effect.

3.5 Intel Trusted Execution Engine Installation

Note :Windows 7 OS only

Important Notes

4) Intel TXE PV Firmware is signed by Intel

- PV POR configuration is signed Intel TXE FW and Production Silicon
- Signed Intel TXE FW and Pre Production Silicon is supported for development needs only

Combination of unsigned Intel TXE Firmware and Production Silicon is not supported and will result in unexpected behavior

5) For Windows 7 OS only:

Intel® Trusted Execution Engine Interface (Intel® TXEI) Driver uses KMDF (WDF) 1.11, which is built-in on Windows 8 and Windows 8.1. However, Windows 7 doesn't have it. Please install Kernel-Mode Driver Framework (KMDF) version 1.1. Otherwise, yellow bang appears on Intel TXEI device upon installation. Please follow instructions in this [link: KB2685811](#)

Other names and brands may be claimed as the property of others.
All products, computer systems, dates and figures specified are preliminary based on current expectations, and are subject to change without notice.


Intel Confidential



1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Baytrail Chipset**. Click **Intel(R) Baytrail Graphics Driver**.



2. On the Setup Welcome screen, click **Next** to proceed with the installation process.



3. Click **Next** accept the license agreement and continue the installation.


4. Installation of the Intel Trusted Execution Engine is now complete. Click **Finish**.

3.6 LAN Controller Drivers Installation


1. Click **LAN Card** and then **Intel LAN Controller Drivers**.



2. Click **Intel(R) I21x Gigabit Network Drivers**.



3. Choose a destination folder for installation.
4. The driver has been completely installed. Click **Finish** and restart the computer for changes to take effect.



Chapter 4

BIOS Setup for

INOSP-152/192-RE

This chapter describes the different settings available in the AMI BIOS that comes with the board. The topics covered in this chapter are as follows:

- Main Settings
- Advanced Settings
- Chipset Settings
- Security Settings
- Boot Settings
- Save & Exit

Introduction

The BIOS (Basic Input/Output System) installed in the ROM of your computer system supports Intel® processors. The BIOS provides critical low-level support for standard devices such as disk drives, serial ports and parallel ports. It also provides password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Pressing the key immediately allows you to enter the Setup utility. If you are a little bit late pressing the key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup. If you still wish to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again. The following message will appear on the screen:

Press to Enter Setup

In general, you press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help and <Esc> to quit.

When you enter the Setup utility, the Main Menu screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

Warning: *It is strongly recommended that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both AMI and your system manufacturer to provide the absolute maximum performance and reliability. Changing the defaults could cause the system to become unstable and crash in some cases.*

Main Settings

Aptio Setup Utility – Copyright © 2013 American Megatrends, Inc.

Main	Advanced	Chipset	Boot	Security	Save & Exit
BIOS Information					Choose the system default language
System Language			[English]		→ ← Select Screen
System Date			[Tue 01/20/2009]		↑ ↓ Select Item
System Time			[21:52:06]		Enter: Select
Access Level			Administrator		+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

System Language

Choose the system default language.

System Date

Set the Date. Use Tab to switch between Data elements.

System Time

Set the Time. Use Tab to switch between Data elements.

Advanced Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility – Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
<div>▶ ACPI Settings</div> <div>▶ LVDS Configuration</div> <div>▶ Smart Controller</div> <div>▶ Super IO Configuration</div> <div>▶ H/W Monitor</div> <div>▶ CPU Configuration</div> <div>▶ FWH Configuration</div> <div>▶ IDE Configuration</div> <div>▶ SDIO Configuration</div>				<div>→ ←Select Screen</div> <div>↑ ↓ Select Item</div> <div>Enter: Select</div> <div>+ - Change Opt.</div> <div>F1: General Help</div> <div>F2: Previous Values</div> <div>F3: Optimized Defaults</div> <div>F4: Save & Exit</div> <div>ESC: Exit</div>	

ACPI Settings

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
ACPI Settings					
Enable ACPI Auto Configuration		Disabled		→ ←Select Screen	
Enable Hibernation		Enabled		↑ ↓ Select Item	
ACPI Sleep State		S3 only (Suspend to ...)		Enter: Select	
				+- Change Opt.	
				F1: General Help	
				F2: Previous Values	
				F3: Optimized	
				Defaults	
				F4: Save & Exit	
				ESC: Exit	

Enabled ACPI Auto Configuration

Enables or Disables BIOS ACPI Auto Configuration.

Enable Hibernation

Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.

ACPI Sleep State

Select ACPI sleep state the system will enter when the SUSPEND button is pressed.

LVDS Configuration

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
Configuration					→ ←Select Screen
Panel Color Depth					↑ ↓ Select Item
LVDS Channel Type					Enter: Select
Panel Type					+ - Change Opt.
LVDS Backlight Control					F1: General Help
					F2: Previous Values
					F3: Optimized
					Defaults
					F4: Save & Exit
					ESC: Exit

Notice!

Please do not change any LVDS setting with INOSP-152/192 series, else the system may not work

iSmart Controller

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
iSmart Controller				→ ←Select Screen ↑ ↓ Select Item Enter: Select +- Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Power-On after Power failure		Disable			
Schedule Slot 1		None			
Schedule Slot 2		None			

Power-On after Power failure

This field sets the system power status whether *Disable* or *Enable* when power returns to the system from a power failure situation.

Schedule Slot 1 / 2

Setup the hour/minute for system power on.

Super IO Configuration

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
Super IO Configuration				→ ←Select Screen ↑ ↓ Select Item Enter: Select +- Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
▶ Serial Port 1 Configuration					
▶ Serial Port 2 Configuration					

Serial Port 1 Configuration

Set parameters of serial port 1(COMA)

Serial Port 2 Configuration

Set parameters of serial port 2(COMA)

H/W Monitor

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.

Main	Advanced	Chipset	Boot	Security	Save & Exit
PC Health Status					
Smart Fan Function			Disabled		
SYS temp			+33.0 C		
CPU temp			+34.5 C		
FAN1 Speed			4000 RPM		
Vcore			+1.704 V		→ ←Select Screen ↑ ↓ Select Item Enter: Select +- Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
+1.35V			+1.544 V		
AVCC			+3.300 V		
VSB3			+3.344 V		
VCC3V			+3.328 V		
CPU Shutdown Temperature			Disabled		

Smart Fan Function

This field enables or disables the smart fan feature.
Disabled (default)

- 50 °C
- 60 °C
- 70 °C
- 80 °C
- 90 °C

Shutdown Temperature

This field enables or disables the Shutdown Temperature

Disabled (default)

- 70 °C/158 F
- 75 °C/167 F
- 80 °C/176 F
- 85 °C/185 F
- 90 °C/194 F
- 90 °C/203 F

Temperatures/Voltages

These fields are the parameters of the hardware monitoring function feature of the motherboard. The values are read-only values as monitored by the system and show the PC health status

CPU Configuration

This section shows the CPU configuration parameters.

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
CPU Configuration					
▶ Socket 0 CPU Information					
CPU Speed		1751 Mhz			
64-bit		Supported			
					→ ←Select Screen
					↑ ↓ Select Item
					Enter: Select
					+ - Change Opt.
					F1: General Help
					F2: Previous Values
					F3: Optimized
					Defaults
					F4: Save & Exit
					ESC: Exit

Socket 0 CPU Information

Socket specific CPU Information.

CPU PPM Configuration

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.

Main	Advanced	Chipset	Boot	Security	Save & Exit
CPU PPM Configuration					
EIST		Enabled		→ ←Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit	

EIST

Enable/Disable Intel SpeedStep.

IDE Configuration

SATA Devices Configuration.

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
IDE Configuration					
Serial-ATA (SATA)		Enabled			
SATA Mode		AHCI			
Serial-ATA Port 0		Enabled			
SATA Port0 HotPlug		Disabled			
Serial-ATA Port 1		Enabled			
SATA Port1 HotPlug		Disabled			
SATA Port0					→ ←Select Screen
Not Present					↑ ↓ Select Item
					Enter: Select
					+ - Change Field
SATA Port1					F1: General Help
Not Present					F2: Previous Values
					F3: Optimized Default
					F4: Save
					ESC: Exit

Serial-ATA(SATA)

Enabled / Disabled Serial ATA

SATA Mode

Select IDE / AHCI Mode

Serail –ATA Port 0

Enabled / Disabled Serial Port 0

SATA Port0 HotPlug

Enabled / Disabled SATA Port 0 HotPlug

Serail –ATA Port 1

Enabled / Disabled Serial Port 1

SATA Port1 HotPlug

Enabled / Disabled SATA Port 1 HotPlug

SDIO Configuration

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.

Main	Advanced	Chipset	Boot	Security	Save & Exit
	SDIO Access Mode		Auto		→ ←Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

SDIO Access Mode

Auto Option: Access SD device in DMA mode if controller supports it. Otherwise, in PIO mode. DMA options: Access SD device in DMA mode. PIO Option: Access PIO device in DMA

Chipset Settings

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
▶ North Bridge				→ ←Select Screen ↑ ↓ Select Item Enter: Select +- Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	

North Bridge

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
Exit					
Memory Information			→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit		
Total Memory		4096 MB (LPDDR3)			
Memory Slot0		4096 MB (LPDDR3)			
Memory Slot2		Not Present			

Security Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.

Main	Advanced	Chipset	Boot	Security	Save & Exit
Password Description If ONLY the Administrator's password is set, then this only limit access to Setup and is only asked for when entering Setup. If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights The password length must be in the following range: Minimum length Maximum length				→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Administrator Password User Password					

Administrator Password

Set Administrator Password.

Boot Settings

This section allows you to configure the boot settings.

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
Boot Configuration					
Setup Prompt Timeout			1		
Bootup NumLock State			On		
Quiet Boot			Disabled		→ ←Select Screen
Fast Boot			Disabled		↑ ↓ Select Item
Boot Option Priorities					Enter: Select
Boot Option #1			UEFI:Built-in EFI		+ - Change Opt.
					F1: General Help
					F2: Previous Values
					F3: Optimized
					Defaults
					F4: Save & Exit
					ESC: Exit

Setup Prompt Timeout

Number of seconds to wait for setup activation key.

65535(0xFFFF) means indefinite waiting.

Bootup NumLock State

Select the keyboard NumLock state.

Quiet Boot

Enables or disables Quiet Boot option.

Fast Boot

Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

Boot Option Priorities

Sets the system boot order.

Save & Exit Settings

Aptio Setup Utility - Copyright © 2013 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
Save Changes and Exit Discard Changes and Exit Save Changes and Reset Discard Changes and Reset Save Options Save Changes Discard Changes Restore Defaults Save as user Defaults Restore User Defaults Boot Override				→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	

Save Changes and Exit

Exit system setup after saving the changes.

Discard Changes and Exit

Exit system setup without saving any changes.

Save Changes and Reset

Reset the system after saving the changes.

Discard Changes and Reset

Reset system setup without saving any changes.

Save Changes

Save Changes done so far to any of the setup options.

Discard Changes

Discard Changes done so far to any of the setup options.

Restore Defaults

Restore/Load Defaults values for all the setup options.

Save as User Defaults

Save the changes done so far as User Defaults.

Restore User Defaults

Restore the User Defaults to all the setup options.

This page is blank

Appendix

This section provides the mapping addresses of peripheral devices and the sample code of watchdog timer configuration.

- I/O Port Address Map
- Interrupt Request Lines (IRQ)
- Digital I/O Sample Code
- Watchdog Timer Configuration

A. Watchdog Timer Configuration

The Watchdog Timer (WDT) is used to generate a variety of output signals after a user programmable count. The WDT is suitable for the use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven.

Under normal circumstance, you will need to restart the WDT at regular intervals before the timer counts to zero.

Sample Code (for Fintek F81846 / F81866):

```
// .....
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A
// PARTICULAR
// PURPOSE.
//
// .....
#include <dos.h>
#include <conio.h>
#include <stdio.h>
#include <stdlib.h>
#include "F81866.H"
// .....
int main (int argc, char *argv[]); void EnableWDT(int);
void DisableWDT(void);
// .....
int main (int argc, char *argv[])
{
    unsigned char bBuf;
    unsigned char bTime;
    char **endptr;

    char SIO;
    printf("Fintek 81866 watch dog program\n");
    SIO = Init_F81866();
    if (SIO == 0)
    {
        printf("Can not detect Fintek 81866, program abort.\n");
        return(1);
    }
    }//if (SIO == 0)

    if (argc != 2)
    {
        printf(" Parameter incorrect!!\n");
        return (1);
    }
}
```

```

bTime = strtol (argv[1], endptr, 10);
printf("System will reset after %d seconds\n", bTime);

if (bTime)
{
    EnableWDT(bTime); }
else
{
    DisableWDT(); }
return 0;
}
//.....
void EnableWDT(int interval)
{
    unsigned char bBuf;

    bBuf = Get_F81866_Reg(0x2B);
    bBuf &= (~0x20);
    Set_F81866_Reg(0x2B, bBuf);           //Enable WDTO

    Set_F81866_LD(0x07);                 //switch to logic device 7
    Set_F81866_Reg(0x30, 0x01);         //enable timer

    bBuf = Get_F81866_Reg(0xF5);
    bBuf &= (~0x0F);
    bBuf |= 0x52;
    Set_F81866_Reg(0xF5, bBuf);          //count mode is second
    Set_F81866_Reg(0xF6, interval);     //set timer
    bBuf = Get_F81866_Reg(0xFA);
    bBuf |= 0x01;
    Set_F81866_Reg(0xFA, bBuf);          //enable WDTO output

    bBuf = Get_F81866_Reg(0xF5);
    bBuf |= 0x20;
    Set_F81866_Reg(0xF5, bBuf);          //start counting
}
//.....
void DisableWDT(void)
{
    unsigned char bBuf;
    Set_F81866_LD(0x07);                 //switch to logic device 7
    bBuf = Get_F81866_Reg(0xFA);
    bBuf &= ~0x01;
    Set_F81866_Reg(0xFA, bBuf);          //disable WDTO output

    bBuf = Get_F81866_Reg(0xF5);
    bBuf &= ~0x20;
    bBuf |= 0x40;
    Set_F81866_Reg(0xF5, bBuf);          //disable WDT
}
//.....

```



```

//.....
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A
// PARTICULAR
// PURPOSE.
//
//.....
#include "F81866.H"
#include <dos.h>
//.....
unsigned int F81866_BASE; void Unlock_F81866 (void); void Lock_F81866 (void);
//.....
unsigned int Init_F81866(void)
{
    unsigned int result;
    unsigned char ucDid;

    F81866_BASE = 0x4E;
    result = F81866_BASE;

    ucDid = Get_F81866_Reg(0x20);
    if (ucDid == 0x07)                                //Fintek 81866
    {
        goto Init_Finish;
    }

    F81866_BASE = 0x2E;
    result = F81866_BASE;

    ucDid = Get_F81866_Reg(0x20);
    if (ucDid == 0x07)                                //Fintek 81866
    {
        goto Init_Finish;
    }

    F81866_BASE = 0x00;
    result = F81866_BASE;

Init_Finish:
    return (result);
}
//.....
void Unlock_F81866 (void)
{
    outportb(F81866_INDEX_PORT, F81866_UNLOCK);
    outportb(F81866_INDEX_PORT, F81866_UNLOCK);
}
//.....
void Lock_F81866 (void)
{
    outportb(F81866_INDEX_PORT, F81866_LOCK);
}
//.....
void Set_F81866_LD( unsigned char LD)
{
    Unlock_F81866();
}

```

```

        outportb(F81866_INDEX_PORT, F81866_REG_LD);
        outportb(F81866_DATA_PORT, LD); Lock_F81866();
    }
    //.....
void Set_F81866_Reg( unsigned char REG, unsigned char DATA)
{
    Unlock_F81866();
    outportb(F81866_INDEX_PORT, REG);
    outportb(F81866_DATA_PORT, DATA);
    Lock_F81866();
}
//.....
unsigned char Get_F81866_Reg(unsigned char REG)
{
    unsigned char Result;
    Unlock_F81866();
    outportb(F81866_INDEX_PORT, REG);
    Result = inportb(F81866_DATA_PORT);
    Lock_F81866();
    return Result;
}
//.....



//.....
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A
// PARTICULAR
// PURPOSE.
//
//.....
#ifndef    F81866_H
#define    F81866_H    1
//.....
#define    F81866_INDEX_PORT    (F81866_BASE)
#define    F81866_DATA_PORT    (F81866_BASE+1)
//.....
#define    F81866_REG_LD    0x07
//.....
#define F81866_UNLOCK 0x87
#define    F81866_LOCK 0xAA
//.....
unsigned int Init_F81866(void);
void Set_F81866_LD( unsigned char);
void Set_F81866_Reg( unsigned char, unsigned char); unsigned char
Get_F81866_Reg( unsigned char);
//.....
#endif //    F81866_H

```


B. External M12 cables PIN definition

• M12 power cable

C501PW35203A21000P




4	Black/黑	端子台(3)
3	Green/綠	3.2mmR型端子
2	Red/紅	端子台(2)
1	White/白	端子台(1)
CN1	Wire Color	CN2
	Pin out	




• M12 USB 2.0 cable

C501USB1804A32000P




• M12 USB 3.0 cable

C501USB1540A22000P





• M12 GbE LAN cable

A012CB01200101000P



• M12 DSUB cable

A012CB01210101000P



CN1
Pin Assignments
Front View

Shell	Gnd	Shell
8	Brown	8
7	Brown/ White	7
6	Green	6
5	Blue/ White	5
4	Blue	4
3	Green/ White	3
2	Orange	2
1	Orange/ White	1
Conn.1	Wire Color	Conn.2
	PIN OUT	

IBASE P/N: A012CB01210101000P

