



J5: Power Supply Connector

Pin #	Signal Name
1	+5V
2	-5V
3	-12V
4	+12V
5	+3.3V
6	GND

FAN1, FAN2: System Fan Connector

Pin #	Signal Name
1	Ground
2	+12V
3	Rotation detect

J6: 5VSB/PS ON Power Connector

Pin #	Signal Name
1	Ground
2	PS_ON-
3	5VSB

J7: System status LED connector

- Pin1-2: System FAN1 status LED
- Pin3-4: System FAN2 status LED
- Pin5-6: System temperature status LED
- Pin7-8: Power indicator LED
- Pin9-10: -12V power status LED
- Pin11-12: -5V power status LED
- Pin13-14: +3.3V power status LED
- Pin15-16: +5V power status LED
- Pin17-18: +12V power status LED
- Pin19-20: 5VSB power status LED

Signal Name	Pin #	Pin #	Signal Name
FAN1_LED+	2	1	FAN1_LED-
FAN2_LED+	4	3	FAN2_LED-
TEMP_LED+	6	5	TEMP_LED-
PWR_LED+	8	7	PWR_LED-
-12V_LED+	10	9	-12V_LED-
-5V_LED+	12	11	-5V_LED-
+3.3V_LED+	14	13	+3.3V_LED-
+5V_LED+	16	15	+5V_LED-
+12V_LED+	18	17	+12V_LED-
5VSB_LED+	20	19	5VSB_LED-