UPC-7210

Industrial Panel PC

User's Manual

Version 1.0 (Nov. 2018)



Copyright

© 2018 IBASE Technology, Inc. All rights reserved.

No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of IBASE Technology, Inc. (hereinafter referred to as "IBASE").

Disclaimer

IBASE reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, IBASE does not guarantee this document is error-free. IBASE assumes no liability for incidental or consequential damages arising from misapplication or inability to use the product or the information contained herein, nor for any infringements of rights of third parties, which may result from its use.

Trademarks

All the trademarks, registrations and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Compliance

CE

This product may cause radio interference in which case users may be required to take adequate measures.

FC

This product has been tested and found to comply with the limits for a Class B device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications.

Operation is subject to the following two conditions:

- This product may not cause harmful interference
- This product must accept any interference received including interference that may cause undesired operation.

However, there is no guarantee that interference will not occur in an installation. If this equipment causes harmful interference to radio or television reception which can be determined by turning the equipment off and on, you may correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the distributor or an experienced radio/TV technician for help.

WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive of for waste electrical and electronic equipment (WEEE - 2012/19/EU). Instead, it should be disposed of by returning it to a municipal recycling collection point. Check local regulations for disposal of electronic products.



Green IBASE



This product complies with the current RoHS restrictions that prohibit the use of the following substances in concentrations exceeding 0.1% by weight (1000 ppm) except for cadmium, limited to 0.01% by weight (100 ppm).

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent chromium (Cr6+)
- Polybrominated biphenyls (PBB)
- Polybrominated diphenyl ether (PBDE)

Important Safety Information

Carefully read the precautions before using the device.

Environmental conditions:

- Put the device horizontally on a stable and solid surface during installation in case the device may fall, causing serious damage.
- Leave plenty of space around the device for ventilation.
- Use this product in environments with ambient temperatures between 0°C and 50°C.
- DO NOT LEAVE THIS DEVICE IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY BE BELOW -20° C OR ABOVE 70° C. To prevent from damages, the device must be used in a controlled environment.
- Keep the device away from humidity to avoid fog or condensation from accumulating on the inner surface of the panel.

Care for your IBASE products:

- Before cleaning the device, turn it off and unplug all cables in case a small amount of electrical current may still flow.
- Use neutral cleaning agents or diluted alcohol to clean the device chassis with a cloth. Then wipe the chassis with a dry cloth.
- Use a computer vacuum cleaner to remove dust to prevent the air vent or slots from getting clogged.



Attention during use:

- Do not use this product near water.
- Do not spill water or any other liquids on your device.
- Do not place heavy objects on the top of the device.
- Operate this device from the type of power indicated on the marking label. If you are not sure of the type of power available, consult your distributor or local power company.
- Ensure to use the correct power supply voltage.
- Do not walk on the power cord or allow anything to rest on it.
- If you use an extension cord, make sure that the total ampere rating of the product plugged into the extension cord does not exceed its limits.

Avoid Disassembly

Disassembly, modification, or any attempt at repair could generate hazards and cause damage to the device, even bodily injury or property damage, and will void any warranty on the product.



Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Warranty Policy

• IBASE standard products:

24-month (2-year) warranty from the date of shipment. If the date of shipment cannot be ascertained, the product serial numbers can be used to determine the approximate shipping date.

• 3rd-party parts:

12-month (1-year) warranty from delivery for the 3rd-party parts that are not manufactured by IBASE, such as CPU, CPU cooler, memory, storage devices, power adapter, panel and touch screen.

 Products, however, that fail due to misuse, accident, improper installation or unauthorized repair shall be treated as out of warranty and customers shall be billed for repair and shipping charges.

Technical Support & Services

- 1. Visit the IBASE website at <u>www.ibase.com.tw</u> to find the latest information about the product.
- 2. If you need any assistance from your distributor or sales representative concerning problems that you may have encountered, please prepare the following information:
 - Product model name
 - Product serial number
 - Detailed description of the problem
 - Error messages in text or in screenshots if there is any
 - The arrangement of the peripherals
 - Software used (such as OS and application software, including the version numbers)
- For repair service, please download the RMA form from <u>http://www.ibase.com.tw/english/Supports/RMAService/</u>.
 Fill out the form and contact your distributor or sales representative.

Table of Contents

Complian	ceiii
Important	Safety Informationiv
WARNING	i v
CAUTION	v
Warranty	Policyv
Technical	Support & Servicesvi
Chapter 1	General Information1
1.1	Introduction2
1.2	Features2
1.3	Packing List
1.4	Specifications
1.5	Overview
1.6	Dimensions
Chapter 2	Hardware Configuration8
2.1	Rear Cover Disassembly9
2.2	Memory Replacement9
2.5	VESA Mounting Installation12
2.6	Pin out for COM113
2.7	Setting the Jumpers14
	How to Set the Jumpers14
2.8	Jumper & Connector Locations15
Chapter 3	Driver Installation26
Chapter 4	BIOS Setup
Appendix	63
Α.	I/O Port Address Map64
В.	Interrupt Request Lines (IRQ)66
C.	Watchdog Timer Configuration67
D.	Onboard Connector Reference Types70

Chapter 1 General Information

The information provided in this chapter includes:

- Features
- Packing List
- Specifications
- Overview
- Dimensions



1.1 Introduction

UPC-7210" is a 21.5" touch panel PCs based on the Intel[®] 7th Core i[™] ultra low power processor. It features IP65 ingress protection for the front bezel and can be operated at ambient operating temperature ranging from 0°C to 50°C.



1.2 Features

- Intel[®] 7th Core i[™] U series processor
- Projected capacitive touch screen
- Low power consumption
- IP65 front-bezel waterproof protection

1.3 Packing List

Your product package should include the items listed below. If any of the items below is missing, contact the distributor or the dealer from whom you have purchased the product.

•	UPC-7210 system	x 1
•	Power adapter	x 1
•	Motherboard Driver DVD	x 1
•	Power core	x 1



1.4 Specifications

	UPC-7210 -I76	
Product Name	UPC-7210 -I73	
	UPC-7210 -I71	
	Dianlay & Tayah Saraan	
Display Size	21.5" IFI-LCD	
Max. Resolution	1920 x 1080	
Luminance (cd/m ²)	250	
Contrast	1000:1	
Max. Color	16.7M	
View Angle (H°/V°)	178/178	
Backlight Lifetime (hrs)	30,000	
Touch Type	Projected capacitive	
Touch Interface	USB	
Light Transmission (%)	88	
Point of Touch	Up to 10	
	I/O Interface	
USB 3.0	4, Туре А	
RS-232/422/485 (Selectable under BIOS)	1, DSUB9	
LAN	2 x GbE ,RJ45	
Additional Graphics	DP & VGA	
Audio	1 x Mic/ 1 x Lin-in, 3.5 mmAudio Jack	
Digital I/O	N/A	
Power Connector	Power Jack	
Power Button	Rock Switch	
Mechanical		
Dimensions (mm)	529.5 x 321 x 59	
Net Weight (kg)	7.7	
	System	
	Intel® i7 7600U UPC-7210 -I76	
Processor	Intel® i3 7100U UPC-7210 -173	
Net Weight (kg) 7.7 System Intel® i7 7600U UPC-7210 -I76 Intel® i5 7300U UPC-7210 -I73 Intel® i3 7100U UPC-7210 -I71		

Memory	2 x DDR4 SO-DIMM, up to 32 GB, default 4GB	
Thermal Design Fanless		
Membrane Control	N/A	
Built-in Speaker / Mic	N/A	
Motherboard	IB917	
Operating System	• Windows 10 (32/64-bit)	
	Expansion	
Internal Expansion Bus	1 x Mini-PCIe full size	
Expansion Slot	N/A	
Wireless	Optional	
Storage Space		
HDD	1 x 2.5" SATA	
Removable	N/A	
Power		
Power Input Range	10~24V DC Input	
Construction		
Chassis Material	Aluminum	
Color (Front /Back)	Black / Black	
IP Rating	IP65 rated front bezel	
Mounting	VESA 100 x100	
Environment		
Operating Temperature	0 ~ 50 °C (32 ~ 122 °F)	
Storage Temperature	-20 ~ 70 °C (-4 ~ 158 °F)	
Storage Humidity	10 ~ 90% (non-condensing)	
Certification	CE, FCC Class B, LVD	

All specifications are subject to change without prior notice.



1.5 Overview

Front View



Oblique View



I/O View



No.	Name	No.	Name
1	Power Switch	6	Display Port
2	COM1 RS-232/422/485 Port	7	Mic In
3	USB 3.0 Port x 4	8	Line in
4	GbE LAN x 2	9	Power input
5	HDMI		



No.	Name
А	Optional SMA anttena hole
В	Optional SMA anttena hole
С	Built-in speaker
D	Built-in speaker
Е	SSD/HDD cover



1.6 Dimensions

Unit: mm



Chapter 2 Hardware Configuration

The information provided in this chapter includes:

- Memory installation and membrane keypad extension
- Information and locations of connectors



Avoid device disassembly: Disassembly, modification, or any attempt at repair could generate hazards and cause damage to the device, injury, or property damage, and will void any warranty. If you need to make any changes to the device, be sure to unplug the power cord of the device and have qualified engineers or technicians do the disassembly or installation.

2.1 Rear Cover Disassembly

In case you need to remove the rear cover to install or replace a memory module or a mini-PCIe card, unscrew the 16 screws as shown below to remove the rear cover. Take extra care to open the rear cover.



2.2 Memory Replacement

To replace or install memory modules, perform the following steps after removing the system rear cover.

- 1. Locate the memory slot and align the key of the memory module with that on the memory slot.
- 2. Insert the module slantwise and gently push the module straight down until the clips of the slot close to hold the module in place when the module touches the bottom of the slot.



To remove the module, press the clips outwards with both hands.



2.3 Mini-PCIe Card Installation

To replace or install a mini-PCIe card, perform the following steps after removing the rear cover.

1. Locate the mini-PCIe, align the key of the card to the interface, and insert the card slantwise.

2. Push the card down and fix it with the supplied flat head screw.



2.4 SSD/HDD Replacement

1. For changing SSD/HDD, unscrew the following 2 screws to open-up the SSD/HDD tray.



 Once open-up the storage cover, you will see the SSD/HDD device, Please gentle release the SATA cable at first





Then unscrew 4 screw as following:



(Be careful, don't let the screw drop into the system)

3. Then you are possible to take the SSD/HDD device with bracket up, please unscrew 4 screw at right and left side to change/install the new SSD/HDD.



Finally, please reverse procedures to fix the SSD/HDD device.

2.5 VESA Mounting Installation

You will need to prepare the VESA mount bracket in advance. Tighten 4 screws as shown below to attach the mounting brackets to the system.



2.6 Pin out for COM1

• COM1 RS232/422/485 Port



COM 1 features jumperless selection for RS-232/422/485, which is configurable in BIOS.

Pin	Signal Name	Pin	Signal Name
1	DCD, Data carrier detect	6	DSR, Data set ready
2	RXD, Receive data	7	RTS, Request to send
3	TXD, Transmit data	8	CTS, Clear to send
4	DTR, Data terminal ready	9	RI, Ring indicator
5	Ground		

Din	Signal Name			
FIII	RS-232	RS-422	RS-485	
1	DCD	TX-	DATA-	
2	RX	TX+	DATA+	
3	ТХ	RX+	NC	
4	DTR	RX-	NC	
5	Ground	Ground	Ground	
6	DSR	NC	NC	
7	RTS	NC	NC	
8	CTS	NC	NC	
9	RI	NC	NC	

2.7 Setting the Jumpers

Configure the jumpers with the settings required to be able to use the features needed for your application. Contact your supplier if you have doubts about the best configuration for your use.

How to Set the Jumpers

Jumpers are short-length conductors consisting of several metal pins with a non-conductive base mounted on the circuit board. Jumper caps are used to have the functions and features enabled or disabled. If a jumper has 3 pins, you can connect either PIN1 to PIN2 or PIN2 to PIN3 by shorting with the jumper cap.





A jumper cap

Pin closed	Oblique view	Illustration
Open		$\Box \bigcirc \bigcirc$ $1 \ 2 \ 3$
1-2		1 2 3
2-3		□ • • 1 2 3

Refer to the illustration below to set the jumpers.

When two pins of a jumper are encased in a jumper cap, this jumper is **closed**, i.e. turned **On**.

When a jumper cap is removed from two jumper pins, this jumper is **open**, i.e. turned **Off**.

2.8 Jumper & Connector Locations

Motherboard: IB917



Motherboard location



For motherboard setting, you must open the rear cover (Ref: section 2.1). We don't suggest you do this way because it may cause system **lose warranty** due to any unexpected actions.

2.9 Jumpers Quick Reference

Function	Jumper Name
CMOS Data Clearance	JP2
ME Register Clearance	JP3
LVDS Panel Power / Brightness Selections	JP4 (For power) / JP5 (For brightness)
Factory Use Only	JP1

2.9.1 CMOS Data Clearance (JP2)



Function	Pin closed	Illustration
Normal (default)	1-2	1
Clear CMOS	2-3	1

2.9.2 ME Register Clearance (JP3)



Function	Pin closed	Illustration
Normal (default)	1-2	○ ● 1 ■
Clear ME	2-3	• • 1

2.9.3 LVDS Panel Power / Brightness Selections (JP4 / JP5) Notice: you cannot change this setting with UPC-7210



Jumper	Function	Pin closed	Illustration
	3.3V (default)	1-2	1 • •
JP4	5V	2-3	1 • •
ID5	3.3V (default)	Open	1 🗆 O
JPD	5V	Close	1

2.10 Connectors Quick Reference

Function	Connector Name	
COM1 RS-232/422/485 Port	CN9	
Audio Connector	J1	
SATA HDD Power Connector	J5	
Front Panel Setting Connector	J6	
USB 2.0 Connector	J7	
Battery Connector	J10	
COM 2, COM3, COM4 RS- 232 Ports	J15, J12, J11	
DC Power Input Connector	J13	
Digital I/O Connector	J16	
LCD Backlight Connector	J19	
LVDS Connectors	J17 (1 st channel), J18 (2 nd channel)	
CPU Fan connector	CPU_FAN1	
SATA III Port	CN1, CN3	
HDMI 1.4 Port	CN4	
Display Port	CN5	
GbE LAN Ports	CN6	
USB 3.0 Port	CN7, CN8	
DDR4 SO-DIMM Slot	J2, J4	
Mini-PCIe / mSATA Slot	J8	
Factory Use Only	J3, J9, J14	



2.10.1 COM1 RS-232/422/485 Port (CN9)



COM1 port is jumper-less and configurable in BIOS.

Pin	Assignment	Pin	Assignment
1	DCD, Data carrier detect	6	DSR, Data set ready
2	RXD, Receive data	7	RTS, Request to send
3	TXD, Transmit data	8	CTS, Clear to send
4	DTR, Data terminal ready	9	RI, Ring indicator
5	Ground		

Din	Assignment			
FIII	RS-232	RS-422	RS-485	
1	DCD	TX-	DATA-	
2	RX	TX+	DATA+	
3	ТХ	RX+	NC	
4	DTR	RX-	NC	
5	Ground	Ground	Ground	
6	DSR	NC	NC	
7	RTS	NC	NC	
8	CTS	NC	NC	
9	RI	NC	NC	

Pin	Assignment	Pin	Assignment
1	Lineout_L	2	Lineout_R
3	JD_FRONT	4	Ground
5	LINEIN_L	6	Linein_R
7	JD_LINEIN	8	Ground
9	MIC_L	10	MIC-R
11	JD_MIC1	12	Ground

2.10.3 SATA HDD Power Connector (J5)



Pin	Assignment	Pin	Assignment
1	+5V	3	Ground
2	Ground	4	+12V

2.10.4 Front Panel Connector (J6)



Pin	Assignment	Pin	Assignment
1	Ground	2	PWR_BTN
3	3.3V	4	HDD Active
5	Ground	6	Reset
7	+5V	8	Ground

J6 is utilized for system indicators to provide light indication of the computer activities and switches to change the computer status. It provides interfaces for the following functions.

• ATX Power ON Switch (Pins 1 and 2)

The 2 pins makes an "ATX Power Supply On/Off Switch" for the system that connects to the power switch on the case. When pressed, the power switch will force the system to power on. When pressed again, it will power off the system.

• Hard Disk Drive LED Connector (Pins 3 and 4)

This connector connects to the hard drive activity LED on control panel. This LED will flash when the HDD is being accessed.

• Reset Switch (Pins 5 and 6)

The reset switch allows you to reset the system without turning the main power switch off and then on again. Orientation is not required when making a connection to this header.

• Power LED: Pins 7 and 8

This connector connects to the system power LED on control panel. This LED will light when the system turns on.

2.10.5 USB 2.0 Connector (J7)



Pin	Assignment	Pin	Assignment
1	VCC	2	Ground
3	D0-	4	D1+
5	D0+	6	D1-
7	Ground	8	VCC

2.10.6 Battery Connector (J10)



Pin	Assignment	
1	Battery+	
2	Ground	

Hardware Configuration

2

2.10.7 COM2, COM3, COM4 RS-232 Ports (J15, J12, J11)



Pin	Assignment	Pin	Assignment
1	DCD, Data carrier detect	2	RXD, Receive data
3	TXD, Transmit data	4	DTR, Data terminal ready
5	Ground	6	DSR, Data set ready
7	RTS, Request to send	8	CTS, Clear to send
9	RI, Ring indicator	10	Not Used

2.10.8 DC Power Input Connector (J13)



Pin	Assignment	
1	+9V ~ +24V	
2	Ground	

2.10.9 Digital I/O Connector (J16)



Pin	Assignment	Pin	Assignment
1	Ground	2	VCC
3	OUT3	4	OUT1
5	OUT2	6	OUT0
7	IN3	8	IN1
9	IN2	10	INO

2.10.10 LCD Backlight Connector (J19)





Pin	Assignment	Pin	Assignment
1	+12V	3	Brightness Control
2	Backlight Enable	4	Ground



2

2.10.11 LVDS Connector (J17, J18)



Pin	Assignment	Pin	Assignment
1	TX0P	2	TX0N
3	Ground	4	Ground
5	TX1P	6	TX1N
7	Ground	8	Ground
9	TX2P	10	TX2N
11	Ground	12	Ground
13	CLKP	14	CLKN
15	Ground	16	Ground
17	TX3P	18	TX3N
19	Power	20	Power

4.2.13 CPU Fan Connector (CPU_FAN1)



Pin	Assignment	Pin	Assignment
1	Ground	3	CPU Fan In
2	12V	4	CPU Fan Out

Chapter 3 Driver Installation

The information provided in this chapter includes:

- Intel[®] Chipset Software Installation Utility
- VGA Driver
- HD Audio Driver
- LAN Driver
- Intel[®] Management Engine Drivers Installation





3.1 Introduction

This section describes the installation procedures for software and drivers. The software and drivers are included with the motherboard. If you find anything missing, please contact the distributor where you made the purchase. The contents of this section include the following:

Note: After installing your Windows operating system, you must install the Intel[®] Chipset Software Installation Utility first before proceeding with the drivers installation.

3.2 Intel[®] Chipset Software Installation Utility

The Intel[®] Chipset drivers should be installed first before the software drivers to install INF files for Plug & Play function for Intel chipset components. Follow the instructions below to complete the installation.

1. Insert the disk enclosed in the package with the board. Click **Intel** on the left pane and then **Intel(R) Kabylake-U Chipset Drivers** on the right pane.



2. Click Intel(R) Chipset Software Installation Utility.



- 3. When the *Welcome* screen to the Intel[®] Chipset Device Software appears, click **Next** to continue.
- 4. Accept the software license agreement and proceed with the installation process.
- 5. On the Readme File Information screen, click Install for installation.
- 6. After the installation, restart the computer for changes to take effect.

3.3 Intel Graphics Driver Installation

1. Insert the disk enclosed in the package with the board. Click **Intel** on the left pane and then **Intel(R) Kabylake-U Chipset Drivers** on the right pane.



2. Click Intel(R) HD Graphics Driver.

Inside This CD Version : I-7_Gen-1.0 @4			
Intel LAN Card Tools	Intel(R) Chipset Software Installation Utility Intel(R) HD Graphics Driver Realtek High Definition Audio Driver Intel(R) PRO LAN Network Drivers Intel(R) ME 11.x Drivers		
(Intel(R) HD Graphics Driver		


3. When the *Welcome* screen appears, click **Next** to continue.

Intel® Installation Framework		<u>1119</u> 9	
Intel® Graphics Driv	er	(intel
This setup program will install the following compo - Intel® Graphics Driver - Intel® Display Audio Driver It is strongly recommended that you exit all prog	onents: rams before conti	nuing. Click Next	to continue.
☑ Automatically run WinSAT and enable the Wir	dows Aero deskt	op theme (if supp	ported).
	< <u>B</u> ack	<u>N</u> ext > — Intel® Insta	<u>C</u> ancel allation Framework

- 4. Click **Yes** to accept the license agreement and click **Next** until the installation starts.
- 5. On the *Readme File Information* screen, click **Next** until the installation starts.
- 6. After the installation, restart the computer for changes to take effect.



3.4 HD Audio Driver Installation

1. Insert the disk enclosed in the package with the board. Click **Intel** on the left pane and then **Intel(R) Kabylake-U Chipset Drivers** on the right pane.



2. Click Realtek High Definition Audio Driver.

Inside T	Version : I-7_Gen-1.0 @4
Intel LAN Card Cools	Intel(R) Chipset Software Installation Utility Intel(R) HD Graphics Driver Realtek High Definition Audio Driver Intel(R) PRO LAN Network Drivers Intel(R) ME 11.x Drivers
8	Realtek High Definition Audio Driver

3. On the *Welcome* screen of the InstallShield Wizard, click Next.

Realtek High Definition Audio Dr	Ver Setup (4.27) R2.79 InstallShield Wizard Complete The InstallShield Wizard has successfully installed Realtek High Definition Audio Driver. Before you can use the program, you must restart your computer. • Yes, I want to restart my computer now. • No, I will restart my computer later. Remove any disks from their drives, and then click Finish to complete setup.
InstallShield	< Back Finish Cancel

- 4. Click **Next** until the installation starts.
- 5. After the installation, restart the computer for changes to take effect.



3.5 LAN Driver Installation

1. Insert the disk enclosed in the package with the board. Click **Intel** on the left pane and then **Intel(R) Kabylake-U Chipset Drivers** on the right pane.

Ins	ide T	Version : I-7_Gen-1.0 @4
	Intel AN Card Tools	Intel(R) Kabylake Chipset Drivers Intel(R) Kabylake-U Chipset Drivers
	8	Support Intel(R) Kabylake-U Chipset Drivers

2. Click Intel(R) PRO LAN Network Drivers..

Inside T	Version : I-7_Gen-1.0 @4
Intel LAN Card Cools	Intel(R) Chipset Software Installation Utility Intel(R) HD Graphics Driver Realtek High Definition Audio Driver Intel(R) PRO LAN Network Drivers Intel(R) ME 11.x Drivers
8	Intel(R) PRO LAN Network Drivers



3. When the *Welcome* screen appears, click **Next**.

Intel(R) Network Connections Install W Welcome to the install wizard fo Network Connections	/izard <mark>r Intel(R)</mark>		(intel)
Installs drivers, Intel(R) Ne Networking Services.	twork Connec	tions, and Advanced	
WARNING: This program is international treaties.	s protected by	r copyright law and	
	< Back	Next >	Cancel

- 4. Accept the license agreement and click Next.
- 5. On the *Setup Options* screen, click the checkbox to select the desired driver(s) for installation. Then click **Next** to continue.

Intel(R) Network Connections Install Wiza	ard		×
Setup Options Select the program features you want in	nstalled.		(intel)
Install:			
Intel(R) PROSet for Windows* Devi Advanced Network Services Advanced Network Services Windows* PowerShell Module Intel(R) Network Connections SNMF	ce Manager 9 Agent		
Feature Description			
	< <u>B</u> ack	<u>N</u> ext >	Cancel

- 6. The wizard is ready for installation. Click Install.
- 7. After the installation, restart the computer for changes to take effect.



3.6 Intel[®] Management Engine Drivers Installation

1. Insert the disk enclosed in the package with the board. Click **Intel** on the left pane and then **Intel(R) Kabylake-U Chipset Drivers** on the right pane.

Inside T	his CD Version : I-7_Gen-1.0 @4
Intel	Intel(R) Kabylake Chipset Drivers Intel(R) Kabylake-U Chipset Drivers
Tools	
8	Support Intel(R) Kabylake-U Chipset Drivers

2. Click Intel(R) ME 11.x Drivers.

Inside T	his CD Version : I-7_Gen-1.0 @4
Intel LAN Card Cols	Intel(R) Chipset Software Installation Utility Intel(R) HD Graphics Driver Realtek High Definition Audio Driver Intel(R) PRO LAN Network Drivers Intel(R) ME 11.x Drivers
8	Intel(R) ME 11.x Drivers

3. When the Welcome screen appears, click Next.



- 4. Accept the license agreement and click **Next** until the installation starts.
- 5. After the installation, restart the computer for changes to take effect.



Chapter 4 BIOS Setup

This chapter describes the different settings available in the AMI BIOS that comes with the board. The topics covered in this chapter are as follows:

- Main Settings
- Advanced Settings
- Chipset Settings
- Security Settings
- Boot Settings
- Save & Exit



Avoid changing the default settings:

We strongly suggest you contact IBASE for technical support before you make any changes in BIOS. Please be noted that the device may malfunction if you change the BIOS settings improperly.

4.1 Introduction

The BIOS (Basic Input/Output System) installed in the ROM of your computer system supports Intel® processors. The BIOS provides critical low-level support for standard devices such as disk drives, serial ports and parallel ports. It also provides password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

4.2 BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Press the key immediately allows you to enter the Setup utility. If you are a little bit late pressing the key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup.

If you still need to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again.

The following message will appear on the screen:

Press to Enter Setup

In general, press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help, and <Esc> to quit.

When you enter the BIOS Setup utility, the *Main Menu* screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

Warning: It is strongly recommended that you avoid making any changes to the chipset defaults.

These defaults have been carefully chosen by both AMI and your system manufacturer to provide the absolute maximum performance and reliability. Changing the defaults could make the system unstable and crash in some cases.

4.3 Main Settings

Aptio Setup Util Main Advanced Chipset Secu	<mark>ity – Copyright (C) 2016 A</mark> ma rity Boot Save & Exit	erican Megatrends, Inc.
Memory RC Version Total Memory Memory Frequency	1.0.3.1 4096 MB 2133 MHz	Set the Date. Use Tab to switch between Date elements.
System Date System Time	[Thu 12/29/2016] [15:45:11]	
		<pre>++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2 18 12	63 Copuright (C) 2016 Amer	ican Megatrends Inc

BIOS Setting	Description
System Date	Sets the date. Use the <tab> key to switch between the data elements.</tab>
System Time	Set the time. Use the <tab> key to switch between the data elements.</tab>

4.4 Advanced Settings

This section allows you to configure, improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility – Copyright (C) 2017 American Main Advanced Chipset Security Boot Save & Exit	Megatrends, Inc.
CPU Configuration Power & Performance PCH-FW Configuration Trusted Computing ACPI Settings LVDS (eDP/DP) Configuration iSmart Controller F81846 Super IO Configuration Hardware Monitor CSM Configuration USB Configuration	<pre> #+: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1263. Copyright (C) 2017 American M	egatrends, Inc.

4.4.1 CPU Configuration

Aptio Setup L Advanced	Utility – Copyright	(C) 2017 American	Megatrends, Inc.
CPU Configuration			
Туре	Intel(R)	Core(TM) CPU @ 2 80CH7	
ID Speed	0×806E9 2900 MHz	61 0 @ 2.000m2	
			↔+: Select Screen †↓: Select Item
			Enter: Select +∕–: Change Opt.
			F1: General Help F2: Previous Values
			F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.18	8.1263. Copyright (C) 2017 American Me	egatrends, Inc.

Displays the type, ID and speed of the CPU.

Note: The CPU information displayed varies upon your actual CPU type.

4.4.2 Power & Performance

Aptio Setup Utility – Copyright (C) 2016 American Advanced	Megatrends, Inc.
Power & Performance	CPU – Power Management Control
▶ CPU – Power Management Control	operons
	↔+: Select Screen †↓: Select Item
	Enter: Select +∕–: Change Opt.
	F1: General Help F2: Previous Values
	F3: Optimized Defaults F4: Save & Exit
	LOD. EAIL
Version 2.18.1263. Copyright (C) 2016 American Me	gatrends. Inc.

Aptio Setup Utility – Advanced	Copyright (C) 2016 American	n Megatrends, Inc.
CPU – Power Management Control		Allows more than two frequency
Intel(R) SpeedStep(tm) Intel(R) Speed Shift Technology	[Enabled] [Enabled]	ranges to be supported.
		<pre>++: Select Screen f4: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1263. C	opyright (C) 2016American M	Megatrends, Inc.

BIOS Setting	Description
Intel(R) SpeedStep(tm)	Allows more than two frequency ranges to be supported.
Intel(R) Speed Shift Technology	Enables / Disables Intel(R) Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.



4.4.3 PCH-FW Configuration

ME Firmware Version 11.6.0.1117 When Disabled ME will be into ME Firmware Mode ME Firmware Mode Normal Mode into ME Temporarily Disa	e put
ME Firmware SKU Corporate SKU Mode. ME File System Integrity Value 2 ME Firmware Status 1 0x9000055 ME Firmware Status 2 0x6600810E NFC Support Disabled ME State [Enabled] MAT BIOS Features [Enabled] AMT Configuration [Disabled] Comms Hub Support [Disabled] JHI Support [Disabled] Firmware Update Configuration #1: Select Item Firmware Update Configuration F1: General Help ME Debug Configuration F2: Previous Values F3: Optimized Defaults F3: Optimized Defaults F4: Save & Exit ESC: Exit	ib1ed

BIOS Setting	Description
ME State	When disabled ME will be put into ME Temporarily Disabled Mode.
Manageability Features State	Enables / Disables Intel(R) manageability features in FW. To disable support platform must be in an unprovisioned state first.
AMT BIOS Features	When disabled AMT BIOS features are no longer supported and user is no longer able to access MEBx Setup. Note: This option does not disable manageability features in FW.
AMT Configuration	Configures Intel(R) Active Management Technology Parameters.
Comms Hub Support	Enables / Disables support for Comms Hub.
JHI Support	Enables / Disables Intel(R) DAL Host Interface Service (JHI).
Core BIOS Done Message	Enables / Disables Core BIOS done message sent to ME.
Firmware Update Configuration	Configures Management Engine Technology parameters.
PTT Configuration	Configures PTT capability or state.

BIOS Setting	Description
ME Debug Configuration	Configures ME debug options. Note: This menu is provided for testing puropses. It is recommended to leave the options in their default states.

4.4.3.1. AMT Configuration

Aptio Setup Uti Advanced	lity – Copyright (C) 2017 Ame.	erican Megatrends, Inc.
ASF support	[Enabled]	Enable/Disable Alert Standard
USB Provisioning of AMT CIRA Configuration ASF Configuration Secure Erase Configuration OEM Flags Settings MEBx Resolution Settings	[Disabled]	<pre>Format support. ++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1	.263. Copyright (C) 2017 Amer	ican Megatrends, Inc.

BIOS Setting	Description
ASF Support	Enables / Disables Alert Standard Format support.
USB Provisioning of AMT	Enables / Disables of AMT USB provisioning.
CIRA Configuration	Configures remote assistance process parameters.
ASF Configuration	Configures Alert Standard Format parameters.
Secure Erase Configutation	Secures erase configuration menu.
OEM Flags Settings	Configures OEM Flags.
MEBx Resolution Settings	Shows resolution settings for MEBx display modes.



CIRA Configuration

Aptio Setup Ut: Advanced	ility — Copyright (C) 2016 Amer	rican Megatrends, Inc.
PET Progress WatchDog OS Timer BIOS Timer	[Enabled] [Disabled] 0 0	Enable/Disable PET Events Progress to receive PET Events. ++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.18.1	1263. Copyright (C) 2016 Americ	can Megatrends, Inc.

BIOS Setting	Description
Activate Remote	Trigger CIRA boot.
Assistance Process	Note: Network Access must be activated
	first from MEBx Setup.

ASF Configuration

Aptio Setup Utility Advanced	– Copyright (C) 2016 American	Megatrends, Inc.
PET Progress WatchDog OS Timer BIOS Timer	[Enabled] [Disabled] O O	Enable/Disable PET Events Progress to receive PET Events.
		<pre>++: Select Screen f↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1263.	Copyright (C) 2016 American M	legatrends, Inc.

BIOS Setting	Description
PET Progress	Enables / Disables PET events progress to receive PET events.
WatchDog	Enables / Disables the watchdog timer.



Secure Erase Configuration:

Aptio Setup Advanced	Utility – Copyright (C) 2016 Amer	rican Megatrends, Inc.
Advanced Secure Erase mode Force Secure Erase	[Simulated] [Disabled]	Change Secure Erase module behavior: Simulated: Performs SE flow without erasing SSD Real: Erase SSD. ++: Select Screen fl: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit F5:: F*it
Version 2.	18.1263. Copyright (C) 2016 Americ	can Megatrends, Inc.

BIOS Setting	Description	
Secure Erase Mode	Changes Secure Erase module behavior.	
	 Simulated performs SE flow without erasing SSD. Real erases SSD. 	
Force Secure Erase	Force Secure Erase on next boot.	

OEM Flags Settings:

Aptio Setu; Advanced	o Utility – Copyright (C) 2016 A	merican Megatrends, Inc.
MEBx hotkey Pressed MEBx Selection Screen Hide Unconfigure ME Conf. Prompt MEBx OEM Debug Menu Enabl Unconfigure ME	[Disabled] [Disabled] irmation [Disabled] le [Disabled] [Disabled] .18.1263. Copyright (C) 2016 Ame	OEMFLag Bit 1: Enable automatic MEBx hotkey press.
BIOS Setting D	escription	

DIOU Octaing	Description
MEBx hotkey Pressed	OEMFlag Bit 1: enables automatic MEBx hotkey press.



BIOS Setting	Description
OEMFLag Bit 1	Enables / Disables Automatic MEBx hotkey press.
MEBx Selection Screen	OEMFlag Bit 2: enables MEBx selection screen with 2 options.
	 Press 1 to enter ME configuration screens. Press 2 to initiate a remote connection. Note: Network access must be activated from MEBx Setup for this screen to be displayed.
Hide Unconfigure ME Confirmation Prompt	OEMFlag Bit 6: hides the unconfigure ME confirmation prompt when attempting ME unconfiguration.
MEBx OEM Debug Menu Enable	OEMFlag Bit 14: enables OEM debug menu in MEBx.
Unconfigure ME	OEMFlag Bit 15: Unconfigures ME with resetting MEBx password to default.

MEBx Resolution Settings:

Aptio Setup Utility - Advanced	Copyright	(C) 2016 American	Megatrends, Inc.
Non-UI Mode Resolution UI Mode Resolution Graphics Mode Resolution	[Auto] [Auto] [Auto]		Resolution for non-UI text mode. ++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.18.1263. C	opyright (C) 2016 American Me	egatrends, Inc.

BIOS Setting	Description
Non-UI Mode Resloution	Sets resolution fro non-UI text mode.
UI Mode Resolution	Sets resolution for UI text mode.
Graphics Mode Resolution	Sets resolution for graphics mode.



4.4.3.2. Firmware Update Configuration

Aptio Setup Ut Advanced	ility – Copyright (C) 2017 Amer	rican Megatrends, Inc.
Me FW Image Re-Flash	[Disabled]	<pre>Fnable/Disable Me FW Image Re-Flash function. **: Select Screen fl: Select Item Enter: Select +/-: Change Opt. Fl: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.	1263. Copyright (C) 2017 Americ	can Megatrends, Inc.

BIOS Setting	Description
ME FW Image RE- Flash	Enables / Disables ME FW Image Re-Flash function.

4.4.3.3. PTT Configuration

Aptio Setup Utility Advanced	– Copyright (C) 2016 Am	erican Megatrends, Inc.
PTT Capability / State TPM Device Selection PTP aware OS	1 / 0 [dTPM] [PTP Aware]	Selects TPM device: PTT or dTPM. PTT – Enables PTT in SkuMgr dTPM 1.2 – Disables PTT in SkuMgr Warning ! PTT/dTPM will be disabled and all data saved on it will be lost.
		++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.18.1263.	Copyright (C) 2016 Amer	ican Megatrends, Inc.

BIOS Setting	Description	
TPM Device	Selects TPM device: PTT or dTPM.	
Selection	 PTT enables PTT in SkuMgr. dTPM 1.2 disables PTT in SkuMgr warning. PTT/dTPM will be disabled and all data saved on it will be lost. 	

4.4.3.4. ME Debug Configuration

Aptio Setup Utility Advanced	– Copyright (C) 2016 Ame	erican Megatrends, Inc.
HECI Timeouts Force ME DID Init Status CPU Replaced Polling Disable ME DID Message HECI Retry Disable HECI Retry Disable MBP HOB Skip HECI2 Interface Communication KT Device IDER Device End Of Post Message DOI3 Setting for HECI Disable	[Enabled] [Disabled] [Disabled] [Enabled] [Disabled] [Disabled] [Disabled] [Enabled] [Enabled] [Send in DXE] [Disabled]	Enable/Disable HECI Send/Receive Timeouts.
		<pre>++: Select Screen fl: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>

BIOS Setting	Description
HECI Timeouts	Enables / Disables HECI sending/receiving timeouts.
Force ME DID Init Status	Forces the DID initialization status value.
CPU Replaced Polling Disable	Disables CPU replacement polling loop.
ME DID Message	Enables / Disables ME DID message (disable will prevent the DID message from being sent).
HECI Retry Disable	Setting this option disables retry mechanism for all HECI APIs.
HECI Message Check Disable	Disables message check for BIOS boot path when sending messages.
MBP HDB Skip	Enables / Disables skip of MBP HDB.
HECI2 Interface Communicationn	Adds / Removes HECI2 device from PCI space.
KT Device	Enables / Disables KT device.
IDER Device	Enables / Disables IDER device.
End of Post Message	Enables / Disables end of Post message sent to ME.
DOI3 Setting for HECI Disable	Disables setting DOI3 bit for all HECI devices.

4.4.4 Trusted Computing

Aptio Setup Utility - Advanced	- Copyright (C) 2016 Americar	∣ Megatrends, Inc.
TPM20 Device Found Security Device Support Active PCR banks Available PCR banks SHA-1 PCR Bank SHA256 PCR Bank Pending operation Platform Hierarchy Storage Hierarchy Endorsement Hierarchy TPM2.0 UEFI Spec Version Physical Presence Spec Version TPM 20 InterfaceType Device Select	[Enable] SHA-1, SHA256 SHA-1, SHA256 [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [TCG_2] [1.2] [TIS] [Auto]	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available. ++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2 18 1263 (Conuright (C) 2016 American M	legatrends Inc

BIOS Setting	Description
Security Device Support	Enables / Disables BIOS support for security device. OS will not show security device. TCG EFI protocol and INTIA interface will not be available.
SHA-1 PCR Bank	Enables / Disables SHA-1 PCR Bank.
SHA256 PCR Bank	Enables / Disables SHA256 PCR Bank.
Pending operation	Schedule an operation for the security device. Note: Your computer will reboot during
	device.
Platform Hierarchy	Enables / Disables platform hierarchy.
Storage Hierarchy	Enables / Disables storage hierarchy.
Endorsement Hierarchy	Enables / Disables endorsement hierarchy.
TPM2.0 UEFI Spec Version	 Selects the supported TCG version based o your OS. TCG_1_2: supports Windows 8 /10. TCG_2: supports new TCG2 protocol and event format for Windows 10 or



BIOS Setting	Description	
Physical Presence Spec Version	Selects to show the PPI Spec Version (1.2 or 1.3) that the OS supports.	
	Note: Some HCK tests might not support 1.3.	
Device Select	 TPM 1.2 will restrict support to TPM 1.2 devices only. TPM 2.0 will restrict support to TPM 2.0 devices only. Auto will support both with the default being set to TPM 2.0 deices if not found, and TPM 1.2 device will be enumerated. 	

4.4.5 ACPI Settings

Aptio Setup Utility - Advanced	· Copyright (C) 2016 American	Megatrends, Inc.
ACPI Settings		Enables or Disables System ability to Hibernate (OS/S4 Sleep State) This option may
Enable Hibernation ACPI Sleep State	[Enabled] [S3 (Suspend to RAM)]	be not effective with some OS.
		<pre>++: Select Screen f↓: Select Item Enter: Select </pre>
		F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Evit
		ESC: Exit
	Conuright (P) 2016 American M	egatrends Inc

BIOS Setting	Description
Enable Hibernation	Enables / Disables the system ability to hibernate (OS/S4 Sleep State). This option may be not effective with some OS.
ACPI Sleep State	Selects an ACPI sleep state (Suspend Disabled or S3) where the system will enter when the Suspend button is pressed.



4.4.6 LVDS (eDP/DP) Configuration

3.3.1 Noticed: please do not change LVDS setting under UPC-7210

Aptio Setup Utility - Advanced	Copyright (C) 2017 American	Megatrends, Inc.
LVDS (eDP/DP) Configuration LVDS (eDP/DP) Support Panel Color Depth LVDS Channel Type LCD Panel Type Brightness Control	[Enabled] [24bit(VESA)] [Single] [VBIOS Default] [Disabled]	<pre>++: Select Screen ↑+: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Vencion 2 10 1262 0	opunight (C) 2017 American M	odatpande Tre

BIOS Setting	Description	
LVDS (eDP/DP) Support	Enables / Disables LVDS (eDP/DP).	
Panel Color Depth	Selects the panel collor depth. Options: 18 bit, 24 Bit (VESA), 24 bit (JEIDA)	
LVDS Channel Type	Chooses the LVDS as single or dual channel.	
LCD Panel Type	Selects LCD panel used by Intel Graphics Device by selecting the appropriate setup item.	
	Resolution Options: VBIOS Default, 640 x 480, 800 x 600, 1024 x 768, 1280 x 1024, 1400 x 1050, 1366 x 768, 1600 x 1200, 1680 x 1050, 1920 x 1200, 1440 x 900, 1600 x 900, 1280 x 800, 1920 x 1080, 2048 x 1536	
Brightness Control	Enables / Disables the brightness control.	



4.4.7 iSMART Controller

Aptio Setup Utility Advanced	y – Copyright (C) 2016 Ame	rican Megatrends, Inc.
iSmart Controller		
Power-On after Power failure Temperature Guardian Schedule Slot 1 Schedule Slot 2	[Disable] [Disable] [None] [None]	→+: Select Screen
		<pre>\$\$\$ \$</pre>

BIOS Setting	Description
Power-On after Power failure	Enables / Disables the system to be turned on automatically after a power failure.
Temperature Guardian	Generate the reset signal when system hands up on POST.
Schedule Slots	Sets up the hour / minute / day for the power-on schedule for the system. Options: • None • Power On • Power On / Off

4.4.8 F81846 Super IO Configuration

Aptio Setup Utility Advanced	– Copyright	(C) 2017 American	Megatrends, Inc.
F81846 Super IO Configuration			Set Parameters of Serial Port
Super IO Chip	F81846		
 Serial Port 1 Configuration Serial Port 2 Configuration Serial Port 3 Configuration Serial Port 4 Configuration 			
			<pre>++: Select Screen f1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1263.	Copyright (C) 2017 American Me	egatrends, Inc.

BIOS Setting	Description
Serial Ports	Sets parameters of serial ports.
Configuration	Enables / Disables the serial port and select an optimal setting for the Super IO device.

4.4.8.1. Serial Port 1 Configuration



BIOS Setting	Description	
Serial Port	Enables / Disables the serial port.	
Change Settings	 Selects an optimal settings for Super I/O device. Options: Auto IO = 3F8h; IRQ = 4 IO = 3F8h; IRQ = 3, 4, 5, 6, 7, 9, 10, 11, 12 IO = 2F8h; IRQ = 3, 4, 5, 6, 7, 9, 10, 11, 12 IO = 3E8h; IRQ = 3, 4, 5, 6, 7, 9, 10, 11, 12 IO = 2E8h; IRQ = 3, 4, 5, 6, 7, 9, 10, 11, 12 	
F81846 Serial Port 1 Mode Select	Changes the serial port mode to RS-232 / 422 / 485.	

4.4.9 Hardware Monitor

Aptio Setup Utili Advanced	ty – Copyright (C) 2016 Ame	rican Megatrends, Inc.
Advanced Pc Health Status CPU Fan smart fan control CPU temperature System temperature CPU Fan Speed SYS Fan Speed VCORE +5V +12V Memory Voltage VCC3V CPU Shutdown Temperature	[Disabled] : +43 C : 0 RPM : 0 RPM : 0 RPM : +0.728 V : +5.045 V : +12.056 V : +1.200 V : +3.360 V [Disabled]	<pre>++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Vancian 2 10 196	2 Copupidat (C) 2016 Amoni	con Morathanda Tha

BIOS Setting	Description
CPU Fan smart fan control	Enables / Disables smart fan control.
Temperatures / Voltages	These fields are the parameters of the hardware monitoring function feature of the motherboard. The values are read-only values as monitored by the system and show the PC health status.
CPU Shutdown Temperature	Sets a threshold of temperature to shut down if CPU goes overheated. Options: Disabled / 70 °C / 75 °C / 80 °C / 85 °C / 90 °C / 95 °C

4.4.10 CSM Configuration

Aptio Setup U Advanced	tility – Copyright (C) 2016 Americ	an Megatrends, Inc.
Option ROM execution Network	[Do not launch]	Controls the execution of UEFI and Legacy PXE OpROM
		tt: Select Screen
		<pre>tl: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit</pre>
Version 2.18	1.1263. Copyright (C) 2016 American	ESC: Exit Megatrends, Inc.

BIOS Setting	Description
Network	Controls the execution of UEFI and Legacy PXE OpROM.

4.4.11 USB Configuration

Aptio Setup Utility – Advanced	Copyright (C) 2016 American	Megatrends, Inc.
USB Configuration		Enables Legacy USB support. AUTO option disables legacy
USB Module Version	16	support if no USB devices are connected. DISABLE option will
USB Controllers: 1 XHCI		keep USB devices available only for EFI applications.
USB Devices: 1 Keyboard		
Legacy USB Support	[Enabled] [Enabled]	
USB Mass Storage Driver Support Port 60/64 Emulation	[Enabled] [Disabled]	
USB hardware delays and time-outs:		↔+: Select Screen ↑↓: Select Item
USB transfer time-out	[20 sec]	Enter: Select
Device power-up delay	[Auto]	F1: General Help
		F2: Previous Values
		F3: Optimized Defaults F4: Save & Exit
		ESC: Exit
Version 2.18.1263. Co	pyright (C) 2016 American M	egatrends, Inc.

BIOS Setting	Description	
Legacy USB Support	 Enabled enables Legacy USB support. Auto disables legacy support if there is no USB device connected. 	
	Disabled keeps USB devices available only for EFI applications.	
XHCI Hand-off	This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.	
USB Mass Storage Driver Support	Enables / Disables the support for USB mass storage driver.	
Port 60/64 Emulation	Enables / Disables the support for I/O port 60h / 64h emulation. This should be enabled for the complete USB keyboard legacy support for non-USB aware OSes.	
USB Transfer time- out	The time-out value (1 / 5 10 / 20 secs) for Control, Bulk, and Interrupt transfers.	
Device reset time- out	Gives seconds (10 / 20 / 30 / 40 secs) to delay execution of Start Unit command to USB mass storage device.	
Device power-up delay	The maximum time the device will take before it properly reports itself to the Host Controller.	
	Auto uses default value for a Root port it is 100ms. But for a Hub port, the delay is taken from Hub descriptor.	

4.5 Chipset Settings

Aptio Setup Utility – Copyright (C) 2016 American Main Advanced <mark>Chipset</mark> Security Boot Save & Exit	Megatrends, Inc.
▶ PCH-IO Configuration	<pre>eDP Control ++: Select Screen t1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1263. Copyright (C) 2016 American Me	egatrends, Inc.

4.5.1 PCH-IO Configuration

Aptio Setup Utility - Chipset	Copyright (C) 2016 Americar	Megatrends, Inc.
PCH-IO Configuration ▶ SATA And RST Configuration PCH LAN Controller	[Enabled]	SATA Device Options Settings
Wake on LAN Enable	(Enabled)	
		<pre>++: Select Screen f1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1263. C	opyright (C) 2016 American ⊦	legatrends, Inc.

BIOS Setting	Description
SATA and RST Configuration	SATA device options and settings
PCH LAN Controller	Enables / Disables onboard NIC.
Wake on LAN Enable	Enables / Disables integrated LAN to wake the system.



Aptio Setup Utility Chipset	– Copyright (C) 2016 America	n Megatrends, Inc.
Chipset Chipset SATA And RST Configuration SATA Controller(s) SATA Mode Selection Serial ATA Port 0 Software Preserve Port 0 Hot Plug Serial ATA Port 1 Software Preserve Port 1 Hot Plug	(Enabled) [AHCI] Empty Unknown [Enabled] [Disabled] Empty Unknown [Enabled] [Disabled]	Enable/Disable SATA Device.
Serial ATA Port 2 Software Preserve Port 2 Hot Plug	Empty Unknown [Enabled] [Disabled]	<pre>++: Select Screen fl: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>

BIOS Setting	Description
SATA Controller(s)	Enables / Disables the Serial ATA.
SATA Mode Selection	Selects IDE or AHCI Mode.
Serial ATA Port 0~2	Enables / Disables Serial Port 0 ~ 2.
SATA Ports Hot Plug	Enables / Disables SATA Ports HotPlug.

4.6 Security Settings

Password DescriptionSet Administrator PasswordIf ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup. If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights. The password length must be in the following range: Minimum length Maximum length User PasswordSet Administrator Password#*: Select Screen 14: Select Item Enter: Select F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	Aptio Setup U Main Advanced Chipset <mark>S</mark>	tility – Copyright (C) 2016 American <mark>ecurity </mark> Boot Save & Exit	n Megatrends, Inc.
Administrator Password User Password User Password ++: Select Screen +1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	Password Description If ONLY the Administrator's then this only limits acces only asked for when enterin If ONLY the User's password is a power on password and boot or enter Setup. In Set have Administrator rights. The password length must be in the following range: Minimum length Maximum length	password is set, s to Setup and is g Setup. is set, then this must be entered to up the User will 3	Set Administrator Password
	Administrator Password User Password	20	<pre>++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>

BIOS Setting	Description
Setup Administrator Password	Sets an administrator password for the setup utility.
User Password	Sets a user password.

4.7 Boot Settings

Aptio Setup Utility – Copyright (C) 2016 American Megatrends, Inc. Main Advanced Chipset Security <mark>Boot</mark> Save & Exit		
Boot Configuration Setup Prompt Timeout Bootup NumLock State Quiet Boot Fast Boot	1 [Off] [Disabled] [Disabled]	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
Driver Option Priorities Boot mode select	[LEGACY]	
FIXED BOOT ORDER Priorities Boot Option #1 Boot Option #2 Boot Option #3 Boot Option #4 Boot Option #5 Boot Option #6 Boot Option #7 Boot Option #8	[Hard Disk] [CD/DVD] [USB Hard Disk] [USB CD/DVD] [USB Key] [USB Floppy] [USB Lan] [Network]	<pre>++: Select Screen fl: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1263. Com	oyright (C) 2016 American M	egatrends. Inc.

BIOS Setting	Description
Setup Prompt Timeout	Number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.
Bootup NumLock State	Selects the keyboard NumLock state.
Quiet Boot	Enables / Disables Quiet Boot option.
Fast Boot	Enables / Disables boot with initialization of a minimal set of devices required to launch the active boot option. Has no effect for BBS boot options.
Boot mode select	Selects a Boot mode, Legacy / UEFI / Dual.
Boot Option Priorities	Sets the system boot order priorities for hard disk, CD/DVD, USB, Network.

4.8 Save & Exit Settings

Aptio Setup Utility – Copyright (C) 2016 American Main Advanced Chipset Security Boot <mark>Save & Exit</mark>	Megatrends, Inc.
Save Options Save Changes and Exit Discard Changes and Reset Discard Changes and Reset Save Changes Discard Changes Default Options Restore Defaults Save as User Defaults Restore User Defaults Boot Override	<pre>Exit system setup after saving the changes. +*: Select Screen f1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.18.1263. Copyright (C) 2016 American M	egatrends. Inc.

BIOS Setting	Description
Save Changes and Exit	Exits system setup after saving the changes.
Discard Changes and Exit	Exits system setup without saving any changes.
Save Changes and Reset	Resets the system after saving the changes.
Discard Changes and Reset	Resets system setup without saving any changes.
Save Changes	Saves changes done so far to any of the setup options.
Discard Changes	Discards changes done so far to any of the setup options.
Restore Defaults	Restores / Loads defaults values for all the setup options.
Save as User Defaults	Saves the changes done so far as User Defaults.
Restore User Defaults	Restores the user defaults to all the setup options.

Appendix

This section provides the mapping addresses of peripheral devices and the sample code of watchdog timer configuration.

- I/O Port Address Map
- Interrupt Request Lines (IRQ)
- Watchdog Timer Configuration



A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. The following table lists the I/O port addresses used.

Address	Device Description
0x00000020-0x00000021	Programmable interrupt controller
0x00000024-0x00000025	Programmable interrupt controller
0x00000028-0x00000029	Programmable interrupt controller
0x0000002C-0x0000002D	Programmable interrupt controller
0x00000030-0x00000031	Programmable interrupt controller
0x00000034-0x00000035	Programmable interrupt controller
0x00000038-0x00000039	Programmable interrupt controller
0x0000003C-0x0000003D	Programmable interrupt controller
0x000000A0-0x000000A1	Programmable interrupt controller
0x000000A4-0x000000A5	Programmable interrupt controller
0x000000A8-0x000000A9	Programmable interrupt controller
0x000000AC-0x000000AD	Programmable interrupt controller
0x000000B0-0x000000B1	Programmable interrupt controller
0x000000B4-0x000000B5	Programmable interrupt controller
0x000000B8-0x000000B9	Programmable interrupt controller
0x000000BC-0x000000BD	Programmable interrupt controller
0x000004D0-0x000004D1	Programmable interrupt controller
0x00000A00-0x00000A0F	Motherboard resources
0x00000A10-0x00000A1F	Motherboard resources
0x00000A10-0x00000A1F	Motherboard resources
0x0000002E-0x0000002F	Motherboard resources
0x0000004E-0x0000004F	Motherboard resources
0x0000061-0x00000061	Motherboard resources

Address	Device Description
0x00000063-0x00000063	Motherboard resources
0x00000065-0x00000065	Motherboard resources
0x00000067-0x00000067	Motherboard resources
0x00000070-0x00000070	Motherboard resources
0x00000070-0x00000070	System CMOS/real time clock
0x0000080-0x0000080	Motherboard resources
0x00000092-0x00000092	Motherboard resources
0x000000B2-0x000000B3	Motherboard resources
0x00000680-0x0000069F	Motherboard resources
0x0000FFFF-0x0000FFFF	Motherboard resources
0x0000FFFF-0x0000FFFF	Motherboard resources
0x0000FFFF-0x0000FFFF	Motherboard resources
0x00001800-0x000018FE	Motherboard resources
0x0000164E-0x0000164F	Motherboard resources
0x00001854-0x00001857	Motherboard resources
0x000003F8-0x000003FF	Communications Port (COM1)
0x000002F8-0x000002FF	Communications Port (COM2)
0x000003E8-0x000003EF	Communications Port (COM3)
0x000002E8-0x000002EF	Communications Port (COM4)
0x00000000-0x00000CF7	PCI Express Root Complex
0x00000D00-0x0000FFFF	PCI Express Root Complex
0x00000040-0x00000043	System timer
0x00000050-0x00000053	System timer
0x0000E000-0x0000EFFF	Mobile 6th/7th Generation Intel(R) Processor Family I/O PCI Express Root Port #11 - 9D1A
0x0000F040-0x0000F05F	Mobile 6th/7th Generation Intel(R) Processor Family I/O SMBUS - 9D23
0x0000FF00-0x0000FFFE	Motherboard resources
0x0000060-0x0000060	Standard PS/2 Keyboard
0x00000064-0x00000064	Standard PS/2 Keyboard
0x0000F090-0x0000F097	Standard SATA AHCI Controller
0x0000F080-0x0000F083	Standard SATA AHCI Controller
0x0000F060-0x0000F07F	Standard SATA AHCI Controller
0x0000F000-0x0000F03F	Intel(R) HD Graphics 620
0x000003B0-0x000003BB	Intel(R) HD Graphics 620
0x000003C0-0x000003DF	Intel(R) HD Graphics 620
B. Interrupt Request Lines (IRQ)

Peripheral devices use interrupt request lines to notify CPU for the service required. The following table shows the IRQ used by the devices on board.

Level	Function		
IRQ 0	System timer		
IRQ 1	Standard PS/2 Keyboard		
IRQ 3	Communications Port (COM2)		
IRQ 4	Communications Port (COM1)		
IRQ 5	Communications Port (COM3)		
IRQ 7	Communications Port (COM4)		
IRQ 8	System CMOS/real time clock		
IRQ 11	Mobile 6th/7th Generation Intel(R) Processor Family I/O SMBUS - 9D23		
IRQ 11	Mobile 6th/7th Generation Intel(R) Processor Family I/O Thermal subsystem - 9D31		
IRQ 12	Microsoft PS/2 Mouse		
IRQ 14	Motherboard resources		
IRQ 16	High Definition Audio Controller		
IRQ 54 ~ IRQ 204	Microsoft ACPI-Compliant System		
IRQ 256 ~ IRQ 511	Microsoft ACPI-Compliant System		
IRQ 4294967285	Intel(R) Management Engine Interface		
IRQ 4294967286	Intel(R) I211 Gigabit Network Connection		
IRQ 4294967287	Intel(R) I211 Gigabit Network Connection		
IRQ 4294967288	Intel(R) I211 Gigabit Network Connection		
IRQ 4294967289	Intel(R) I211 Gigabit Network Connection		
IRQ 4294967290	Intel(R) USB 3.0 eXtensible Host Controller - 1.0 (Microsoft)		
IRQ 4294967291	Intel(R) HD Graphics 620		
IRQ 4294967292	Intel(R) Ethernet Connection I219-V		
IRQ 4294967293	Standard SATA AHCI Controller		
IRQ 4294967294	Mobile 6th/7th Generation Intel(R) Processor Family I/O PCI Express Root Port #11 - 9D1A		

C. Watchdog Timer Configuration

The Watchdog Timer (WDT) is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven.

Under normal circumstance, you will need to restart the WDT at regular intervals before the timer counts to zero.

Sample Code:

```
//--
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//--
#include <dos.h>
#include <conio.h>
#include <stdio.h>
#include <stdlib.h>
#include "F81866.H"
11
int main (int argc, char *argv[]);
void EnableWDT(int);
void DisableWDT(void);
//-
int main (int argc, char *argv[])
{
              unsigned char bBuf;
              unsigned charbTime;
              char **endptr;
              char SIO:
              printf("Fintek 81866 watch dog program\n");
              SIO = Init_F81866();
              if (SIO == 0)
              {
                            printf("Can not detect Fintek 81866, program abort.\n");
                            return(1);
              }//if (SIO == 0)
              if (argc != 2)
                            printf("Parameter incorrect!!\n");
                            return (1);
              }
              bTime = strtol (argv[1], endptr, 10);
              printf("System will reset after %d seconds\n", bTime);
              if (bTime)
              { EnableWDT(bTime); }
              else
              { DisableWDT(); }
              return 0;
11
void EnableWDT(int interval)
{
              unsigned char bBuf;
              bBuf = Get_F81866_Reg(0x2B);
              bBuf &= (~0x20);
              Set_F81866_Reg(0x2B, bBuf);
                                                  //Enable WDTO
              Set_F81866_LD(0x07);
                                                  //switch to logic device 7
              Set_F81866_Reg(0x30, 0x01);
                                                  //enable timer
              bBuf = Get_F81866_Reg(0xF5);
              bBuf &= (~0x0F);
              bBuf |= 0x52:
              Set_F81866_Reg(0xF5, bBuf);
                                                  //count mode is second
              Set_F81866_Reg(0xF6, interval);
                                                  //set timer
              bBuf = Get_F81866_Reg(0xFA);
              bBuf |= 0x01;
              Set_F81866_Reg(0xFA, bBuf);
                                                  //enable WDTO output
              bBuf = Get_F81866_Reg(0xF5);
              bBuf l= 0x20:
              Set F81866 Reg(0xF5, bBuf);
                                                  //start counting
```

void DisableWDT(void)



//

//--

{

unsigned char bBuf;

Set_F81866_LD(0x07); //switch to logic device 7 bBuf = Get_F81866_Reg(0xFA); bBuf &= -0x01; Set_F81866_Reg(0xFA, bBuf); //disable WDTO output bBuf = Get_F81866_Reg(0xF5); bBuf &= -0x20; bBuf |= 0x40; Set_F81866_Reg(0xF5, bBuf); //disable WDT

// // THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY // KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE // IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR // PURPOSE. //

#include "F81866.H"
#include <dos.h>
//----unsigned intF81866_BASE;

void Unlock_F81866 (void); void Lock_F81866 (void); //-----

unsigned int Init_F81866(void)

unsigned int result; unsigned charucDid;

F81866_BASE = 0x4E; result = F81866_BASE;

ucDid = Get_F81866_Reg(0x20); if (ucDid == 0x07) //Fintek 81866 { goto lnit_Finish; }

F81866_BASE = 0x2E; result = F81866_BASE;

ucDid = Get_F81866_Reg(0x20); if (ucDid == 0x07) //Fintek81866 { goto Init_Finish; }

F81866_BASE = 0x00; result = F81866_BASE;

Init_Finish:

return (result);

, //----

{

}

{

{

void Unlock_F81866 (void)

outportb(F81866_INDEX_PORT, F81866_UNLOCK); outportb(F81866_INDEX_PORT, F81866_UNLOCK);

//-----void Lock_F81866 (void)

outportb(F81866_INDEX_PORT, F81866_LOCK);

void Set_F81866_LD(unsigned char LD)

Unlock_F81866(); outportb(F81866_INDEX_PORT, F81866_REG_LD); outportb(F81866_DATA_PORT, LD); Lock_F81866();

} //-----

}

outportb(F81866_DATA_PORT, DATA); Lock_F81866();

Lock_F81866(); return Result;

}

//-// // THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY // KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE // IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR // PURPOSE. // //----_____ #ifndef F81866_H #define F81866_H 1 //-#define F81866_INDEX_PORT #define F81866_DATA_PORT (F81866_BASE) (F81866_BASE+1) //---#define F81866_REG_LD0x07 //---#define F81866_UNLOCK #define F81866_LOCK 0xAA 0x87 //--unsigned int Init_F81866(void); void Set_F81866_LD(unsigned char); void Set_F81866_Reg(unsigned char, unsigned char); unsigned char Get_F81866_Reg(unsigned char); //-

#endif // F81866_H

//-

iBASE

D. Onboard Connector Reference Types

Function	Connector Name	Onboard Type	Compatible Mating Type
Audio Connector	J1	Hao Guo Xing Ye DF11-12S-PA66H	Hirose DF11-12DS-2C
SATA HDD Power Connector	J5	E-call 0110-071-040	JST XHP-4
Front Panel Setting Connector	J6	Dupon 2.54 mm-pitch pin header (Male)	Dupon 2.54 mm-pitch (Female)
USB 2.0 Connector	J7	Hao Guo Xing Ye DF11-8S-PA66H	Hirose DF11-8DS-2C
Battery Connector	J10	Molex 53047-0210	Molex 51021-0200
COM 2, COM3, COM4 RS-232 Ports	J15, J12, J11	Hao Guo Xing Ye DF11-10S-PA66H	Hirose DF11-10DS-2C
DC Power Input Connector	J13	Hao Guo Xing Ye WAFER396-2S-WV	JST VHR-2N
Digital I/O Connector	J16	Dupon 2.00 mm-pitch pin header (Male)	Dupon 2.00 mm-pitch (Female)
LCD Backlight Connector	J19	E-CALL 0110-161-040	JST PHR-4.
LVDS Connectors	J17 (1st channel), J18 (2nd channel)	Hirose DF20G-20DP-1V	Hirose DF20A-20DS-1C