

IB889

AMD eNile Platform
Geneva ASB2 CPU+785E+SB820M
3.5" Disk Size SBC

USER'S MANUAL

Version 1.1

Acknowledgments

PS/2 is a trademark of International Business Machines Corporation.

AMD and Athlon™ II Neo are registered trademarks of Advanced Micro Devices, Inc.

Microsoft Windows is a registered trademark of Microsoft Corporation.

Winbond is a registered trademark of Winbond Electronics Corporation.

All other product names or trademarks are properties of their respective owners.

Table of Contents

Introduction	1
Product Description.....	1
Checklist.....	2
IB889 Specifications	3
Board Dimensions	4
Installations	5
Installing the Memory	6
Setting the Jumpers	7
Connectors on IB889.....	10
BIOS Setup.....	17
Drivers Installation	37
VGA Drivers Installation	38
Audio Drivers Installation	43
LAN Drivers Installation.....	44
Appendix	47
A. I/O Port Address Map.....	47
B. Interrupt Request Lines (IRQ)	48
C. Watchdog Timer Configuration.....	49

This page is intentionally left blank.

Introduction

Product Description

The 3.5-inch disk-size IB889 is based on the AMD Athlon™ II Neo processor built with the AMD 785E chipset. Dimensions of the board are 102mm x 147mm. It features a low-power design, with one SO-DIMM socket supporting DDR3 memory modules for a maximum size of 4GB system memory.

Features

- AMD Athlon™ II Neo / Turion™ II Neo Processors on board, up to 2.2GHz
- 1 x DDR3 SO-DIMM , Max. 4GB
- Integrated HD4200, supports DVI and LVDS
- 2 x PCI-E Gigabit LAN
- 2x SATA III, 6x USB 2.0, 2x COM,
- Digital I/O, Watchdog timer

The IB889 is currently available in the following configurations:

IB889-22	AMD Turion™ II Neo N54L (2.2GHz), 785E, 3.5"-inch Disk Size SBC w/ DVI and dual PCI-E Gigabit LAN
IB888-13	AMD Athlon™ II Neo N36L (1.3GHz), 785E, 3.5"-inch Disk Size SBC w/ DVI and dual PCI-E Gigabit LAN

Remarks: Specifications and offerings are subject to change without prior notice.

Checklist


Your IB889 package should include the items listed below.

- The IB889 3.5" disk-size SBC
- This User's Manual
- 1 CD containing chipset drivers and flash memory utility
- Cable kit for SATA and COM port
- Optional cables for USB and audio

IB889 Specifications

Product Name	IB889-13 / IB889-22
Form Factor	3.5" Disk Size SBC
CPU Type	AMD Geneva ASB2 Turion™ II Neo / Athlon™ II Neo DC CPU
CPU Operate Frequency	Dual-Core CPU (27 x 27 mm) /45nm SOI / 812-ball package FSB=3200 MHz Hyper Transport AMD Athlon™ II Neo N36L=1.3GHz DC (12W) AMD Turion™ II Neo N54L=2.2GHz DC (25W)
Cache	2MB
Green /APM	APM1.2
CPU Socket	812-ball BGA ASB2 CPU on board
Chipset	AMD 785E NB : 21 mm x 21 mm AMD SB820M SB: 21mm x 21mm
BIOS	AMI BIOS, support ACPI function
Memory	DDRIII-800 SO-DIMM x1 , Single Channel, Max. 4GB (Non-ECC, 1.5V)
VGA	AMD 785E built-in ATi HD4200 Graphics Core 1 x Dual Link DVI-I connector (via 785E TMDS & RAM DAC)
LVDS	AMD 785E built-in 1 x 24-bit dual channels w/ DF13 socket x2 (via LVTM)
LAN	Realtek 8111DL PCI-Express GbE x 1 for 1 st LAN Realtek 8111DL PCI-Express GbE x 1 for 2 nd LAN
USB	SB820M built-in USB 2.0 host controller, supports 6 ports
Audio	SB820M Built-in HD Audio engine + Audio Codec Realtek ALC662 w/ 5.1 channels (Line-out, Line-in, Mic.)
Expansion Slot	Mini PCI-e socket x 1 w/ USB for Wireless LAN or TV-tuner module
Parallel IDE/ CF	N/A
Serial ATA Ports	SB820M built-in SATA controller, supports 2 x ports for SATA 3.0
LPC I/O	W83627DHG-P: COM1 (RS232/422/485), COM2 (RS232) & hardware monitor (3 thermal inputs, 6 voltage monitor inputs, 2 fan headers).
Edge Connector	DVI-I Connector x 1 RJ45 x 2 for LAN 1 & LAN 2 Dual USB stack connector x2 for USB1/2 & 3/4 DC jack x 1
On Board Header / Connectors	DF13 Socket x2 for LVDS 2x4 pins header x1 for USB 5/6 2x6 pins header x1 for Audio 2x10 pins header x1 for COM1 (RS232/422/485) & COM2(RS232 only) 2x5 pins headers x 1 for LPC(80-port card debugging purpose) 5 pins box header x 1 for smart battery 4 pins box header x 1 for backlight/brightness control 4-pins power connector x 1 for SATA HDD 3-pins connector x 1 for CPU fan 2-pins connector x 1 for DC-in power
Digital I/O	4 in & 4 out
Watchdog Timer	Yes (256 segments, 0, 1, 2...255. sec/min)
Power Connector	+12V DC-IN
Board Size	102x147mm

Board Dimensions



Installations

This section provides information on how to use the jumpers and connectors on the IB889 in order to set up a workable system. The topics covered are:

Installing the Memory	6
Setting the Jumpers.....	7
Connectors on IB889	10


Installing the Memory

The IB889 board supports a DDR3 memory socket for a maximum total memory of 4GB in DDR3 800 memory type.

Installing and Removing Memory Modules

To install DDR3 modules, locate the memory socket on the board and perform the following steps:

1. Hold the DDR3 module so that the keys of the DDR3 module align with those on the memory slot.
2. Gently push the DDR3 module in an angle as shown in the picture below until the clips of the sockets lock to hold the DDR3 module in place when the DDR3 module touches the bottom of the socket.
3. To remove the DDR3 module, press the clips with both hands.




Setting the Jumpers

Jumpers are used on IB889 to select various settings and features according to your needs and applications. Contact your supplier if you have doubts about the best configuration for your needs. The following lists the connectors on IB889 and their respective functions.



Jumper Locations on IB889.....	8
JP5: Clear CMOS Setting	9
JP1, JP2, JP3: RS232/422/485 (COM1) Selection	9
JP4: ATX or AT Power Selection	9
JP6: LCD Panel Power Selection	9

Jumper Locations on IB889



Jumpers on IB889	Page
JP5: Clear CMOS Setting	9
JP1, JP2, JP3: RS232/422/485 (COM1) Selection	9
JP4: ATX or AT Power Selection.....	9
JP6: LCD Panel Power Selection.....	9

JP5: Clear CMOS Setting


JP5	Setting
	Normal
	Clear CMOS

JP1, JP2, JP3: RS232/422/485 (COM1) Selection

COM1 is selectable for RS232, RS-422 and RS-485.



COM2 is fixed for RS-232 use only.

The following table describes the jumper settings for COM1 selection.





COM1 Function	RS-232	RS-422	RS-485
Jumper Setting (pin closed)	JP1: 1-2	JP1: 3-4	JP1: 5-6
	JP2: 3-5 & 4-6	JP2: 1-3 & 2-4	JP2: 1-3 & 2-4
	JP3: 3-5 & 4-6	JP3: 1-3 & 2-4	JP3: 1-3 & 2-4

JP4: ATX or AT Power Selection

JP4	ATX Power
	ATX
	AT


JP6: LCD Panel Power Selection

JP6	LCD Panel Power
	3.3V
	5V


Connectors on IB889

Connector Locations on IB889	11
CN13, CN14: USB0/1/4/5 Ports	12
CN11, CN12: GbE RJ45 Ports	12
CN17: DVI-I Connector	12
CN15, CN16: DC-IN 12V Power Connector	12
FAN1: System Fan Power Connector	12
CN1: Audio Connector (DF11 Connector)	13
CN3: HDD Power Connector	13
CN4, CN6: Serial ATA Connectors	13
CN5: LCD Backlight Connector	13
CN9/CN8: LVDS Connector (1st channel, 2nd channel)	14
CN10: USB2/USB3 Connector	14
J1: Digital I/O	14
J2: COM1/2: Serial Port	15
J5: System Function Connector	16
J6: SPI Flash Connector (factory use only)	16

Connector Locations on IB889




Connectors on IB889	Page
CN13, CN14: USB0/1/4/5 Ports.....	12
CN11, CN12: GbE RJ45 Ports	12
CN17: DVI-I Connector	12
CN15, CN16: DC-IN 12V Power Connector	12
FAN1: System Fan Power Connector	12
CN1: Audio Connector (DF11 Connector)	13
CN3: HDD Power Connector	13
CN4, CN6: Serial ATA Connectors	13
CN5: LCD Backlight Connector	13
CN9/CN8: LVDS Connector (1st channel, 2nd channel).....	14
CN10: USB2/USB3 Connector	14
J1: Digital I/O	14
J2: COM1/2: Serial Port	15
J5: System Function Connector.....	16
J6: SPI Flash Connector (factory use only)	16



CN13, CN14: USB0/1/4/5 Ports


CN11, CN12: GbE RJ45 Ports

CN17: DVI-I Connector



Signal Name	Pin #	Pin #	Signal Name
DATA 2-	1	16	HOT POWER
DATA 2+	2	17	DATA 0-
Shield 2/4	3	18	DATA 0+
DATA 4-	4	19	SHIELD 0/5
DATA 4+	5	20	DATA 5-
DDC CLOCK	6	21	DATA 5+
DDC DATA	7	22	SHIELD CLK
VSYNC	8	23	CLOCK -
DATA 1-	9	24	CLOCK +
DATA 1+	10	C1	Red.
SHIELD 1/3	11	C2	Green
DATA 3-	12	C3	Blue
DATA 3+	13	C4	HSYNC
DDC POWER	14	C5	Ground
A GROUND 1	15	C6	Ground


CN15, CN16: DC-IN 12V Power Connector



Pin #	Signal Name
1	DC in (12V only)
2	Ground


FAN1: System Fan Power Connector

FAN1 are 3-pin headers for system fans. The fan must be a 12V fan.




Pin #	Signal Name
1	Ground
2	+12V
3	Rotation detection

CN1: Audio Connector (DF11 Connector)



Signal Name	Pin #	Pin #	Signal Name
LINEOUT R	2	1	LINEOUT L
Ground	4	3	JD FRONT
LINEIN R	6	5	LINEIN
Ground	8	7	JD LINEIN
MIC-In	10	9	MIC L
Ground	12	11	JD MIC1


CN3: HDD Power Connector



Pin #	Signal Name
1	+5V
2	Ground
3	Ground
4	+12V

CN4, CN6: Serial ATA Connectors


CN5: LCD Backlight Connector



Pin #	Signal Name
1	+12V
2	Backlight Enable
3	Backlight Adj
4	Ground

CN9/CN8: LVDS Connector (1st channel, 2nd channel)


The LVDS connectors, DF13 20-pin mating connectors, are composed of the first channel (CN9) and second channel (CN8) to support 24-bit or 48-bit.



Signal Name	Pin #	Pin #	Signal Name
TX0-	2	1	TX0+
Ground	4	3	Ground
TX1-	6	5	TX1+
*5V/3.3V	8	7	Ground
TX3-	10	9	TX3+
TX2-	12	11	TX2+
Ground	14	13	Ground
TXC-	16	15	TXC+
*5V/3.3V	18	17	VDD_EDID
DAT_EDID	20	19	CLK_EDID


*JP6 can be used to set 3.3V or 5V.

CN10: USB2/USB3 Connector



Signal Name	Pin	Pin	Signal Name
Vcc	1	2	Ground
D0-	3	4	D1+
D0+	5	6	D1-
Ground	7	8	Vcc


J1: Digital I/O



Signal Name	Pin	Pin	Signal Name
GND	1	2	VCC
OUT3	3	4	OUT1
OUT2	5	6	OUT0
IN3	7	8	IN1
IN2	9	10	IN0

J2: COM1/2: Serial Port

J2 COM1 serial port connector is jumper selectable for RS-232, RS-422 and RS-485. COM2 serial port support RS-232 only.



Signal Name	Pin #	Pin #	Signal Name
DSR1 Data set ready	2	1	DCD1 Data carrier detect
RTS1 Request to send	4	3	RXD1 Receive data
CTS1 Clear to send	6	5	TXD1 Transmit data
RI1 Ringing indicator	8	7	DTR1 Data terminal ready
Not used	10	9	Ground
DSR2	12	11	DCD2
RTS2	14	13	RXD2
CTS2	16	15	TXD2
RI2	18	17	DTR2
Not used	20	19	Ground

Pin #	Signal Name		
	RS-232	R2-422	RS-485
1	DCD1	TX-	DATA-
2	DSR1	NC	NC
3	RXD1	TX+	DATA+
4	RTS1	RTS1	RTS1
5	TXD1	RX+	NC
6	CTS1	NC	NC
7	DTR1	RX-	NC
8	RI1	NC	NC
9	Ground	Ground	Ground
10	NC	NC	NC

J5: System Function Connector



ATX Power ON Switch: Pins 1 and 2

This 2-pin connector is an “ATX Power Supply On/Off Switch” on the system that connects to the power switch on the case. When pressed, the power switch will force the system to power on. When pressed again, it will force the system to power off.

Power LED: Pins 3 and 4

Pin #	Signal Name
3	Vcc
4	Ground

Hard Disk Drive LED Connector: Pins 5 and 6

This connector connects to the hard drive activity LED on control panel. This LED will flash when the HDD is being accessed.

Pin #	Signal Name
6	HDD Active
5	Vcc

Reset Switch: Pins 7 and 8

The reset switch allows the user to reset the system without turning the main power switch off and then on again.

J6: SPI Flash Connector (factory use only)

BIOS Setup

This chapter describes the different settings available in the AMI (American Megatrends, Inc.) BIOS that comes with the board. The topics covered in this chapter are as follows:

BIOS Introduction	18
BIOS Setup.....	18
Main BIOS Setup	19
Advanced Settings	20
PCI/PnP Settings.....	26
Boot Settings	27
Security Settings.....	29
Advanced Chipset Settings.....	30
Exit Setup	35

BIOS Introduction

The BIOS provides critical low-level support for a standard device such as disk drives, serial ports and parallel ports. It also adds virus and password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Pressing the key immediately allows you to enter the Setup utility. If you are a little bit late pressing the key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup. If you still wish to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again. The following message will appear on the screen:

Press to Enter Setup

In general, you press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help and <Esc> to quit.

When you enter the Setup utility, the Main Menu screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

Advanced Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

BIOS SETUP UTILITY

Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
<p>Advanced Settings</p> <p>WARNING: Setting wrong values in below sections may cause system to malfunction.</p> <ul style="list-style-type: none"> ▶ CPU Configurations ▶ IDE Configuration ▶ Super IO Configuration ▶ Hardware Health Configuration ▶ ACPI Configuration ▶ AHCI Configuration ▶ PCI Express Configuration ▶ Trusted Computing ▶ USB Configuration ▶ Lan Configuration ▶ Power Configuration 		<p>Configure CPU.</p> <p><- Select Screen</p> <p>↑↓ Select Item</p> <p>Enter Go to Sub Screen</p> <p>F1 General Help</p> <p>F10 Save and Exit</p> <p>ESC Exit</p>				

The fields in each section are shown in the following sections, as seen in the computer screen. Please note that setting the wrong values may cause the system to malfunction. If unsure, please contact technical support of your supplier.

BIOS SETUP UTILITY

Advanced	
<p>CPU Configuration</p> <p>Module Version: 15.00 AGESA Version: 1.0.0.0 Physical Count: 1 Logical Count: 2</p> <hr/> <p>AMD Turion™ II Neo N54L Dual Core Processor Revision: C3 Cache L1: 256KB Cache L2: 2048KB Cache L3: N/A Speed: 2200MHz, NB Clk: 1600MHz Able to Change Freq. : Yes uCode Patch Level: 0x10000B6</p> <p>GART Error Reporting [Disabled] Microcode Update [Enabled] Secure Virtual Machine Mode [Enabled] PowerNow [Enabled] C1E Support [Enable]</p>	<p>This option should remain disabled for the normal operation. The driver developer may enable it for testing purpose.</p> <p><- Select Screen</p> <p>↑↓ Select Item</p> <p>+ - Change Field</p> <p>F1 General Help</p> <p>F10 Save and Exit</p> <p>ESC Exit</p>

BIOS SETUP UTILITY

Advanced	
IDE Configuration	
OnBoard PCI IDE Controller	[Both]
▶ Primary IDE Master	: [Not Detected]
▶ Primary IDE Slave	: [Not Detected]
▶ Secondary IDE Master	: [Not Detected]
▶ Secondary IDE Slave	: [Not Detected]
▶ Third IDE Master	: [Not Detected]
▶ Third IDE Slave	: [Not Detected]
▶ Fourth IDE Master	: [Not Detected]
▶ Fourth IDE Slave	: [Not Detected]
Hard Disk Write Protect	[Disabled]
IDE Detect Time Out (Sec)	[35]
ATA(P) 80Pin Cable Detection	[Host & Device]
DISABLED: disables the integrated IDE Controller. PRIMARY: enables only the Primary IDE Controller. SECONDARY: enables only the Secondary IDE Controller. BOTH: enables both IDE Controllers.	
<- Select Screen ↑↓ Select Item +/- Change Field F1 General Help F10 Save and Exit ESC Exit	

The IDE Configuration menu is used to change and/or set the configuration of the IDE devices installed in the system.

BIOS SETUP UTILITY

Advanced	
Configure Win627DHG Super IO Chipset	
Serial Port1 Address [3F8/IRQ4] Serial Port2 Address [2F8/IRQ3] Restore on AC Power Loss [Power Off]	Allows BIOS to Select Serial Port Base Addresses <- Select Screen ↑↓ Select Item +- Change Field F1 General Help F10 Save and Exit ESC Exit

Onboard Serial Port

The default values are:

Serial Port 1: 3F8/IRQ4

Serial Port 2: 2F8/IRQ3

Restore on AC Power Loss

This field sets the system power status whether *Power On* or *Power Off* when power returns to the system from a power failure situation.

BIOS SETUP UTILITY

Advanced	
Hardware Health Configuration	
System Temperature :43°C/109°F CPU Temperature :64°C/147°F NB Temperature :49°C/120°F CPUFAN Speed :6490 RPM Vcore :1.152 V +3.3V :3.328 V +12V :12.196 V VDDR3 :1.480 V VGPU :1.104V +5V : 5.068V VSB :3.328V VBAT :3.328V CPU Shutdown Temperature [Disabled]	Options Disabled 80°C/176°F 85°C/185°F 90°C/194°F 95°C/203°F <- Select Screen ↑↓ Select Item +- Change Field Tab Select Field F1 General Help F10 Save and Exit ESC Exit

BIOS SETUP UTILITY

Advanced	
ACPI Settings	General ACPI Configuration settings
<ul style="list-style-type: none"> ▶ General ACPI Configuration ▶ Advanced ACPI Configuration 	

BIOS SETUP UTILITY

Advanced	
General ACPI Configuration	Select the ACPI state used for System Suspend.
Suspend mode [S1 (POS)] C1E Support [Enable]	

BIOS SETUP UTILITY

Advanced	
Advanced ACPI Configuration	Enable RSDP pointers to 64-bit Fixed System Description Tables. Different ACPI version Has some addition
ACPI Version Features [ACPI v1.0] ACPI APIC support [Enabled] AMI OEMB table [Enabled] Headless mode [Disabled]	

BIOS SETUP UTILITY

Advanced	
AHCI Settings [Enabled]	Enables for supporting AHCI controller in AHCI mode during BIOS control otherwise operates in IDE mode.
AHCI BIOS Support AHCI Port0 [Not Detected] AHCI Port1 [Not Detected] AHCI Port2 [Not Detected] AHCI Port3 [Not Detected] AHCI Port4 [Not Detected] AHCI Port5 [Not Detected]	

BIOS SETUP UTILITY

Advanced	
PCI Express Configuration	Enables/Disables Pci Express Device Relaxed Ordering.
Relaxed Ordering [Auto]	
Maximum Payload Size [Auto]	
Extended Tag Field [Auto]	
No Snoop [Auto]	
Maximum Read Request Size [Auto]	
Active State Power Management [Disabled]	
Extended Synch [Auto]	

BIOS SETUP UTILITY

Advanced	
Trusted Computing	Enable/Disable TPM TCG (TPM 1.1/1.2) supp in BIOS
TCG/TPM SUPPORT [No]	

BIOS SETUP UTILITY

Advanced	
USB Configuration	Configure the USB Mass Storage Class Devices.
Module Version - 2.24.5-13.4	
USB Devices Enabled: 1 Keyboard, 1 Mouse, 1 Drive	
Legacy USB Support [Enabled]	<- Select Screen
USB 2.0 Controller Mode [HiSpeed]	↑↓ Select Item
BIOS EHCI Hand-Off [Enabled]	+ - Change Field
Legacy USB1.1 HC Support [Enabled]	F1 General Help
► USB Mass Storage Device Configuration	F10 Save and Exit
	ESC Exit

The USB Configuration menu is used to read USB configuration information and configure the USB settings.

Legacy USB Support

Enables support for legacy USB. AUTO option disables legacy support if no USB devices are connected.

USB 2.0 Controller Mode

Configures the USB 2.0 controller in HiSpeed (480Mbps) or FullSpeed (12Mbps). This option is enabled by HiSpeed.

BIOS EHCI Hand-Off

Enabled/Disabled. This is a workaround for Oses without EHCI hand-off support. The EHCI ownership change should be claimed by EHCI driver.

Legacy USB1.1 HC Support

Support USB1.1 HC.

BIOS SETUP UTILITY

Advanced	
Lan Configuration	Options
Onboard LAN Option ROM [Disabled]	Disabled Enabled

BIOS SETUP UTILITY

Advanced	
Power Configuration	Disable/Enable RTC to generate a wake event.
RTC Resume [Disabled]	
Resume By Ring [Disabled]	

PCIPnP Settings

This option configures the PCI/PnP settings.

BIOS SETUP UTILITY			
Main	Advanced	PCIPnP	Boot Security Chipset Exit
Advanced PCI/PnP Settings		NO: lets the BIOS Configure all the Devices in the system. YES: lets the operating system configure Plug and Play (PnP) devices not required for boot if your system has a Plug and Play operating system.	
WARNING: Setting wrong values in below sections may cause system to malfunction.			
Clear NVRAM		[No]	
Plug & Play O/S		[No]	
PCI Latency Timer		[64]	
Allocate IRQ to PCI VGA		[Yes]	
Palette Snooping		[Disabled]	
PCI IDE BusMaster		[Enabled]	
OffBoard PCI/ISA IDE Card		[Auto]	
IRQ3		[Available]	
IRQ4		[Available]	
IRQ5		[Available]	
IRQ7		[Available]	
IRQ9		[Available]	
IRQ10		[Available]	
IRQ11		[Available]	
IRQ14		[Available]	
IRQ15		[Available]	
DMA Channel 0		[Available]	
DMA Channel 1		[Available]	
DMA Channel 3		[Available]	
DMA Channel 5		[Available]	
DMA Channel 6		[Available]	
DMA Channel 7		[Available]	
			<- Select Screen ↑↓ Select Item +- Change Field F1 General Help F10 Save and Exit ESC Exit

Clear VRAM

Clear VRAM during system boot.

Plug & Play O/S

This lets BIOS configure all devices in the system or lets the OS configure PnP devices not required for boot if your system has a Plug and Play OS.

Allocate IRQ to PCI VGA

This assigns IRQ to PCI VGA card if card requests IRQ or doesn't assign IRQ to PCI VGA card even if card requests an IRQ.

Palette Snooping

When enabled, PCI will allow VGA palette signals to go to the ISA bus.

PCI IDE BusMaster

This function allows the BIOS to use PCI BusMastering for reading or writing to IDE drives.

OffBoard PCI/ISA IDE Card

This option specifies if an offboard PCI IDE controller adapter card is installed in the computer. You must specify the PCI Expansion slot on the motherboard where the offboard PCI IDE controller is installed. This disables the onboard PCI IDE controller. You must also specify the IRQs for this PCI IDE card.

IRQ#

Use the IRQ# address to specify what IRQs can be assigned to a particular peripheral device.

Boot Settings

BIOS SETUP UTILITY						
Main	Advanced	PCIPnP	Boot	Security	Chipset	Exit
Boot Settings			Configure Settings during System Boot.			
▶ Boot Settings Configuration			<- Select Screen ↑↓ Select Item +- Change Field Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit			
▶ Boot Device Priority						
▶ Hard Disk Drives						
▶ CD/DVD Drives						

BIOS SETUP UTILITY	
Boot	
Boot Settings Configuration	
Quick Boot	[Enabled]
Quiet Boot	[Disabled]
AddOn ROM Display Mode	[Force BIOS]
Bootup Num-Lock	[On]
PS/2 Mouse Support	[Auto]
Wait for 'F1' If Error	[Enabled]
Hit 'DEL' Message Display	[Enabled]
Interrupt 19 Capture	[Disabled]
Allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system.	
<- Select Screen ↑↓ Select Item +- Change Field F1 General Help F10 Save and Exit ESC Exit	

Quick Boot

This allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system.

Quiet Boot

When disabled, this displays normal POST messages. When enabled, this displays OEM Logo instead of POST messages.

AddOn ROM Display Mode

This allows user to force BIOS/Option ROM of add-on cards to be displayed during quiet boot.

Bootup Num-Lock

This select the power-on state for numlock.

PS/2 Mouse Support

This select support for PS/2 mouse.

Wait for 'F1' If Error

When set to Enabled, the system waits for the F1 key to be pressed when error occurs. This allows option ROM to trap interrupt 19.

Hit Message Display

This displays "Press to run Setup" in POST.

Interrupt 19 Capture

This allows option ROMs to trap interrupt 19.

Security Settings

This setting comes with two options set the system password. Supervisor Password sets a password that will be used to protect the system and Setup utility. User Password sets a password that will be used exclusively on the system. To specify a password, highlight the type you want and press <Enter>. The Enter Password: message prompts on the screen. Type the password and press <Enter>. The system confirms your password by asking you to type it again. After setting a password, the screen automatically returns to the main screen.

To disable a password, just press the <Enter> key when you are prompted to enter the password. A message will confirm the password to be disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

BIOS SETUP UTILITY						
Main	Advanced	PCIPnP	Boot	Security	Chipset	Exit
Security Settings				Install or Change the Password.		
Supervisor Password : Not Installed				<- Select Screen ↑↓ Select Item Enter Change F1 General Help F10 Save and Exit ESC Exit		
User Password : Not Installed						
Change Supervisor Password Change User Password						
Boot Sector Virus Protection [Disabled]						

Advanced Chipset Settings

This setting configures the north bridge, south bridge and the ME subsystem. **WARNING!** Setting the wrong values may cause the system to malfunction.

BIOS SETUP UTILITY						
Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
Advanced Chipset Settings					Options for NB	
<p>WARNING: Setting wrong values in below sections may cause system to malfunction.</p> <p>▶ North Bridge Configuration</p> <p>▶ North Bridge2 Configuration</p> <p>▶ South Bridge Configuration</p>					<p><- Select Screen</p> <p>↑↓ Select Item</p> <p>Enter Go to Sub Screen</p> <p>F1 General Help</p> <p>F10 Save and Exit</p> <p>ESC Exit</p>	

BIOS SETUP UTILITY																								
					Chipset																			
North Bridge Chipset Configuration																								
<p>Memory Configuration</p> <p>DRAM Timing Configuration</p> <p>Size of Dimm #0: 1 GB Timing Configuration</p> <p>Size of Dimm #1: Non-Presence</p>																								
<table> <tr><td>Memory CLK</td><td>:400 MHz, N/A</td></tr> <tr><td>CAS Latency(Tcl)</td><td>: 6 CLK , N/A</td></tr> <tr><td>RAS/CAS dELAY(Trcd)</td><td>: 6 CLK , N/A</td></tr> <tr><td>Row Precahrge Time (Trp)</td><td>: 6 CLK , N/A</td></tr> <tr><td>Min Active RAS (Tras)</td><td>: 15 CLK , N/A</td></tr> <tr><td>RAS/RAS Delay (Trrd)</td><td>: 4 CLK , N/A</td></tr> <tr><td>Row Cycle (Trc)</td><td>: 21 CLK , N/A</td></tr> <tr><td>Read to Precharge (Trtp)</td><td>: 4 CLK , N/A</td></tr> <tr><td>Write Recover Time (Twr)</td><td>: 6 CLK , N/A</td></tr> </table>					Memory CLK	:400 MHz, N/A	CAS Latency(Tcl)	: 6 CLK , N/A	RAS/CAS dELAY(Trcd)	: 6 CLK , N/A	Row Precahrge Time (Trp)	: 6 CLK , N/A	Min Active RAS (Tras)	: 15 CLK , N/A	RAS/RAS Delay (Trrd)	: 4 CLK , N/A	Row Cycle (Trc)	: 21 CLK , N/A	Read to Precharge (Trtp)	: 4 CLK , N/A	Write Recover Time (Twr)	: 6 CLK , N/A	<p><- Select Screen</p> <p>↑↓ Select Item</p> <p>Enter Go to Sub Screen</p> <p>F1 General Help</p> <p>F10 Save and Exit</p> <p>ESC Exit</p>	
Memory CLK	:400 MHz, N/A																							
CAS Latency(Tcl)	: 6 CLK , N/A																							
RAS/CAS dELAY(Trcd)	: 6 CLK , N/A																							
Row Precahrge Time (Trp)	: 6 CLK , N/A																							
Min Active RAS (Tras)	: 15 CLK , N/A																							
RAS/RAS Delay (Trrd)	: 4 CLK , N/A																							
Row Cycle (Trc)	: 21 CLK , N/A																							
Read to Precharge (Trtp)	: 4 CLK , N/A																							
Write Recover Time (Twr)	: 6 CLK , N/A																							
<p>HT Link Width Control [Enable]</p> <p>GfxNBPstateDis Support [Enable]</p> <p>T0Time Override [Disabled]</p>																								

Memory Configuration
BIOS SETUP UTILITY

Memory Configuration		Chipset
Channel Interleaving	[Auto]	Enable Channel Memory Interleaving
Enable Clock to All DIMMs	[Disabled]	
Memory Hole Remapping	[Enabled]	
CS Sparing Enable	[Disabled]	
Power Down Enable	[Auto]	
Power Down Mode	[Auto]	
DRAM Parity Enable	[Auto]	
Bank Swizzle Mode	[Auto]	
Power Down Enable	[Auto]	
		<- Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

DRAM Timing Configuration
BIOS SETUP UTILITY

DRAM Timing Configuration		Chipset
		Options
DRAM Timing Config	[Auto]	Auto Manual
		<- Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

NorthBridge2 Chipset Configuration
BIOS SETUP UTILITY

NorthBridge2 Chipset Configuration		Chipset
RS880 CIMx Version : 1.3.0.5		
▶ Internal Graphics Configuration		
NB Power Management Features	[Auto]	<- Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit
Memory Hole	[Disabled]	

Internal Graphics Configuration
BIOS SETUP UTILITY

Internal Graphics Configuration		Chipset
Internal Graphics Mode		Options
UMA Frame Buffer Size	[UMA+SIDEPORT]	Disable
SIDEPORT Clock Speed	[Auto]	UMA
GFX Engine Clock Override	[400MHz]	SIDEPORT
UMA-SP Interleave Mode	[Disable]	UMA+SIDEPORT
SP Power Management	[Auto]	<- Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit
SP NB Termination	[Disable]	
SP Memory Termination	[Disable]	
SP CMD Hold	[Auto]	
SP CMD Hold	[Auto]	
Special Graphics Features	[Disabled]	
FB Location	[Below 4G]	
LVDS Type Select	[NOT EDID]	
LVDS ID Selection	[1024 x 768 24 bit]	
LVDS Back Light Control	[7 (Max)]	

South Bridge Configuration
BIOS SETUP UTILITY

SouthBridge Chipset Configuration		Chipset
<ul style="list-style-type: none"> ▶ SP GPP Port Graphics Configuration ▶ SB Azalia Audio Configuration ▶ SB SATA Configuration 		Options for SB GPP Por <- Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

BIOS SETUP UTILITY

SB GPP Port Configuration		Chipset
SB GPP Function [Enable] GPP Port Link Configuration [1:1:1:1 mode] Unhide unused GPP ports [Disable] GPP Link ASPM [Disable] GPP Lane Reversal [Disabled] NB-SB PHY PLL Power Down [Enable] GPP PHY PLL Power Down [Enable]		Options Disable Enable <- Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

BIOS SETUP UTILITY

Onchip HD Azalia Configuration		Chipset
HD Audio Azalia Device [Enabled] HD Onboard PIN Config [Enabled] Azalia Front Panel [Auto] SDIN0 Pin Config [Azalia] SDIN1 Pin Config [Azalia] SDIN2 Pin Config [Azalia] SDIN3 Pin Config [GPIO] Azalia Snoop [Disabled]		Options Auto Disable Enable <- Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

BIOS SETUP UTILITY

Onchip SATA Configuration		Chipset
OnChip SATA Channel	[Enabled]	Options
OnChip SATA Type	[IDE]	Auto
OnChip IDE Type	[Legacy IDE]	Disable
SATA IDE Combined Mode	[Enabled]	Enable
PATA Channel Config	[SATA as primary]	
		<- Select Screen
		↑↓ Select Item
		Enter Go to Sub Screen
		F1 General Help
		F10 Save and Exit
		ESC Exit

OnChip SATA Type

The options are:

- (1) IDE
- (2) RAID
- (3) AHCI

Exit Setup

The exit setup has the following settings which are:

BIOS SETUP UTILITY						
Main	Advanced	PCIPnP	Boot	Security	Chipset	Exit
Exit Options					Exit system setup after saving the changes.	
Save Changes and Exit					F10 key can be used for this operation	
Discard Changes and Exit						
Discard Changes						
Load Optimal Defaults						
Load Failsafe Defaults						
					<- Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit	

Save Changes and Exit

This option allows you to determine whether or not to accept the modifications and save all changes into the CMOS memory before exit.

Discard Changes and Exit

This option allows you to exit the Setup utility without saving the changes you have made in this session.

Discard Changes

This option allows you to discard all the changes that you have made in this session.

Load Optimal Defaults

This option allows you to load the default values to your system configuration. These default settings are optimal and enable all high performance features.

Load Failsafe Defaults

This option allows you to load the troubleshooting default values permanently stored in the BIOS ROM. These default settings are non-optimal and disable all high-performance features.

This page is intentionally left blank.


Drivers Installation

This section describes the installation procedures for software and drivers under the Windows XP and Windows Vista. The software and drivers are included with the board. If you find the items missing, please contact the vendor where you made the purchase. The contents of this section include the following:



VGA Drivers Installation	38
Audio Drivers Installation	43
LAN Drivers Installation	44

VGA Drivers Installation



1. Insert the CD that comes with the board. Click **AMD** then **AMD 785E Chipset Drivers** and then **AMD 785E Series Graphics Drivers**.




2. When the Welcome Screen appears, click **Next**. Click **Install** to install the ATI software components.





3. Click **Custom** and select the components to install as shown.






4. Accept the license agreement to proceed with installation. Reboot the computer when prompted for changes to take effect.





Audio Drivers Installation

1. Insert the CD that comes with the board. Click **AMD** then **AMD 785E Chipset Drivers** and then **Realtek High Definition Audio Driver**.



2. The Welcome screen to the InstallShield Wizard for Realtek High Definition Audio Driver will appear. At this point, click **Next** to continue the installation process.


3. When installation is completed, restart the computer as prompted. Click **Finish**.

LAN Drivers Installation

1. Insert the CD that comes with the board. Click **LAN Card** at the left side and then **Realtek LAN Controller Drivers**.



2. In the welcome screen of the InstallShield Wizard for REALTEK GbE & FE Ethernet PCI-E NIC Driver, click *Next*.



3. In the InstallShield Wizard screen, click *Install* to begin the installation.

4. InstallShield Wizard completed. Click *Finish* to exit the Wizard.

This page is intentionally left blank.

Appendix

A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses, which also becomes the identity of the device. The following table lists the I/O port addresses used.

Address	Device Description
000h - 01Fh	DMA Controller #1
020h - 03Fh	Interrupt Controller #1
040h - 05Fh	Timer
060h - 06Fh	Keyboard Controller
070h - 07Fh	Real Time Clock, NMI
080h - 09Fh	DMA Page Register
0A0h - 0BFh	Interrupt Controller #2
0C0h - 0DFh	DMA Controller #2
0F0h	Clear Math Coprocessor Busy Signal
0F1h	Reset Math Coprocessor
1F0h - 1F7h	IDE Interface
278 - 27F	Parallel Port #2(LPT2)
2F8h - 2FFh	Serial Port #2(COM2)
2B0 - 2DF	Graphics adapter Controller
378h - 3FFh	Parallel Port #1(LPT1)
360 - 36F	Network Ports
3B0 - 3BF	Monochrome & Printer adapter
3C0 - 3CF	EGA adapter
3D0 - 3DF	CGA adapter
3F0h - 3F7h	Floppy Disk Controller
3F8h - 3FFh	Serial Port #1(COM1)

B. Interrupt Request Lines (IRQ)

Peripheral devices use interrupt request lines to notify CPU for the service required. The following table shows the IRQ used by the devices on board.

Level	Function
IRQ0	System Timer Output
IRQ1	Keyboard
IRQ2	Interrupt Cascade
IRQ3	Serial Port #2
IRQ4	Serial Port #1
IRQ5	Reserved
IRQ6	Floppy Disk Controller
IRQ7	Parallel Port #1
IRQ8	Real Time Clock
IRQ9	Reserved
IRQ10	Reserved
IRQ11	Reserved
IRQ12	PS/2 Mouse
IRQ13	80287
IRQ14	Primary IDE
IRQ15	Secondary IDE

C. Watchdog Timer Configuration

The WDT is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven. Under normal circumstance, the user will restart the WDT at regular intervals before the timer counts to zero.

SAMPLE CODE:

```

=====
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
=====
#include <stdio.h>
#include <stdlib.h>
#include "W627EHF.H"
=====
int main (int argc, char *argv[])
void copyright(void);
void EnableWDT(int);
void DisableWDT(void);
=====
int main (int argc, char *argv[])
{
    unsigned char bBuf;
    unsigned char bTime;
    char **endptr;

    copyright();

    if (argc != 2)
    {
        printf(" Parameter incorrect!!\n");
        return 1;
    }

    if (!Init_W627EHF() == 0)
    {
        printf(" Winbond 83627HF is not detected, program abort.\n");
        return 1;
    }
    bTime = strtol (argv[1], endptr, 10);
    printf("System will reset after %d seconds\n", bTime);

    EnableWDT(bTime);

    return 0;
}
=====

```

```
void copyright(void)
{
    printf("\n===== Winbond 83627EHF Watch Timer Tester (AUTO DETECT) =====\n")
        "      Usage : W627E_WD reset_time\n"
        "      Ex : W627E_WD 3 => reset system after 3 second\n"
        "      W627E_WD 0 => disable watch dog timer\n");
}
//=====
void EnableWDT(int interval)
{
    unsigned char bBuf;

    bBuf = Get_W627EHF_Reg( 0x2D);
    bBuf &= (!0x01);
    Set_W627EHF_Reg( 0x2D, bBuf);           //Enable WDTO

    Set_W627EHF_LD( 0x08);                 //switch to logic device 8
    Set_W627EHF_Reg( 0x30, 0x01);         //enable timer

    bBuf = Get_W627EHF_Reg( 0xF5);
    bBuf &= (!0x08);
    Set_W627EHF_Reg( 0xF5, bBuf);         //count mode is second

    Set_W627EHF_Reg( 0xF6, interval);     //set timer
}
//=====
void DisableWDT(void)
{
    Set_W627EHF_LD(0x08);                 //switch to logic device 8
    Set_W627EHF_Reg(0xF6, 0x00);         //clear watchdog timer
    Set_W627EHF_Reg(0x30, 0x00);         //watchdog disabled
}
//=====
```

```

=====
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
=====
#include "W627EHF.H"
#include <dos.h>
=====
unsigned int W627EHF_BASE;
void Unlock_W627EHF(void);
void Lock_W627EHF(void);
=====
unsigned int Init_W627EHF(void)
{
    unsigned int result;
    unsigned char ucDid;

    W627EHF_BASE = 0x2E;
    result = W627EHF_BASE;

    ucDid = Get_W627EHF_Reg(0x20);
    if (ucDid == 0x88)
    {
        goto Init_Finish;
    }

    W627EHF_BASE = 0x4E;
    result = W627EHF_BASE;
    ucDid = Get_W627EHF_Reg(0x20);
    if (ucDid == 0x88)
    {
        goto Init_Finish;
    }

    W627EHF_BASE = 0x00;
    result = W627EHF_BASE;

Init_Finish:
    return (result);
}
=====
void Unlock_W627EHF(void)
{
    outportb(W627EHF_INDEX_PORT, W627EHF_UNLOCK);
    outportb(W627EHF_INDEX_PORT, W627EHF_UNLOCK);
}
=====
void Lock_W627EHF(void)
{
    outportb(W627EHF_INDEX_PORT, W627EHF_LOCK);
}
=====
void Set_W627EHF_LD(unsigned char LD)
{
    Unlock_W627EHF();
    outportb(W627EHF_INDEX_PORT, W627EHF_REG_LD);
    outportb(W627EHF_DATA_PORT, LD);
    Lock_W627EHF();
}

```

```

=====
void Set_W627EHF_Reg( unsigned char REG, unsigned char DATA)
{
    Unlock_W627EHF();
    outportb(W627EHF_INDEX_PORT, REG);
    outportb(W627EHF_DATA_PORT, DATA);
    Lock_W627EHF();
}
=====
unsigned char Get_W627EHF_Reg(unsigned char REG)
{
    unsigned char Result;
    Unlock_W627EHF();
    outportb(W627EHF_INDEX_PORT, REG);
    Result = inportb(W627EHF_DATA_PORT);
    Lock_W627EHF();
    return Result;
}
=====

=====
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//=====
#ifndef __W627EHF_H
#define __W627EHF_H                1
//=====
#define W627EHF_INDEX_PORT        (W627EHF_BASE)
#define W627EHF_DATA_PORT        (W627EHF_BASE+1)
//=====
#define W627EHF_REG_LD            0x07
//=====
#define W627EHF_UNLOCK            0x87
#define W627EHF_LOCK              0xAA
//=====
unsigned int Init_W627EHF(void);
void Set_W627EHF_LD( unsigned char);
void Set_W627EHF_Reg( unsigned char, unsigned char);
unsigned char Get_W627EHF_Reg( unsigned char);
//=====
#endif __W627EHF_H

```