

MI956

**Intel® Sandy Bridge / PCH
Mini-ITX Motherboard**

USER'S MANUAL

Version 1.0

Acknowledgments

AMI is a registered trademark of American Megatrends Inc.
PS/2 is a trademark of International Business Machines Corporation.

Intel and Intel® Sandy Bridge DC Mobile Processor are registered trademarks of Intel Corporation.

Microsoft Windows is a registered trademark of Microsoft Corporation.

Fintek is a registered trademark of Fintek Electronics Corporation.

All other product names or trademarks are properties of their respective owners.

Table of Contents

Introduction	1
Product Description.....	1
Checklist.....	2
MI956 Specifications	3
Board Dimensions	4
Installations	5
Installing the CPU	6
Installing the Memory.....	7
Setting the Jumpers.....	8
Connectors on MI956.....	12
BIOS Setup	21
Drivers Installation	49
Intel Chipset Software Installation Utility.....	50
VGA Drivers Installation.....	53
Realtek HD Audio Driver Installation	56
LAN Drivers Installation	58
Intel® Management Engine Interface	62
ASMedia USB 3.0 Drivers	65
Appendix	67
A. I/O Port Address Map.....	67
B. Interrupt Request Lines (IRQ).....	68
C. Watchdog Timer Configuration	69

This page is intentionally left blank.

Introduction

Product Description

The MI956F Mini ITX motherboard is based on the latest Intel® QM67 chipset. The platform supports 2nd generation Intel® Core processor family with rPGA988B packing and features an integrated dual-channel DDR3 memory controller as well as a graphics core.

The latest Intel® processors provide advanced performance in both computing and graphics quality. This meets the requirement of customers in the gaming, POS, digital signage and server market segment.

The Intel® QM67 is made with 32 nanometer technology that supports Intel's first processor architecture to unite the CPU and the graphics core on the transistor level. The MI956F Mini ITX board utilizes the dramatic increase in performance provided by this Intel's latest cutting-edge technology. Measuring 170mm x 170mm, MI956F offers fast 6Gbps SATA support (2 ports), USB3.0 (2 ports) and interfaces for DVI-D, DVI-I, LVDS and HDMI displays. MI956AF features Intel Active Management Technology 7.0.

MI956F FEATURES:

- Supports Intel® 2nd Generation Core i7/i5/i3 QC/DC mobile processors
- Two DDR3 SoDIMM, 1066/1333MHz, Max. 8GB memory
- Dual Intel® PCI-Express Gigabit LAN
- Integrated Graphics for DVI-I, DVI-D/HDMI/LVDS displays
- 4x SATA 2.0, 2x SATA 3.0, 8x USB 2.0, USB 3.0 (2 ports), 4x COM, Watchdog timer
- 1x PCI-E (x16), 1x Mini PCI-E
- Optional AMT (MI956AF only)

Checklist


Your MI956 package should include the items listed below.

- The MI956 Mini-ITX motherboard
- This User's Manual
- 1 CD containing chipset drivers and flash memory utility
- Serial ATA cable

MI956 Specifications

Product Name	MI956AF/MI956F
Form Factor	Mini-ITX
CPU Type	- Intel® 2 nd generation Core™ i7/i5/i3 QC/DC mobile processor - rPGA package, 37.5 x 37.5 mm - TDP: QC = 45W~ 55W/ DC = 35W **Sandy Bridge CPU is <u>NOT</u> socket compatible with Arrandale
CPU Speed	Up to 2.7GHz
Cache	Up to 8MB
CPU Socket	rPGA 988B
Chipset	Intel® QM67 PCH; 25 x 27 mm package size
BIOS	AMI BIOS, support ACPI Function
Memory	Intel® 2 nd generation Core™ i7/i5/i3 QC/DC mobile processor integrated memory controller DDRIII 1067/1333 MHz - SO-DIMM x 2 (w/o ECC), Max. 8GB
VGA	- Intel® 2 nd generation Core™ i7/i5/i3 mobile processor integrated Gfx • DVI-I X 1 (thru Level shifter ASM1442) • DVI-D X 1 (thru Level shifter ASM1442) • HDMI X 1 (thru Level shifter ASM1442) • LVDS : DF13 x 2 for supporting dual channel 24-bit
LAN	1. Intel® Lewisville 82579LM GbE PHY [MI956AF only] or 82579V GbE PHY [MI956F only] 2. Intel® 82583V as 2 nd GbE
USB	USB <u>2.0</u> host controller, supports 8 ports w/ two EHCI, 7 UHCI controllers Integrated USB 2.0 Rate Matching Hub. - 4 ports in the rear panel - Others reserved for onboard pin header (4 ports, 2.54mm pitch) USB 3.0 host controller [ASMedia # ASM1042], support 2 ports - 2 ports in the rear panel
Serial ATA	Intel® QM67 PCH built-in SATA controller, supports total 6 ports 2 x SATA (3.0) 6Gbps+ 4 x SATA (2.0) 3Gbps ports (2 FIS based Port Multiplier)
Audio	Intel® QM67 PCH built-in High Definition Audio controller+ ALC892 w/ 7.1 CH
LPC I/O	Fintek F81865-1 (Ver. C) COM1 (RS232/422/485), COM2/COM3/COM4 (RS232), Hardware Monitor (2 thermal inputs, 4 voltage monitor inputs & 2 fan headers) [CPU FAN controllabl, but not the system fan] COM1/2 with pin-9 with power for 2 ports (500 mA for each port)
Digital IO	4 in & 4 out
IAMT(7.0)	Intel® QM67 PCH built-in (MI956AF only) - Intel® Active Management Technology ver. 7.0
Expansion Slots	- PCI-Express (16x) *1 [PEG] - Mini PCI-Express (1x) *1 @ Solder side [Reserved mounting holes for Half-sized also]
Edge Connector:	DVI-D + DVI-I stack connector; Dual DB9 stack connector for COM #1, #2 Dual USB(3.0) dual stack connector; HDMI stack connector Gbit LAN RJ-45 + dual USB(2.0) stack connector x2 RCA Jack 3x1 for HD Audio
Onboard Header/ Connector	2 ports x SATA III [Blue color]; 4 ports x SATA II 2x5 pin-header x2 for 4 ports USB; 2x5 pin-header for front panel audio 2x10 pin-header for COM3 (RS232) & COM4 (RS232) 2x5 pin-header for Digital IO; 4-pin box header for LCD backlight control
Watchdog Timer	Yes (256 segments, 0, 1, 2...255 sec/min)
System Voltage	ATX
Others	LAN Wakeup, EuP/ErP feature (Fintek F75160), UL 60950-1 2 nd Edition compatible
Board Size	170mm x 170mm

Board Dimensions



Installations


This section provides information on how to use the jumpers and connectors on the MI956 in order to set up a workable system. The topics covered are:

Installing the CPU.....	6
Installing the Memory	7
Setting the Jumpers.....	8
Connectors on MI956	12

Installing the CPU

The MI956 board supports rPGA988B socket for Intel® Sandy Bridge Dual Core mobile processors.

The processor socket comes with a screw to secure the processor. As shown in the left picture below, loosen the screw first before inserting the processor. Place the processor into the socket by making sure the notch on the corner of the CPU corresponds with the notch on the inside of the socket. Once the processor has slide into the socket, fasten the screw. Refer to the figures below.



NOTE: Ensure that the CPU heat sink and the CPU top surface are in total contact to avoid CPU overheating problem that would cause your system to hang or be unstable.


Installing the Memory

The MI956 board supports two DDR3 memory socket for a maximum total memory of 8GB in DDR3 SO-DIMM memory type.

Installing and Removing Memory Modules

To install the DDR3 modules, locate the memory slot on the board and perform the following steps:

1. Hold the DDR3 module so that the key of the DDR3 module aligned with that on the memory slot.
2. Gently push the DDR3 module in an upright position until the clips of the slot close to hold the DDR3 module in place when the DDR3 module touches the bottom of the slot.
3. To remove the DDR3 module, press the clips with both hands.




Setting the Jumpers

Jumpers are used on MI956 to select various settings and features according to your needs and applications. Contact your supplier if you have doubts about the best configuration for your needs. The following lists the connectors on MI956 and their respective functions.

Jumper Locations on MI956	9
JP2, JP3, JP4: RS232/RS422/RS485 (COM1) Selection	10
JP5: COM1 RS232 RI/+5V/+12V Power Setting.....	10
JP6: COM2 RS232 RI/+5V/+12V Power Setting.....	10
J10: LCD Panel Power Selection	11
J14: Flash Descriptor Security Override (Factory use only)	11
J22: Clear ME Contents.....	11
J23: Clear CMOS Contents.....	11


Jumper Locations on MI956



Jumpers on MI956.....	Page
JP2, JP3, JP4: RS232/RS422/RS485 (COM1) Selection	10
JP5: COM1 RS232 RI/+5V/+12V Power Setting.....	10
JP6: COM2 RS232 RI/+5V/+12V Power Setting.....	10
J10: LCD Panel Power Selection.....	11
J14: Flash Descriptor Security Override (Factory use only).....	11
J22: Clear ME Contents.....	11
J23: Clear CMOS Contents.....	11

INSTALLATIONS

JP2, JP3, JP4: RS232/RS422/RS485 (COM1) Selection



COM1 Function	RS-232	RS-422	RS-485
Jumper Setting (pin closed)	JP2: 3-5&4-6	JP2: 1-3&2-4	JP2: 1-3&2-4
	JP3: 1-2	JP3: 3-4	JP3: 5-6
	JP4: 3-5 & 4-6	JP4: 1-3 & 2-4	JP4: 1-3 & 2-4



JP5: COM1 RS232 RI/+5V/+12V Power Setting

JP5	Setting	Function
	Pin 1-2 Short/Closed	+12V
	Pin 3-4 Short/Closed	RI
	Pin 5-6 Short/Closed	+5V

JP6: COM2 RS232 RI/+5V/+12V Power Setting

JP6	Setting	Function
	Pin 1-2 Short/Closed	+12V
	Pin 3-4 Short/Closed	RI
	Pin 5-6 Short/Closed	+5V



J10: LCD Panel Power Selection

J10	LCD Panel Power
	3.3V
	5V



J14: Flash Descriptor Security Override (Factory use only)

J14	Flash Descriptor Security Override
Open	Disabled (Default)
Close	Enabled

J22: Clear ME Contents

J22	Setting	Function
	Pin 1-2 Short/Closed	Normal
	Pin 2-3 Short/Closed	Clear ME


J23: Clear CMOS Contents

J23	Setting	Function
	Pin 1-2 Short/Closed	Normal
	Pin 2-3 Short/Closed	Clear CMOS


Connectors on MI956

Connector Locations on MI956	13
CN1: COM1 and COM2 Serial Ports	14
CN2: DVI-D and DVI-I Connector	14
CN3: USB3.0 Connector	15
CN4: HDMI Connector	15
CN5: Gigabit LAN (Intel 82579LM) + USB 2/3	15
CN8: Gigabit LAN (Intel 82583V) + USB 0/1	15
CN11: HD Audio Connector	15
J1: Digital I/O.....	16
J3: ATX Power Supply Connector.....	16
J2, J4: COM3, COM4 RS232 Serial Ports	16
J6: ATX 12V Power Connector.....	16
JP8, JP7: LVDS Connectors (1st channel, 2nd channel)	17
JP9: LCD Backlight Connector.....	17
JP10, JP11: USB Connectors.....	17
JP13: SPDIF I/O.....	17
J24: Audio Pin Header for Chassis Front Panel	18
J26: Front Panel Connector.....	18
CN6, CN7, CN9, CN10, CN12, CN13: SATA Connectors	18
CPU_FAN1: CPU Fan Power Connector.....	18
SYS_FAN1: System Fan1 Power Connector.....	18
JP1: LPC Debug Connector (Factory use only)	19
J11: Mini-PCIE Connector	19
JP12: SPI Flash Connector (Factory use only).....	19


Connector Locations on MI956



INSTALLATIONS




CN1: COM1 and COM2 Serial Ports





Pin #	Signal Name		
	RS-232	R2-422	RS-485
1	DCD	TX-	DATA-
2	RX	TX+	DATA+
3	TX	RX+	NC
4	DTR	RX-	NC
5	Ground	Ground	Ground
6	DSR	NC	NC
7	RTS	NC	NC
8	CTS	NC	NC
9	RI	NC	NC
10	NC	NC	NC

CN2: DVI-D and DVI-I Connector



Signal Name	Pin #	Pin #	Signal Name
DATA 2-	1	16	HOT POWER
DATA 2+	2	17	DATA 0-
Shield 2/4	3	18	DATA 0+
DATA 4-	4	19	SHIELD 0/5
DATA 4+	5	20	DATA 5-
DDC CLOCK	6	21	DATA 5+
DDC DATA	7	22	SHIELD CLK
N.C	8	23	CLOCK -
DATA 1-	9	24	CLOCK +
DATA 1+	10	C1	N.C
SHIELD 1/3	11	C2	N.C
DATA 3-	12	C3	N.C
DATA 3+	13	C4	N.C
DDC POWER	14	C5	A GROUND2
A GROUND 1	15	C6	A GROUND3



Signal Name	Pin #	Pin #	Signal Name
DATA 2-	1	16	HOT POWER
DATA 2+	2	17	DATA 0-
Shield 2/4	3	18	DATA 0+
DATA 4-	4	19	SHIELD 0/5
DATA 4+	5	20	DATA 5-
DDC CLOCK	6	21	DATA 5+
DDC DATA	7	22	SHIELD CLK
N.C.	8	23	CLOCK -
DATA 1-	9	24	CLOCK +
DATA 1+	10	C1	N.C.
SHIELD 1/3	11	C2	N.C.
DATA 3-	12	C3	N.C.
DATA 3+	13	C4	N.C.
DDC POWER	14	C5	N.C.
A GROUND 1	15	C6	N.C.

CN3: USB3.0 Connector

CN4: HDMI Connector


CN5: Gigabit LAN (Intel 82579LM) + USB 2/3

CN8: Gigabit LAN (Intel 82583V) + USB 0/1

CN11: HD Audio Connector


INSTALLATIONS

J1: Digital I/O



Signal Name	Pin #	Pin #	Signal Name
GND	1	2	VCC
OUT3	3	4	OUT1
OUT2	5	6	OUT0
IN3	7	8	IN1
IN2	9	10	IN0

J3: ATX Power Supply Connector




Signal Name	Pin #	Pin #	Signal Name
3.3V	11	1	3.3V
-12V	12	2	3.3V
Ground	13	3	Ground
PS-ON	14	4	+5V
Ground	15	5	Ground
Ground	16	6	+5V
Ground	17	7	Ground
-5V	18	8	Power good
+5V	19	9	5VSB
+5V	20	10	+12V

J2, J4: COM3, COM4 RS232 Serial Ports

Signal Name	Pin #	Pin #	Signal Name
DCD#	1	6	DSR#
SIN#	2	7	RTS#
SOUT	3	8	CTS#
DTR#	4	9	RI#
GND	5	X	KEY

J6: ATX 12V Power Connector


This connector supplies the CPU operating voltage.



Pin #	Signal Name
1	Ground
2	Ground
3	+12V
4	+12V

JP8, JP7: LVDS Connectors (1st channel, 2nd channel)

The LVDS connectors on board consist of the first channel (LVDS1) and second channel (LVDS2).



Signal Name	Pin #	Pin #	Signal Name
TX0-	2	1	TX0+
Ground	4	3	Ground
TX1-	6	5	TX1+
5V/3.3V	8	7	Ground
TX3-	10	9	TX3+
TX2-	12	11	TX2+
Ground	14	13	Ground
TXC-	16	15	TXC+
5V/3.3V	18	17	ENABKL
+12V	20	19	+12V

JP9: LCD Backlight Connector




Pin #	Signal Name
1	+12V
2	Backlight Enable
3	Brightness Control
4	Ground

JP10, JP11: USB Connectors

Signal Name	Pin #	Pin #	Signal Name
VCC	1	2	Vcc
D0-	3	4	D1-
D0+	5	6	D1+
GND	7	8	GND
KEY	9	10	NC


JP13: SPDIF I/O



Pin #	Signal Name
1	SPDIF IN
2	Ground
3	SPDIF OUT
4	Ground


INSTALLATIONS

J24: Audio Pin Header for Chassis Front Panel




Signal Name	Pin #	Pin #	Signal Name
MIC IN_L	1	2	Ground
MIC IN_R	3	4	DET
LINE_R	5	6	Ground
Sense	7	8	KEY
LINE_L	9	10	Ground

J26: Front Panel Connector




Signal Name	Pin #	Pin #	Signal Name
Power BTN	1	2	Power BTN
HDD LED+	3	4	HDD LED-
Reset BTN	5	6	Reset BTN
Power LED+	7	8	Power LED-

CN6, CN7, CN9, CN10, CN12, CN13: SATA Connectors




Pin #	Signal Name
1	Ground
2	TX+
3	TX-
4	Ground
5	RX-
6	RX+
7	Ground

CPU_FAN1: CPU Fan Power Connector



Pin #	Signal Name
1	Ground
2	+12V
3	Rotation detection
4	Control

SYS_FAN1: System Fan1 Power Connector



Pin #	Signal Name
1	Ground
2	+12V
3	NC

JP1: LPC Debug Connector (Factory use only)

J11: Mini-PCIE Connector

JP12: SPI Flash Connector (Factory use only)

This page is intentionally left blank.

BIOS Setup

This chapter describes the different settings available in the AMI BIOS that comes with the board. The topics covered in this chapter are as follows:

BIOS Introduction.....	22
BIOS Setup	22
Main BIOS Setup	23
Advanced Settings	24
Chipset Settings	37
Boot Settings.....	44
Security Settings.....	46
Save & Exit Settings.....	47

BIOS Introduction

The BIOS (Basic Input/Output System) installed in your computer system's ROM supports Intel processors. The BIOS provides critical low-level support for a standard device such as disk drives, serial ports and parallel ports. It also provides password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Pressing the key immediately allows you to enter the Setup utility. If you are a little bit late pressing the key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup. If you still wish to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again. The following message will appear on the screen:

```
Press <DEL> or <F2> to Enter Setup
```

In general, you press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help and <Esc> to quit.

When you enter the Setup utility, the Main Menu screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

Main BIOS Setup

This setup allows you to record some basic hardware configurations in your computer system and set the system clock.

Aptio Setup Utility – Copyright © 2010 American Megatrends, Inc.

Main	Advanced	Chipset	Boot	Security	Save & Exit
BIOS INFORMATION					
System Date			[Tue 01/06/2009]		→ ← Select Screen
System Time			[00:08:21]		↑ ↓ Select Item
Access Level			Administrator		Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save & Exit
					ESC: Exit

Note: *If the system cannot boot after making and saving system changes with Setup, the AMI BIOS supports an override to the CMOS settings that resets your system to its default.*

Warning: *It is strongly recommended that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both AMI and your system manufacturer to provide the absolute maximum performance and reliability. Changing the defaults could cause the system to become unstable and crash in some cases.*

System Date


Set the Date. Use Tab to switch between Data elements.

System Time

Set the Time. Use Tab to switch between Data elements.

Advanced Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.



REMARKS:

1.The Intel AMT Configuration is available only on MI956AF, not MI956F.

2.The EuP/ErP Power Saving Controller is available only on MI956F, not MI956AF.

PCI Subsystem Settings

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
	PCI Bus Driver Version		V 2.0502		
	PCI 64bit Resources Handing				→ ← Select Screen
	Above 4G Decoding		Disabled		↑ ↓ Select Item
	PCI Common Settings				Enter: Select
	PCI Latency Timer		32 PCI Bus Clocks		+ - Change Field
	VGA Palette Snoop		Disabled		F1: General Help
	PERR# Generation		Disabled		F2: Previous Values
	SERR# Generation		Disabled		F3: Optimized Default
	▶ PCI Express Settings				F4: Save ESC: Exit

Above 4G Decoding

Enables or Disables 64bit capable devices to be decoded in above 4G address space (only if system supports 64 bit PCI decoding).

PCI Latency Timer

Value to be programmed into PCI Latency Timer Register.

VGA Palette Snoop

Enables or disables VGA Palette Registers Snooping.

PERR# Generation

Enables or disables PCI device to generate PERR#.

SERR# Generation

Enables or disables PCI device to generate SERR#.

PCI Express Settings

Change PCI Express devices settings.

PCI Express Settings

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit	
PCI Express Device Register Settings						
Relaxed Ordering			Disabled		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit	
Extended Tag			Disabled			
No Snoop			Enabled			
Maximum Payload			Auto			
Maximum Read Request			Auto			
PCI Express Link Register Settings						
ASPM Support			Disabled			
WARNING: Enabling ASPM may cause some PCI-E devices to fail			Disabled			
Extended Synch			Disabled			
Link Training Retry			5			
Link Training Timeout (uS)			100			
Unpopulated Links			Keep Link ON			

Relaxed Ordering

Enables or disables PCI Express Device Relaxed Ordering.

Extended Tag

If ENABLED allows device to use 8-bit Tag field as a requester.

No Snoop

Enables or disables PCI Express Device No Snoop option.

Maximum Payload

Set Maximum Payload of PCI Express Device or allow System BIOS to select the value.

Maximum Read Request

Set Maximum Read Request Size of PCI Express Device or allow System BIOS to select the value.

ASPM Support

Set the ASPM Level: Force L0s – Force all links to L0s State:
 AUTO – BIOS auto configure : DISABLE – Disables ASPM.

Extended Synch

If ENABLED allows generation of Extended Synchronization patterns.

Link Training Retry

Defines number of Retry Attempts software will take to retrain the link if previous training attempt was unsuccessful.

Link Training Timeout (uS)

Defines number of Microseconds software will wait before polling 'Link Training' bit in Link Status register. Value range from 10 to 1000 uS.

Unpopulated Links

In order to save power, software will disable unpopulated PCI Express links, if this option set to 'Disable Link'.

ACPI Settings

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
ACPI Settings					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit
Enable Hibernation		Enabled			
ACPI Sleep State		S1 (Suspend to R...)			
Lock Legacy Resources		Disabled			
S3 Video Repost		Disabled			

Enable Hibernation

Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.

ACPI Sleep State

Select ACPI sleep state the system will enter, when the SUSPEND button is pressed.

Lock Legacy Resources

Enabled or Disabled Lock of Legacy Resources.

S3 Video Repost

Enable or disable S3 Video Repost.

Wake up event settings

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
	Wake system with Fixed Time		Disabled		
	Wake up hour		0		
	Wake up minute		0		
	Wake up second		0		
	Wake on Ring		Disabled		→ ← Select Screen
	Wake on PCIE Wake Event		Disabled		↑ ↓ Select Item
					Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

Wake system with Fixed Time

Enables or Disables System wake on alarm event. When enabled, System will wake on the hr::min:: sec specified.

Wake on PCIE PME Wake Event

The options are Disabled and Enabled.

CPU Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
CPU Configuration					
Intel® CPU @ 2.20GHz					
Processor Stepping			206a5		
Microcode Revision			Not Loaded		
Max CPU Speed			2200 MHz		
Min CPU Speed			800 MHz		
CPU Speed			2200 MHz		
Processor Cores			4		
Intel HT Technology			Supported		
Intel VT-x Technology			Supported		
Intel SMX Technology			Supported		
64-bit			Supported		
Hyper-threading			Enabled		→ ← Select Screen
Active Processor Cores			All		↑ ↓ Select Item
Limit CPUID Maximum			Disabled		Enter: Select
Execute Disable Bit			Enabled		+ - Change Field
Intel Virtualization Technology			Disabled		F1: General Help
Hardware Prefetcher			Disabled		F2: Previous Values
Adjacent Cache Line Prefetch			Enabled		F3: Optimized Default
					F4: Save ESC: Exit

Hyper-threading

Enabled for Windows XP and Linux (OS optimized for Hyper-Threading Technology) and Disabled for other OS (OS not optimized for Hyper-Threading Technology). When Disabled, only one thread per enabled core is enabled.

Active Processor Cores

Number of cores to enable in each processor package.

Limit CPUID Maximum

Disabled for Windows XP.

Execute Disable Bit

XD can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS (Windows Server 2003 SP1, Windows XP SP2, SuSE Linux 9.2, Re33dHat Enterprise 3 Update 3.)

Intel Virtualization Technology

When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

Hardware Prefetcher

To turn on/off the Mid level Cache (L2) streamer Prefetcher.

Adjacent Cache Line Prefetch

To turn on/off prefetching of adjacent cache lines.

SATA Configuration

SATA Devices Configuration.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
SATA Controller(s)		Enabled			
SATA Mode Selection		IDE			
SATA Port0		Empty		→ ← Select Screen	
Software Preserve		Unknown		↑ ↓ Select Item	
SATA Port1		Empty		Enter: Select	
Software Preserve		Unknown		+- Change Field	
SATA Port2		Empty		F1: General Help	
Software Preserve		Unknown		F2: Previous Values	
SATA Port3		Empty		F3: Optimized Default	
Software Preserve		Unknown		F4: Save ESC: Exit	
SATA Port4		Empty			
Software Preserve		Unknown			
SATA Port5		Empty			
Software Preserve		Unknown			

SATA Controller(s)

Enable / Disable Serial ATA Controller.

SATA Mode Selection

- (1) IDE Mode.
- (2) AHCI Mode.
- (3) RAID Mode.

Shutdown Temperature Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
ACPI Shutdown Temperature			Disabled		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

ACPI Shutdown Temperature

The default setting is Disabled.

EuP/ErP Power Saving Controller

Saving the power consumption on power off.

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Standby Power on S5			All Enable		[Enable] Provide the Standby Power for devices. [Disable] Shutdown the standby power.

AMT Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Intel AMT			Enabled		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit
BIOS Hotkey Pressed			Disabled		
MEBx Selection Screen			Disabled		
Hide Un-Configure ME Confirmation			Disabled		
Un-Configure ME			Disabled		
Amt Wait Timer			0		
Activate Remote Assistance Process			Disabled		
USB Configure			Enabled		
PET Progress			Enabled		
AMT CIRA Timeout			0		
Watchdog			Disabled		
OS Timer			0		
BIOS Timer			0		

Intel AMT

This configuration is supported only with MI956AF (with iAMT function). Options are Enabled and Disabled.

Note: iAMT H/W is always enabled. This option just controls the BIOS extension execution. If enabled, this requires additional firmware in the SPI device.

Unconfigure ME

This configuration is supported only with MI956AF (with iAMT function). Perform AMT/ME unconfigure without password operation.

Amt Wait Timer

Set timer to wait before sending ASF_GET_BOOT_OPTIONS.

Activate Remote Assistance Process

Trigger CIRA boot.

PET Progress

User can Enable/Disable PET Events progress to receive PET events or not.

Watchdog Timer

This configuration is supported only with MI956AF (with iAMT function). Enable/Disable Watchdog Timer.

DPTF Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
	DPTF Configuration				
	DPTF		Disabled		Enable/Disable intel Dynamic Platform Thermal Framework.

Acoustic Management Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Acoustic Management Configuration				Disabled	
Acoustic Management					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

USB Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
USB Configuration					
USB Devices: 2 Hubs					
Legacy USB Support			Enabled		
USB3.0 Support			Enabled		
XHCI Hand-off			Enabled		
EHCI Hand-off			Enabled		
USB hardware delays and time-outs:					
USB Transfer time-out			20 sec		
Device reset time-out			20 sec		
Device power-up delay			Auto		
					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

Legacy USB Support

Enables Legacy USB support.

AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.

USB3.0 Support

Enable/Disable USB3.0 (XHCI) Controller support.

XHCI Hand-off

This is a workaround for Oses without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

EHCI Hand-off

Enabled/Disabled. This is a workaround for OSES without EHCI hand-off support. The EHCI ownership change should be claimed by EHCI driver.

USB Transfer time-out

The time-out value for Control, Bulk, and Interrupt transfers.

Device reset time-out

USB mass Storage device start Unit command time-out.

Device power-up delay

Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100ms, for a Hub port the delay is taken from Hub descriptor.

F81865 Super IO Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Super IO Configuration					
F81865 Super IO Chip		F81865		→ ← Select Screen	
▶ Serial Port 0 Configuration				↑ ↓ Select Item	
▶ Serial Port 1 Configuration				Enter: Select	
▶ Serial Port 2 Configuration				+- Change Field	
▶ Serial Port 3 Configuration				F1: General Help	
Power Failure		Always off		F2: Previous Values	
				F3: Optimized Default	
				F4: Save ESC: Exit	

Serial Port Configuration

Set Parameters of Serial Ports. User can Enable/Disable the serial port and Select an optimal settings for the Super IO Device.

F81865 H/W Monitor

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
PC Health Status					
CPU_Fan smart fan control			Disabled		
CPU temperature			+35 C		
SYS temperature			+39 C		
CPU_FAN Speed			7045 RPM		
Vcore			+0.960 V		
+5V			+5.003 V		
+12V			+12.058 V		
					→ ← Select Screen
					↑ ↓ Select Item
					Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

Temperatures/Voltages

These fields are the parameters of the hardware monitoring function feature of the motherboard. The values are read-only values as monitored by the system and show the PC health status.

CPU Fan Smart Fan Control

This field enables or disables the smart fan feature. At a certain temperature, the fan starts turning. Once the temperature drops to a certain level, it stops turning again.

CPU PPM Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
CPU PPM Configuration					
EIST					Enabled
Turbo Mode					Enabled
					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

EIST

Enable/Disable Intel SpeedStep.

Sandybridge DTS Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Sadybridge DTS Configuration					
CPU DTS					Disable
					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save & Exit ESC: Exit

CPU DTS

Disabled: ACPI thermal management uses EC reported temperature values.

Enabled: ACPI thermal management uses DTS SMM mechanism to obtain CPU temperature values.

Out of Spec: ACPI Thermal Management uses EC reported temperature values and TS SMM is used to handle Out of Spec.

Chipset Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility	
Main	Advanced
<ul style="list-style-type: none"> ▶ PCH-IO Configuration ▶ System Agent (SA) Configuration 	<p>→ ← Select Screen</p> <p>↑ ↓ Select Item</p> <p>Enter: Select</p> <p>+ - Change Field</p> <p>F1: General Help</p> <p>F2: Previous Values</p> <p>F3: Optimized Default</p> <p>F4: Save ESC: Exit</p>

PCH-IO Configuration

This section allows you to configure the North Bridge Chipset.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
		Intel PCH RC Version	1.1.0.0		
		Intel PCH SKU Name	QM67		
		Intel PCH Rev ID	O5/B3		
		<ul style="list-style-type: none"> ▶ PCI Express Configuration ▶ USB Configuration ▶ PCH Azalia Configuration 			
		PCH LAN Controller	Enabled		
		Wake on LAN	Disabled		
		Board Capability	SUS_PWR_ON_ACK		→ ← Select Screen
		High Precision Event Timer Configuration			↑ ↓ Select Item
		High Precision Timer	Enabled		Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit
		SLP_S4 Assertion Width	1-2 Seconds		

PCH LAN Controller

Enable or disable onboard NIC.

Wake on LAN

Enable or disable integrated LAN to wake the system. (The Wake On LAN cannot be disabled if ME is on at Sx state.)

SLP_S4 Assertion Width

Select a minimum assertion width of the SLP_S4# signal.

PCI Express Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
PCI Express Configuration					
PCI Express Clock Gating			Enabled		
DMI Link ASPM Control			Enabled		
DMI Link Extended Synch Control			Disabled		
PCIe-USB Glitch W/A			Disabled		
Subtractive Decode			Disabled		
▶ PCI Express Root Port 1					
▶ PCI Express Root Port 2					
▶ PCI Express Root Port 3					
▶ PCI Express Root Port 4					
▶ PCI Express Root Port 5					
PCI-E Port 6 is assigned to LAN					
▶ PCI Express Root Port 7					
▶ PCI Express Root Port 8					
					→ ← Select Screen
					↑ ↓ Select Item
					Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

PCI Express Clock Gating

Enable or disable PCI Express Clock Gating for each root port.

DMI Link ASPM Control

The control of Active State Power Management on both NB side and SB side of the DMI link.

PCIe-USB Glitch W/A

PCIe-USB Glitch W/A for bad USB device(s) connected behind PCIe/PEG port.

USB Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
USB Configuration					
EHCI1			Enabled		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit
EHCI2			Enabled		
USB Ports Per-Port Disable Control			Disabled		

EHCI1/2

Control the USAB EHCI (USB 2.0) functions. One EHCI controller must always be enabled.

USB Ports Per-Port Disable Control

Control each of the USB ports (0~13) disabling.

PCH Azalia Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
PCH Azalia Configuration					
Azalia			Auto		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

Azalia

Control Detection of the Azalia device.

Disabled = Azalia will unconditionally disabled.

Enabled Azalia will be unconditionally enabled.

Auto = Azalia will enabled if present, disabled otherwise.

System Agent (SA) Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
		System Agent Bridge Name	SandyBridge		
		System Agent RC Version	1.1.0.0		
		VT-d Capability	Supported		
		VT-d	Enabled		
		CHAP Device (B0:D7:F0)	Disabled		→ ← Select Screen
		Thermal Device (B0:D4:F0)	Disabled		↑ ↓ Select Item
		Enable NB CRID	Disabled		Enter: Select
		BDAT ACPI Table Support	Disabled		+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit
		▶ Graphics Configuration			
		▶ Memory Configuration			

VT-d

Check to enable VT-d function on MCH.

Enable NB CRID

Enable or disable NB CRID WorkAround.

Graphics Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Graphics Configuration					
		IGFX VBIOS Version	2132		
		IGfx Frequency	650 MHz		
		Primary Display	Auto		
		Internal Graphics	Auto		→ ← Select Screen
		GTT Size	2MB		↑ ↓ Select Item
		Aperture Size	256MB		Enter: Select
		DVMT Pre-Allocated	64M		+ - Change Field
		DVMT Total Gfx Mode	Disabled		F1: General Help
		▶ LCD Control			F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

Primary Display

Select which of IGFX/PEG/PCI graphics device should be primary display or select SG for switchable Gfx.

Internal Graphics

Keep IGD enabled based on the setup options.

DVMT Pre-Allocated

Select DVMT 5.0 Pre-Allocated (Fixed) graphics memory size used by the internal graphics device.

DVMT Total Gfx Mem

Select DVMT 5.0 total graphics memory size used by the internal graphics device.

Gfx Low Power Mode

This option is applicable for SFF only.

LCD Control

Select the Video Device that will be activated during POST. This has no effect if external graphics present. Secondary boot display selection will appear based on your selection. VGA modes will be supported only on primary display.

LCD Control

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
LCD Control					→ ← Select Screen
Primary IGFX Boot Display			VBIOS Default		↑ ↓ Select Item
LCD Panel Type			1024x768 LVDS		Enter: Select
Active LFP			No LVDS		+ - Change Field
Panel Color Depth			18 Bit		F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save & Exit
					ESC: Exit

Primary IGFX Boot Display

Select the Video Device, which will be activated during POST. This has no effect if external graphics present.

Secondary boot display selection will appear based on your selection. VGA modes will be supported only on primary display.

LCD Panel Type

Select LCD panel used by Internal Graphics Device by selecting the appropriate setup item: 640x480 LVDS ~ 2048x1536 LVDS.

Active LFP

Select the Active LFP Configuration.

No LVDS: VBIOS does not enable LVDS.

Int-LVDS: VBIOS enables LVDS driver by Integrated encoder.

SDVO LVDS: VBIOS enables LVDS driver by SDVO encoder.

eDP Port-A: LFP Driven by Int-DisplayPort encoder from Port-A.

Panel Color Depth

Select the LFP Panel Color Depth: 18 Bit, 24 Bit.

Memory Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Memory Information					
		Memory RC Version	1.2.2.0		
		Memory Frequency	1333 MHz		
		Total Memory	2048 MB (DDR3)		
		DIMM#0	2048 MB (DDR3)		
		DIMM#1	Not Present		
		CAS Latency (tCL)	9		
		Minimum delay time			
		CAS to RAS (tRCDmin)	9		
		Row Precharge (tRPmin)	9		
		Active to Precharge (tRASmin)	24		
					→ ← Select Screen
					↑ ↓ Select Item
					Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

Boot Settings

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Boot Configuration					
Setup Prompt Timeout			1		
Bootup NumLock State			On		
Quiet Boot			Disabled		
Fast Boot			Disabled		
CSM16 Module Version			07.69		→ ← Select Screen
GateA20 Active			Upon Request		↑ ↓ Select Item
Option ROM Messages			Force BIOS		Enter: Select
INT19 Trap Response			Immediate		+ - Change Field
Boot Option Priorities					F1: General Help
▶ CSM parameters					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

Setup Prompt Timeout

Number of seconds to wait for setup activation key.

65535(0xFFFF) means indefinite waiting.

Bootup NumLock State

Select the keyboard NumLock state.

Quiet Boot

Enables/Disables Quiet Boot option.

Fast Boot

Enables/Disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

GateA20 Active

UPON REQUEST – GA20 can be disabled using BIOS services.

ALWAYS – do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.

Option ROM Messages

Set display mode for Option ROM. Options: Force BIOS and Keep Current.

INT19 Trap Response

Enable: Allows Option ROMs to trap Int 19.

Boot Option Priorities

Sets the system boot order.

CSM parameters

This section allows you to configure the boot settings.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
			Launch CSM	Always	
			Boot option filter	UEFI and Legacy	
			Launch PXE OpROM policy	Do not launch	
			Launch Storage OpROM policy	Legacy only	
			Launch Video OpROM policy	Legacy only	
			Other PCI device ROM priority	Legacy OpROM	
					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

Boot option filter

This option controls what devices system can boot to.

Launch PXE OpROM policy

Controls the execution of UEFI and Legacy PXE OpROM.

Launch Storage OpROM policy

Controls the execution of UEFI and Legacy Storage OpROM.

Launch Video OpROM policy

Controls the execution of UEFI and Legacy Video OpROM.

Other PCI device ROM priority

For PCI devices other than Network, Mass storage or Video defines which OpROM to launch.

Security Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
Password Description					
If ONLY the Administrator's password is set, then this only limit access to Setup and is only asked for when entering Setup.					
If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights					
The password length must be in the following range:					
Minimum length			3		
Maximum length			20		
Administrator Password					
User Password					
					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

Administrator Password

Set Setup Administrator Password.

User Password

Set User Password.

Save & Exit Settings

Aptio Setup Utility	
Main	Advanced
Save Changes and Exit	
Discard Changes and Exit	
Save Changes and Reset	
Discard Changes and Reset	
Save Options	
Save Changes	
Discard Changes	
Restore Defaults	
Save as User Defaults	
Restore User Defaults	
	→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

Save Changes and Exit

Exit system setup after saving the changes.

Discard Changes and Exit

Exit system setup without saving any changes.

Save Changes and Reset

Reset the system after saving the changes.

Discard Changes and Reset

Reset system setup without saving any changes.

Save Changes

Save Changes done so far to any of the setup options.

Discard Changes

Discard Changes done so far to any of the setup options.

Restore Defaults

Restore/Load Defaults values for all the setup options.

Save as User Defaults

Save the changes done so far as User Defaults.

Restore User Defaults

Restore the User Defaults to all the setup options.

This page is intentionally left blank.

Drivers Installation

This section describes the installation procedures for software and drivers. The software and drivers are included with the motherboard. If you find the items missing, please contact the vendor where you made the purchase. The contents of this section include the following:

Intel Chipset Software Installation Utility	50
VGA Drivers Installation	53
Realtek HD Audio Driver Installation	56
LAN Drivers Installation.....	58
Intel® Management Engine Interface	62
ASMedia USB 3.0 Drivers.....	65


IMPORTANT NOTE:

After installing your Windows operating system, you must install first the Intel Chipset Software Installation Utility before proceeding with the drivers installation.

Intel Chipset Software Installation Utility

The Intel Chipset Drivers should be installed first before the software drivers to enable Plug & Play INF support for Intel chipset components. Follow the instructions below to complete the installation.

1. Insert the CD that comes with the board. Click **Intel** and then **Intel(R) 7 Series Chipset Drivers**.



2. Click **Intel(R) Chipset Software Installation Utility**.




3. When the Welcome screen to the Intel® Chipset Device Software appears, click *Next* to continue.



4. Click *Yes* to accept the software license agreement and proceed with the installation process.



5. On the Readme File Information screen, click *Next* to continue the installation.



6. The Setup process is now complete. Click *Finish* to restart the computer and for changes to take effect.



VGA Drivers Installation

NOTE: Before installing the *Intel(R) Q77 Chipset Family Graphics Driver*, the Microsoft .NET Framework 3.5 SPI should be first installed.

To install the VGA drivers, follow the steps below.


1. Insert the CD that comes with the board. Click *Intel* and then *Intel(R) Q7 Series Chipset Drivers*.




2. Click *Intel(R) Q77 Chipset Family Graphics Driver*.




3. When the Welcome screen appears, click *Next* to continue.




4. Click *Yes* to agree with the license agreement and continue the installation.



5. On the Readme File Information screen, click *Next* to continue the installation of the Intel® Graphics Media Accelerator Driver.



6. On Setup Progress screen, click *Next* to continue.



7. Setup complete. Click *Finish* to restart the computer and for changes to take effect.

Realtek HD Audio Driver Installation

Follow the steps below to install the Realtek HD Audio Drivers.


1. Insert the CD that comes with the board. Click *Intel* and then *Intel(R) O7 Series Chipset Drivers*.




2. Click *Realtek High Definition Audio Driver*.



3. On the Welcome to the InstallShield Wizard screen, click *Next* to proceed with and complete the installation process.



4. The InstallShield Wizard Complete. Click *Finish* to restart the computer and for changes to take effect.



LAN Drivers Installation


1. Insert the CD that comes with the board. Click *Intel* and then *Intel(R) 7 Series Chipset Drivers*.




2. Click *Intel(R) PRO LAN Network Driver*.




3. Click **Install Drivers and Software**.




4. When the Welcome screen appears, click **Next**.




5. Click *Next* to to agree with the license agreement.




6. Click the checkbox for **Drivers** in the Setup Options screen to select it and click **Next** to continue.



7. The wizard is ready to begin installation. Click **Install** to begin the installation.



8. When InstallShield Wizard is complete, click **Finish**.



Intel® Management Engine Interface

REMARKS: The Intel iAMT 8.0 Drivers can be installed on MI956AF, not MI956F.




The following application requires Microsoft .NET Framework 3.5 or later: Intel® Management Engine Components. Please install the latest version of Microsoft .NET Framework from Microsoft Download Center to run this application correctly.

Follow the steps below to install the Intel Management Engine.


1. Insert the CD that comes with the board. Click **Intel** and then **Intel(R) AMT 8.0 Drivers**.





2. When the Welcome screen to the InstallShield Wizard for Intel® Management Engine Components, click the checkbox for **Install Intel® Control Center** & click **Next**.



3. Click **Yes** to to agree with the license agreement.



4. When the Setup Progress screen appears, click *Next*. Then, click *Finish* when the setup progress has been successfully installed.



ASMedia USB 3.0 Drivers

1. Insert the CD that comes with the board. Click *Intel* and then *Intel(R) 6 Series Chipset Drivers*.
2. Click *Intel(R) PRO LAN Network Driver*.



2. When the Welcome screen to the InstallShield Wizard for Intel® Management Engine Components, click *Next*.



3. When InstallShield Wizard is complete, click *Finish*.



This page is intentionally left blank.

Appendix

A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. The following table lists the I/O port addresses used.

Address	Device Description
000h - 01Fh	DMA Controller #1
020h - 03Fh	Interrupt Controller #1
040h - 05Fh	Timer
060h - 06Fh	Keyboard Controller
070h - 07Fh	Real Time Clock, NMI
080h - 09Fh	DMA Page Register
0A0h - 0BFh	Interrupt Controller #2
0C0h - 0DFh	DMA Controller #2
0F0h	Clear Math Coprocessor Busy Signal
0F1h	Reset Math Coprocessor
1F0h - 1F7h	IDE Interface
278h - 27Fh	Parallel Port #2(LPT2)
2E8h - 2EFh	Serial Port #4(COM4)
2F8h - 2FFh	Serial Port #2(COM2)
2B0h- 2DFh	Graphics adapter Controller
360h - 36Fh	Network Ports
3B0h - 3BFh	Monochrome & Printer adapter
3C0h - 3CFh	EGA adapter
3D0h - 3DFh	CGA adapter
3E8h - 3EFh	Serial Port #3(COM3)
3F8h - 3FFh	Serial Port #1(COM1)

B. Interrupt Request Lines (IRQ)

Peripheral devices use interrupt request lines to notify CPU for the service required. The following table shows the IRQ used by the devices on board.

Level	Function
IRQ0	System Timer Output
IRQ1	Keyboard
IRQ2	Interrupt Cascade
IRQ3	Serial Port #2
IRQ4	Serial Port #1
IRQ5	Reserved
IRQ6	Reserved
IRQ7	Reserved
IRQ8	Real Time Clock
IRQ9	Reserved
IRQ10	Serial Port #3
IRQ11	Serial Port #4
IRQ12	PS/2 Mouse
IRQ13	80287
IRQ14	Primary IDE
IRQ15	Secondary IDE

C. Watchdog Timer Configuration

The WDT is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven. Under normal circumstance, the user will restart the WDT at regular intervals before the timer counts to zero.

SAMPLE CODE:

```
//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include <dos.h>
#include <conio.h>
#include <stdio.h>
#include <stdlib.h>
#include "F81865.H"
//-----
int main (int argc, char *argv[]);
void EnableWDT(int);
void DisableWDT(void);
//-----
int main (int argc, char *argv[])
{
    unsigned char bBuf;
    unsigned char bTime;
    char **endptr;

    char SIO;

    printf("Fintek 81865 watch dog program\n");

    SIO = Init_F81865();
    if (SIO == 0)
    {
        printf("Can not detect Fintek 81865, program abort.\n");
        return(1);
    }/if (SIO == 0)

    if (argc != 2)
    {
        printf(" Parameter incorrect!!\n");
        return (1);
    }

    bTime = strtol (argv[1], endptr, 10);
    printf("System will reset after %d seconds\n", bTime);

    if (bTime)
    {
        EnableWDT(bTime); }
    else
    {
        DisableWDT(); }

    return 0;
}
```

```
}
//-----
void EnableWDT(int interval)
{
    unsigned char bBuf;

    bBuf = Get_F81865_Reg(0x2B);
    bBuf &= (~0x20);
    Set_F81865_Reg(0x2B, bBuf); //Enable WDTO

    Set_F81865_LD(0x07); //switch to logic device 7
    Set_F81865_Reg(0x30, 0x01); //enable timer

    bBuf = Get_F81865_Reg(0xF5);
    bBuf &= (~0x0F);
    bBuf |= 0x52;
    Set_F81865_Reg(0xF5, bBuf); //count mode is second

    Set_F81865_Reg(0xF6, interval); //set timer

    bBuf = Get_F81865_Reg(0xFA);
    bBuf |= 0x01;
    Set_F81865_Reg(0xFA, bBuf); //enable WDTO output

    bBuf = Get_F81865_Reg(0xF5);
    bBuf |= 0x20;
    Set_F81865_Reg(0xF5, bBuf); //start counting
}
//-----
void DisableWDT(void)
{
    unsigned char bBuf;

    Set_F81865_LD(0x07); //switch to logic device 7

    bBuf = Get_F81865_Reg(0xFA);
    bBuf &= ~0x01;
    Set_F81865_Reg(0xFA, bBuf); //disable WDTO output

    bBuf = Get_F81865_Reg(0xF5);
    bBuf &= ~0x20;
    bBuf |= 0x40;
    Set_F81865_Reg(0xF5, bBuf); //disable WDT
}
//-----
```

```

//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include "F81865.H"
#include <dos.h>
//-----
unsigned int F81865_BASE;
void Unlock_F81865 (void);
void Lock_F81865 (void);
//-----
unsigned int Init_F81865(void)
{
    unsigned int result;
    unsigned char ucDid;

    F81865_BASE = 0x4E;
    result = F81865_BASE;

    ucDid = Get_F81865_Reg(0x20);
    if (ucDid == 0x07) //Fintek 81865
    {
        goto Init_Finish;
    }

    F81865_BASE = 0x2E;
    result = F81865_BASE;

    ucDid = Get_F81865_Reg(0x20);
    if (ucDid == 0x07) //Fintek 81865
    {
        goto Init_Finish;
    }

    F81865_BASE = 0x00;
    result = F81865_BASE;
}

Init_Finish:
    return (result);
}
//-----
void Unlock_F81865 (void)
{
    outportb(F81865_INDEX_PORT, F81865_UNLOCK);
    outportb(F81865_INDEX_PORT, F81865_UNLOCK);
}
//-----
void Lock_F81865 (void)
{
    outportb(F81865_INDEX_PORT, F81865_LOCK);
}
//-----
void Set_F81865_LD( unsigned char LD)
{
    Unlock_F81865();
    outportb(F81865_INDEX_PORT, F81865_REG_LD);
    outportb(F81865_DATA_PORT, LD);
    Lock_F81865();
}
//-----
void Set_F81865_Reg( unsigned char REG, unsigned char DATA)
{
    Unlock_F81865();
    outportb(F81865_INDEX_PORT, REG);
    outportb(F81865_DATA_PORT, DATA);
    Lock_F81865();
}
//-----
unsigned char Get_F81865_Reg(unsigned char REG)

```

APPENDIX

```
{
    unsigned char Result;
    Unlock_F81865();
    outportb(F81865_INDEX_PORT, REG);
    Result = inportb(F81865_DATA_PORT);
    Lock_F81865();
    return Result;
}
//-----

//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#ifndef __F81865_H
#define __F81865_H                1
//-----
#define F81865_INDEX_PORT        (F81865_BASE)
#define F81865_DATA_PORT        (F81865_BASE+1)
//-----
#define F81865_REG_LD            0x07
//-----
#define F81865_UNLOCK            0x87
#define F81865_LOCK              0xAA
//-----
unsigned int Init_F81865(void);
void Set_F81865_LD(unsigned char);
void Set_F81865_Reg(unsigned char, unsigned char);
unsigned char Get_F81865_Reg(unsigned char);
//-----
#endif // __F81865_H
```