

# **ET976**

**AMD Ryzen™ (FP5)  
COM Express Type 6 Module**

## **User's Manual**

Version 1.1

## **Copyright**

© 2020 IBASE Technology, Inc. All rights reserved.

No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of IBASE Technology, Inc. (hereinafter referred to as “IBASE”).

## **Disclaimer**

IBASE reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, IBASE does not guarantee this document is error-free.

IBASE assumes no liability for incidental or consequential damages arising from misapplication or inability to use the product or the information contained herein, nor for any infringements of rights of third parties, which may result from its use.

## **Trademarks**

All the trademarks, registrations and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

## Compliance



This product has passed CE tests for environmental specifications and limits. This product is in accordance with the directives of the European Union (EU). In a domestic environment, this product may cause radio interference in which case users may be required to take adequate measures.



This product has been tested and found to comply with the limits for a Class B device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications.

### WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive of for waste electrical and electronic equipment (WEEE - 2012/19/EU). Instead, it should be disposed of by returning it to a municipal recycling collection point. Check local regulations for disposal of electronic products.

### Green IBASE



This product is compliant with the current RoHS restrictions and prohibits use of the following substances in concentrations exceeding 0.1% by weight (1000 ppm) except for cadmium, limited to 0.01% by weight (100 ppm).

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent chromium (Cr6+)
- Polybrominated biphenyls (PBB)
- Polybrominated diphenyl ether (PBDE)

## Important Safety Information

Carefully read the precautions before using the board.

### Environmental conditions:

- Use this product in environments with ambient temperatures between 0°C and 60°C.
- Do not leave this product in an environment where the storage temperature may be below -20° C or above 80° C.

### Care for your iBASE products:

- Before cleaning the PCB, unplug all cables and remove the battery.
- Clean the PCB with a circuit board cleaner or degreaser, or use cotton swabs and alcohol.



### WARNING

#### Attention during use:

- Do not use this product near water.
- Do not spill water or any other liquids on this product.
- Do not place heavy objects on the top of this product.

#### Anti-static precautions

- Wear an anti-static wrist strap to avoid electrostatic discharge.
- Place the PCB on an anti-static kit or mat.
- Ground yourself by touching a grounded conductor or a grounded bit of metal frequently to discharge any static.



### CAUTION

Danger of explosion if the internal lithium-ion battery is replaced by an incorrect type. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions or recycle them at a local recycling facility or battery collection point.

## Warranty Policy

- **IBASE standard products:**

24-month (2-year) warranty from the date of shipment. If the date of shipment cannot be ascertained, the product serial numbers can be used to determine the approximate shipping date.

- **3<sup>rd</sup>-party parts:**

12-month (1-year) warranty from delivery for the 3<sup>rd</sup>-party parts that are not manufactured by IBASE, such as CPU, CPU cooler, memory, storage devices, power adapter, panel and touchscreen.

- \* PRODUCTS, HOWEVER, THAT FAIL DUE TO MISUSE, ACCIDENT, IMPROPER INSTALLATION OR UNAUTHORIZED REPAIR SHALL BE TREATED AS OUT OF WARRANTY AND CUSTOMERS SHALL BE BILLED FOR REPAIR AND SHIPPING CHARGES.

## Technical Support & Services

1. Visit the IBASE website at [www.ibase.com.tw](http://www.ibase.com.tw) to find the latest information about the product.
2. If you need any further assistance from your distributor or sales representative, prepare the following information of your product and elaborate upon the problem.
  - Product model name
  - Product serial number
  - Detailed description of the problem
  - The error messages in text or in screenshots if there is any
  - The arrangement of the peripherals
  - Software in use (such as OS and application software, including the version numbers)
3. If repair service is required, please log in to the RMA system of the website or and contact your distributor or sales representative for assistance.

# Table of Contents

---

|  |            |
|--|------------|
| <b>Compliance</b> .....                            | <b>iii</b> |
| <b>Important Safety Information</b> .....          | <b>iv</b>  |
| <b>Warranty Policy</b> .....                       | <b>v</b>   |
| <b>Technical Support &amp; Services</b> .....      | <b>v</b>   |
| <b>Chapter 1      General Information</b> .....    | <b>1</b>   |
| 1.1    Introduction .....                          | 2          |
| 1.2    Features .....                              | 2          |
| 1.3    Packing List .....                          | 3          |
| 1.4    Specifications .....                        | 3          |
| 1.5    Block Diagram .....                         | 5          |
| 1.6    Board Layout .....                          | 6          |
| 1.7    Dimensions .....                            | 7          |
| <b>Chapter 2      Hardware Configuration</b> ..... | <b>9</b>   |
| 2.1    ET976 COM Express Connectors .....          | 10         |
| <b>Chapter 3      Drivers Installation</b> .....   | <b>13</b>  |
| 3.1    Introduction .....                          | 14         |
| 3.2    AMD Ryzen™ V1000 Graphics Drivers .....     | 14         |
| 3.3    Realtek HD Audio Driver Installation .....  | 16         |
| 3.4    LAN Driver Installation .....               | 17         |
| 3.5    Observer Setup Wizard .....                 | 18         |

|                  |                                    |           |
|------------------|------------------------------------|-----------|
| <b>Chapter 4</b> | <b>BIOS Setup.....</b>             | <b>21</b> |
| 4.1              | Introduction.....                  | 22        |
| 4.2              | BIOS Setup.....                    | 22        |
| 4.3              | Main Settings.....                 | 23        |
| 4.4              | Advanced Settings.....             | 23        |
| 4.5              | Chipset Settings.....              | 38        |
| 4.6              | Security Settings.....             | 39        |
| 4.7              | Boot Settings.....                 | 41        |
| 4.8              | Save & Exit.....                   | 42        |
| <b>Appendix</b>  | <b>.....</b>                       | <b>43</b> |
| A.               | I/O Port Address Map.....          | 44        |
| B.               | Interrupt Request Lines (IRQ)..... | 47        |
| C.               | Watchdog Timer Configuration.....  | 48        |

This page is intentionally left blank.

# Chapter 1

## General Information

The information provided in this chapter includes:

- Features
- Packing List
- Optional Accessories
- Specifications
- Block Diagram
- Board Layout
- Board Dimensions

## 1.1 Introduction

ET976 is a COM Express Type-6 module supporting AMD V1000 series APUs with AMD V1000 series built-in Radeon Vega graphics for two independent displays with interface on the carrier board. It supports DDR4-2666 memory for QC APUs and DDR4-2400 for DC APUs.

Standard features supported with interface on the carrier board include an Intel® I210IT Gigabit controller, 4x USB 3.1 ports, 8x USB2.0 ports, and 2x SATA 3.0 ports. ET976 measures 125mm x 95mm and supports the Windows 10 (64bit) OS, with an operating temperature range of 0°C to 60°C.



**ET976**

## 1.2 Features

- AMD Ryzen™ Embedded V1000 APU
- 4GB or 8GB DDR4 memory on board
- 2 x DDI + 1x eDP or 2x DDI + 1x LVDS
- 1 x Intel® PCIe GbE LAN, 8x USB 2.0, 4x USB 3.1, 2x SATA III
- 1x PCIe (x8), 7x PCIe (x1)
- Configurable watchdog timer, TPM 2.0, Digital I/O

### 1.3 Packing List

Your ET976 package should include the items listed below. If any of the items below is missing, contact the distributor or dealer from whom you purchased the product.

- ET976 COM Express Module x 1


### 1.4 Specifications

|                         |  |
|-------------------------|--|
| <b>Product name</b>     | <ul style="list-style-type: none"> <li>ET976-1807-4G</li> <li>ET976-1807LV-8G</li> <li>ET976-1605LV-4G</li> <li>ET976-1202-4G</li> <li>ET976-1202LV-E4G</li> </ul>   |
| <b>System</b>           |  |
| <b>Operating system</b> | Windows 10 (64-bit)  |
| <b>APU</b>              | <ul style="list-style-type: none"> <li>- BGA-1140 package (35 x 32 x 1.38mm), 14nm, Zen cores</li> <li>- AMD V1807B: /QC/3.35GHz~3.8GHz/2MB L2 cache /35W~54W TDP</li> <li>- AMD V1605B: /QC/3.0GHz~3.6GHz/2MB L2 cache/12W~25W TDP</li> <li>- AMD V1202B: /DC/2.3GHz~3.3GHz/1MB L2 cache/12W~25W TDP</li> </ul> |
| <b>Memory</b>           | AMD V1000 APU integrated memory controller<br>Onboard memory DDR4-2666 (1.2V), Max. 8GB, ECC compatible<br>-DDR4 4G (512MX16) FBGA<br>-DDR4 8G (1GX16) TFBGA<br>**DDR4-2666 for QC#, DDR4-2400 DC**  |
| <b>Graphics</b>         | AMD V1000 series APU built-in Radeon Vega graphics, Supports 2x independent displays via carrier board for 2x DDI  |
| <b>LVDS</b>             | 24-bit dual channel via NXP PTN3460 for eDP to LVDS<br>P/N: PTN3460 or eDP   |
| <b>LAN</b>              | 1x Intel® I210IT GbE, co-lay Intel I211AT via carrier board  |
| <b>USB</b>              | AMD V1000 APU built-in USB controller, Max. ports support:<br>4x USB3.1 ports (COMe supports USB3.1 Gen1)<br>8x USB2.0 ports [USB 2.0 Hub x4 ports (Thru Renesas PD720115) via carrier board   |

|                                   |  |
|-----------------------------------|--|
| <b>Expansion</b>                  | -1 x PEG(x8) (Gen3.0)<br>-7 x PCIe(x1) (Gen2.0)<br>(4xPCIe(1x)(Gen3)thru GPP, 4x PCIe(1x) from PCIe switch (PERICOM PI7C9X2G606PR) 2x PCIe(1x)for A/B connector and 1x PCIe(1x) for C/D connector) |
| <b>Serial ATA</b>                 | 2x SATA 3.0 (6Gb/sec.) ports via carrier board   |
| <b>LPC I/O</b>                    | Fintek F81804U-I for 2x COM port x2 (TX/RX), -GPIO, Brightness control   |
| <b>Digital IO</b>                 | 4 in & 4 out   |
| <b>Audio</b>                      | AMD V1000 series APU built-in HD interface   |
| <b>Watchdog</b>                   | Yes (256 segments, 0, 1, 2...255. sec/min)   |
| <b>Connector to carrier board</b> | Two 220-pin connectors (A-B & C-D)<br>[COM Express 3.0 standard]   |
| <b>Power</b>                      | +12V, +5VSB, 8.5V~ 20V (DC-IN)   |
| <b>TPM 2.0</b>                    | Infineon SLB9670VQ2  |
| <b>Certification</b>              | CE (EN55032:2012), FCC Class B   |
| <b>OS support</b>                 | Windows 10 (64bit)   |
| <b>Board size</b>                 | 125mm x 95mm   |
| <b>RoHS</b>                       | Yes  |
| <b>Operating temperature</b>      | 0°C~60°C   |
| <b>Storage temperature</b>        | -20°C~80°C   |


All specifications are subject to change without prior notice.

## 1.5 Block Diagram




## 1.6 Board Layout

### Top View




### Bottom View



\* The pictures above are for reference only.

## 1.7 Dimensions

Unit: mm



This page is intentionally left blank.


## Chapter 2

# Hardware Configuration

The ET976 is connected to the COM Express carrier board via two 220-pin connectors based on the COM Express 3.0 standard. Each connector contains two rows of signals (A-B & C-D). This section provides pinout definitions of the ET976 COM Express connectors.

## 2.1 ET976 COM Express Connectors

### COM Express Module Type 6 Connector (COM\_E\_AB1, COM\_E\_CD1)



| Row A |                | Row B |             | Row C |             | Row D |                    |
|-------|----------------|-------|-------------|-------|-------------|-------|--------------------|
| Pin   | Signal         | Pin   | Signal      | Pin   | Signal      | Pin   | Signal             |
| A1    | GND (FIXED)    | B1    | GND (FIXED) | C1    | GND (FIXED) | D1    | GND (FIXED)        |
| A2    | GBE0_MDI3-     | B2    | GBE0_ACT#   | C2    | GND         | D2    | GND                |
| A3    | GBE0_MDI3+     | B3    | LPC_FRAME#  | C3    | USB_SSRX0-  | D3    | USB_SSTX0-         |
| A4    | GBE0_LINK100#  | B4    | LPC_AD0     | C4    | USB_SSRX0+  | D4    | USB_SSTX0+         |
| A5    | GBE0_LINK1000# | B5    | LPC_AD1     | C5    | GND         | D5    | GND                |
| A6    | GBE0_MDI2-     | B6    | LPC_AD2     | C6    | USB_SSRX1-  | D6    | USB_SSTX1-         |
| A7    | GBE0_MDI2+     | B7    | LPC_AD3     | C7    | USB_SSRX1+  | D7    | USB_SSTX1+         |
| A8    | GBE0_LINK#     | B8    | LPC_DRQ0#   | C8    | GND         | D8    | GND                |
| A9    | GBE0_MDI1-     | B9    | NC          | C9    | USB_SSRX2-  | D9    | USB_SSTX2-         |
| A10   | GBE0_MDI1+     | B10   | LPC_CLK     | C10   | USB_SSRX2+  | D10   | USB_SSTX2+         |
| A11   | GND (FIXED)    | B11   | GND (FIXED) | C11   | GND (FIXED) | D11   | GND (FIXED)        |
| A12   | GBE0_MDI0-     | B12   | PWRBTN#     | C12   | USB_SSRX3-  | D12   | USB_SSTX3-         |
| A13   | GBE0_MDI0+     | B13   | SMB_CK      | C13   | USB_SSRX3+  | D13   | USB_SSTX3+         |
| A14   | GBE0_CTREF     | B14   | SMB_DAT     | C14   | GND         | D14   | GND                |
| A15   | SUS_S3#        | B15   | SMB_ALERT#  | C15   | NC          | D15   | DDI1_CTRLCLK_A UX+ |
| A16   | SATA0_TX+      | B16   | SATA1_TX+   | C16   | NC          | D16   | DDI1_CTRLDATA_AUX- |
| A17   | SATA0_TX-      | B17   | SATA1_TX-   | C17   | RSVD        | D17   | RSVD               |
| A18   | SUS_S4#        | B18   | NC          | C18   | RSVD        | D18   | RSVD               |
| A19   | SATA0_RX+      | B19   | SATA1_RX+   | C19   | PCIE_RX6+   | D19   | PCIE_TX6+          |
| A20   | SATA0_RX-      | B20   | SATA1_RX-   | C20   | PCIE_RX6-   | D20   | PCIE_TX6-          |
| A21   | GND (FIXED)    | B21   | GND (FIXED) | C21   | GND (FIXED) | D21   | GND (FIXED)        |
| A22   | NC             | B22   | NC          | C22   | NC          | D22   | NC                 |
| A23   | NC             | B23   | NC          | C23   | NC          | D23   | NC                 |
| A24   | SUS_S5#        | B24   | PWR_OK      | C24   | DDI1_HPD    | D24   | RSVD               |
| A25   | NC             | B25   | NC          | C25   | NC          | D25   | RSVD               |
| A26   | NC             | B26   | NC          | C26   | NC          | D26   | DDI1_PAIR0+        |
| A27   | BATLOW#        | B27   | WDT         | C27   | RSVD        | D27   | DDI1_PAIR0-        |
| A28   | SATA_ACT#      | B28   | NC          | C28   | RSVD        | D28   | RSVD               |
| A29   | HDA_SYNC       | B29   | NC          | C29   | NC          | D29   | DDI1_PAIR1+        |
| A30   | HDA_RST#       | B30   | HDA_SDINO   | C30   | NC          | D30   | DDI1_PAIR1-        |

| Row A |                       | Row B |             | Row C |                    | Row D |                  |
|-------|-----------------------|-------|-------------|-------|--------------------|-------|------------------|
| Pin   | Signal                | Pin   | Signal      | Pin   | Signal             | Pin   | Signal           |
| A31   | GND (FIXED)           | B31   | GND (FIXED) | C31   | GND (FIXED)        | D31   | GND (FIXED)      |
| A32   | HDA_BITCLK            | B32   | SPKR        | C32   | DDI2_CTRLCLK_AUX+  | D32   | DDI1_PAIR2+      |
| A33   | HDA_SDOOUT            | B33   | I2C_CK      | C33   | DDI2_CTRLDATA_AUX- | D33   | DDI1_PAIR2-      |
| A34   | BIOS_DIS0#            | B34   | I2C_DAT     | C34   | DDI2_DDC_AUX_SEL   | D34   | DDI1_DDC_AUX_SEL |
| A35   | THRMTRIP#             | B35   | THRM#       | C35   | RSVD               | D35   | RSVD             |
| A36   | USB6-                 | B36   | USB7-       | C36   | NC                 | D36   | DDI1_PAIR3+      |
| A37   | USB6+                 | B37   | USB7+       | C37   | NC                 | D37   | DDI1_PAIR3-      |
| A38   | USB_6_7_OC#           | B38   | USB_4_5_OC# | C38   | NC                 | D38   | RSVD             |
| A39   | USB4-                 | B39   | USB5-       | C39   | NC                 | D39   | DDI2_PAIR0+      |
| A40   | USB4+                 | B40   | USB5+       | C40   | NC                 | D40   | DDI2_PAIR0-      |
| A41   | GND (FIXED)           | B41   | GND (FIXED) | C41   | GND (FIXED)        | D41   | GND (FIXED)      |
| A42   | USB2-                 | B42   | USB3-       | C42   | NC                 | D42   | DDI2_PAIR1+      |
| A43   | USB2+                 | B43   | USB3+       | C43   | NC                 | D43   | DDI2_PAIR1-      |
| A44   | USB_2_3_OC#           | B44   | USB_0_1_OC# | C44   | NC                 | D44   | DDI2_HPD         |
| A45   | USB0-                 | B45   | USB1-       | C45   | RSVD               | D45   | RSVD             |
| A46   | USB0+                 | B46   | USB1+       | C46   | NC                 | D46   | DDI2_PAIR2+      |
| A47   | VCC_RTC               | B47   | NC          | C47   | NC                 | D47   | DDI2_PAIR2-      |
| A48   | RSVD                  | B48   | NC          | C48   | RSVD               | D48   | RSVD             |
| A49   | GBE0_SDP              | B49   | SYS_RESET#  | C49   | NC                 | D49   | DDI2_PAIR3+      |
| A50   | LPC_SERIRQ            | B50   | CB_RESET#   | C50   | NC                 | D50   | DDI2_PAIR3-      |
| A51   | GND (FIXED)           | B51   | GND (FIXED) | C51   | GND (FIXED)        | D51   | GND (FIXED)      |
| A52   | PCIE_TX5+             | B52   | PCIE_RX5+   | C52   | PEG_RX0+           | D52   | PEG_TX0+         |
| A53   | PCIE_TX5-             | B53   | PCIE_RX5-   | C53   | PEG_RX0-           | D53   | PEG_TX0-         |
| A54   | GPIO                  | B54   | GPO1        | C54   | NC                 | D54   | NC               |
| A55   | PCIE_TX4+             | B55   | PCIE_RX4+   | C55   | PEG_RX1+           | D55   | PEG_TX1+         |
| A56   | PCIE_TX4-             | B56   | PCIE_RX4-   | C56   | PEG_RX1-           | D56   | PEG_TX1-         |
| A57   | GND                   | B57   | GPO2        | C57   | NC                 | D57   | TYPE2#           |
| A58   | PCIE_TX3+             | B58   | PCIE_RX3+   | C58   | PEG_RX2+           | D58   | PEG_TX2+         |
| A59   | PCIE_TX3-             | B59   | PCIE_RX3-   | C59   | PEG_RX2-           | D59   | PEG_TX2-         |
| A60   | GND (FIXED)           | B60   | GND (FIXED) | C60   | GND (FIXED)        | D60   | GND (FIXED)      |
| A61   | PCIE_TX2+             | B61   | PCIE_RX2+   | C61   | PEG_RX3+           | D61   | PEG_TX3+         |
| A62   | PCIE_TX2-             | B62   | PCIE_RX2-   | C62   | PEG_RX3-           | D62   | PEG_TX3-         |
| A63   | GPIO1                 | B63   | GPO3        | C63   | RSVD               | D63   | RSVD             |
| A64   | PCIE_TX1+             | B64   | PCIE_RX1+   | C64   | RSVD               | D64   | RSVD             |
| A65   | PCIE_TX1-             | B65   | PCIE_RX1-   | C65   | PEG_RX4+           | D65   | PEG_TX4+         |
| A66   | GND                   | B66   | WAKE0#      | C66   | PEG_RX4-           | D66   | PEG_TX4-         |
| A67   | GPIO2                 | B67   | WAKE1#      | C67   | NC                 | D67   | GND              |
| A68   | PCIE_TX0+             | B68   | PCIE_RX0+   | C68   | PEG_RX5+           | D68   | PEG_TX5+         |
| A69   | PCIE_TX0-             | B69   | PCIE_RX0-   | C69   | PEG_RX5-           | D69   | PEG_TX5-         |
| A70   | GND (FIXED)           | B70   | GND (FIXED) | C70   | GND (FIXED)        | D70   | GND (FIXED)      |
| A71   | LVDS_A0+/<br>eDP_TX2+ | B71   | LVDS_B0+    | C71   | PEG_RX6+           | D71   | PEG_TX6+         |
| A72   | LVDS_A0-/<br>eDP_TX2- | B72   | LVDS_B0-    | C72   | PEG_RX6-           | D72   | PEG_TX6-         |
| A73   | LVDS_A1+/<br>eDP_TX1+ | B73   | LVDS_B1+    | C73   | GND                | D73   | GND              |
| A74   | LVDS_A1-/<br>eDP_TX1- | B74   | LVDS_B1-    | C74   | PEG_RX7+           | D74   | PEG_TX7+         |
| A75   | LVDS_A2+/<br>eDP_TX0+ | B75   | LVDS_B2+    | C75   | PEG_RX7-           | D75   | PEG_TX7-         |

| Row A |                        | Row B |                          | Row C |             | Row D |             |
|-------|------------------------|-------|--------------------------|-------|-------------|-------|-------------|
| Pin   | Signal                 | Pin   | Signal                   | Pin   | Signal      | Pin   | Signal      |
| A76   | LVDS_A2-/eDP_TX0-      | B76   | LVDS_B2-                 | C76   | GND         | D76   | GND         |
| A77   | LVDS_VDD_EN/eDP_VDD_EN | B77   | LVDS_B3+                 | C77   | RSVD        | D77   | RSVD        |
| A78   | LVDS_A3+               | B78   | LVDS_B3-                 | C78   | NC          | D78   | NC          |
| A79   | LVDS_A3-               | B79   | LVDS_BKLT_EN/eDP_BKLT_EN | C79   | NC          | D79   | NC          |
| A80   | GND (FIXED)            | B80   | GND (FIXED)              | C80   | GND (FIXED) | D80   | GND (FIXED) |
| A81   | LVDS_A_CK+/eDP_TX3+    | B81   | LVDS_B_CK+               | C81   | NC          | D81   | NC          |
| A82   | LVDS_A_CK-/eDP_TX3-    | B82   | LVDS_B_CK-               | C82   | NC          | D82   | NC          |
| A83   | LVDS_I2C_CK/eDP_AUX+   | B83   | LVDS_BKLT_CTRL           | C83   | RSVD        | D83   | RSVD        |
| A84   | LVDS_I2C_DAT/eDP_AUX-  | B84   | VCC_5V_SBY               | C84   | GND         | D84   | GND         |
| A85   | GPI3                   | B85   | VCC_5V_SBY               | C85   | NC          | D85   | NC          |
| A86   | RSVD                   | B86   | VCC_5V_SBY               | C86   | NC          | D86   | NC          |
| A87   | eDP_HPD                | B87   | VCC_5V_SBY               | C87   | GND         | D87   | GND         |
| A88   | PCIE_CLK_REF+          | B88   | BIOS_DIS1#               | C88   | NC          | D88   | NC          |
| A89   | PCIE_CLK_REF-          | B89   | NC                       | C89   | NC          | D89   | NC          |
| A90   | GND (FIXED)            | B90   | GND (FIXED)              | C90   | GND (FIXED) | D90   | GND (FIXED) |
| A91   | SPI_POWER              | B91   | NC                       | C91   | NC          | D91   | NC          |
| A92   | SPI_MISO               | B92   | NC                       | C92   | NC          | D92   | NC          |
| A93   | GPO0                   | B93   | NC                       | C93   | GND         | D93   | GND         |
| A94   | SPI_CLK                | B94   | NC                       | C94   | NC          | D94   | NC          |
| A95   | SPI_MOSI               | B95   | NC                       | C95   | NC          | D95   | NC          |
| A96   | TPM_PP                 | B96   | NC                       | C96   | GND         | D96   | GND         |
| A97   | NC                     | B97   | SPI_CS#                  | C97   | RSVD        | D97   | RSVD        |
| A98   | SER0_TX                | B98   | RSVD                     | C98   | NC          | D98   | NC          |
| A99   | SER0_RX                | B99   | RSVD                     | C99   | NC          | D99   | NC          |
| A100  | GND (FIXED)            | B100  | GND (FIXED)              | C100  | GND (FIXED) | D100  | GND (FIXED) |
| A101  | SER1_TX                | B101  | FAN_PWMOUT               | C101  | NC          | D101  | NC          |
| A102  | SER1_RX                | B102  | FAN_TACHIN               | C102  | NC          | D102  | NC          |
| A103  | NC                     | B103  | NC                       | C103  | GND         | D103  | GND         |
| A104  | VCC_12V                | B104  | VCC_12V                  | C104  | VCC_12V     | D104  | VCC_12V     |
| A105  | VCC_12V                | B105  | VCC_12V                  | C105  | VCC_12V     | D105  | VCC_12V     |
| A106  | VCC_12V                | B106  | VCC_12V                  | C106  | VCC_12V     | D106  | VCC_12V     |
| A107  | VCC_12V                | B107  | VCC_12V                  | C107  | VCC_12V     | D107  | VCC_12V     |
| A108  | VCC_12V                | B108  | VCC_12V                  | C108  | VCC_12V     | D108  | VCC_12V     |
| A109  | VCC_12V                | B109  | VCC_12V                  | C109  | VCC_12V     | D109  | VCC_12V     |
| A110  | GND (FIXED)            | B110  | GND (FIXED)              | C110  | GND (FIXED) | D110  | GND (FIXED) |

# Chapter 3

## Drivers Installation

This chapter introduces installation of the following drivers:


- AMD Ryzen™ V1000 Graphics Drivers
- Realtek HD Audio Driver Installation
- LAN Driver Installation
- Observer Setup Wizard

## 3.1 Introduction

This section describes the installation procedures for software and drivers. The contents of this section include the following:

## 3.2 AMD Ryzen™ V1000 Graphics Drivers


1. Go to the download page of the product. Copy the compressed drivers file to your computer. Double click the file to decompress it. Run “CDGuide” to go to the main drivers page as shown. Click **AMD** on the left pane and then **AMD Ryzen V1000 Drivers**.




2. Click **AMD Ryzen V1000 Graphics Drivers**.



3. Read the software license agreement and click **Accept and Install** to proceed.




4. Choose and click on either **Express Install** or **Custom Install**.




5. Proceed to install the graphics driver.
6. Restart the computer when prompted for changes to take effect.

### 3.3 Realtek HD Audio Driver Installation

1. Click **AMD** on the left pane and then **AMD Ryzen V1000 Drivers**.
2. Click **Realtek High Definition Audio Driver**.



3. On the *Welcome* screen of the InstallShield Wizard, click **Next** to continue with the installation.



4. When installation is complete, restart the computer when prompted.

### 3.4 LAN Driver Installation

1. Click **LAN Card** on the left pane and then **Intel LAN Controller Drivers**.



2. Click **Intel(R) I21x Gigabit Networks Drivers**.




3. When the *Welcome* screen to the install wizard appears, click **Next**.
4. On the following screen, accept the license agreement and click **Next**.
5. On the *Setup Options* screen, tick the checkbox to select the desired driver(s) for installation. Then click **Next** to continue.
6. On the next screen, click **Install** to begin the installation.
7. Once "Install wizard is Completed," click **Finish**.

## 3.5 Observer Setup Wizard


1. Click **Tools** on the left pane and then **Observer**.



2. On the Welcome screen, click **Next** to install Observer on your system. It is recommended that you close all other applications before continuing.



- The following screen shows the installation destination location or folder. To continue, click **Next**. If you would like to select a different folder, click **Browse**.



- In the **Ready to Install** screen, click **Install** to continue with the installation.
- On the following screen, you will be prompted to restart your computer to complete the installation. Click **Finish**.

This page is intentionally left blank.

# Chapter 4

## BIOS Setup

This chapter describes the different settings available in the AMI BIOS that comes with the board. The topics covered in this chapter are as follows:

- Main Settings
- Advanced Settings
- Chipset Settings
- Security Settings
- Boot Settings
- Save & Exit

## 4.1 Introduction

The BIOS (Basic Input/Output System) installed in the ROM of your computer system supports Intel® processors. The BIOS provides critical low-level support for standard devices such as disk drives, serial ports and parallel ports. It also provides password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

## 4.2 BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Press the <Del> key immediately allows you to enter the Setup utility. If you are a little bit late pressing the <Del> key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup.

If you still need to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again.

The following message will appear on the screen:

```
Press <DEL> to Enter Setup
```

In general, press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help, and <Esc> to quit.

When you enter the BIOS Setup utility, the *Main Menu* screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.


---

**Warning:** It is strongly recommended that you avoid making any changes to the chipset defaults.

These defaults have been carefully chosen by both AMI and your system manufacturer to provide the absolute maximum performance and reliability. Changing the defaults could make the system unstable and crash in some cases.

---


### 4.3 Main Settings








| BIOS Setting | Description   |
|--------------|---|
| System Date  | Sets the date. Use the <Tab> key to switch between the date elements. |
| System Time  | Set the time. Use the <Tab> key to switch between the time elements.  |

### 4.4 Advanced Settings


This section allows you to configure, improve your system and allows you to set up some system features according to your preference.




## 4.4.1 AMD CBS




## 4.4.2 Trusted Computing



| BIOS Setting            | Description   |
|-------------------------|---|
| Security Device Support | Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available. |
| Pending operation       | Schedule an operation for the Security Device. NOTE: Your computer will reboot during restart in order to change State of Security Device.            |




### 4.4.3 ACPI Settings




| BIOS Setting       | Description  |
|--------------------|--|
| Enable Hibernation | Enables / Disables the system ability to hibernate (OS/S4 Sleep State). This option may be not effective with some OS. |
| ACPI Sleep State   | Selects an ACPI sleep state where the system will enter when the Suspend button is pressed.                            |

### 4.4.4 IDE Configuration




| BIOS Setting | Description  |
|--------------|--|
| SATA Ports   | Detects the connection of SATA Port0 and SATA Port1. |

### 4.4.5 eDP/LVDS Configuration





| BIOS Setting       | Description                        |
|--------------------|------------------------------------|
| eDP / LVDS Control | Enable or Disables eDP / LVDS out. |




## 4.4.6 F81964 Super IO Configuration



This section describes the system Super IO Chip parameters.

### Serial Port 1 Configuration:





### Serial Port 2 Configuration:









Paralle Port Configuration:




## 4.4.7 F81804SEC Super IO Configuration

This section describes the Super IO Chip parameters.





### 4.4.8 F81804 Hardware Monitor


| BIOS Setting               | Description   |
|----------------------------|---|
| CPU Shutdown Temperature   | Enables / Disables the CPU shutdown temperature function.   |
| CPU Smart Fan Function     | Enables / Disables the CPU smart fan feature.   |
| System Smart Fans Function | Enables / Disables the system smart fans feature.   |
| Temperatures / Voltages    | These fields are the parameters of the hardware monitoring function feature of the motherboard. The values are read-only values as monitored by the system and show the PC health status. |



## 4.4.10 CPU Configuration



| BIOS Setting       | Description  |
|--------------------|--|
| Node 0 Information | Displays the memory information related to Node 0. |




### 4.4.11 AMI Graphic Output Protocol Policy






| BIOS Setting  | Description                               |
|---------------|---|
| Output Select | Allows you to select an output interface. |

### 4.4.12 Network Stack Configuration




| BIOS Setting  | Description                            |
|---------------|--|
| Network Stack | Enables / Disables UEFI Network Stack. |

## 4.4.13 CSM Configuration





| BIOS Setting | Description   |
|--------------|---|
| CSM Support  | Enables / Disables CSM support.   |
| Network      | Controls the execution of UEFI and Legacy PXE OpROM.<br>Options: Do not launch / Legacy |


### 4.4.14 CSM Configuration



## 4.4.15 NVMe Configuration




### 4.4.16 USB Configuration




| BIOS Setting                    | Description   |
|---------------------------------|---|
| Legacy USB Support              | <p>Enables Legacy USB support.</p> <ul style="list-style-type: none"> <li><b>Auto</b> disables legacy support if there is no USB device connected.</li> <li><b>Disable</b> keeps USB devices available only for EFI applications.</li> </ul>                        |
| XHCI Hand-off                   | <p>This is a workaround for Oses without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.</p>   |
| USB Mass Storage Driver Support | <p>Enables / Disables the support for USB mass storage driver.</p>  |
| USB Transfer time-out           | <p>The time-out value for control, bulk, and Interrupt transfers.</p> <p>Options: 1 sec / 5 sec / 10 sec / 20 sec</p>   |
| Device reset time-out           | <p>Seconds of delaying execution of start unit command to USB mass storage device.</p> <p>Options: 10 sec / 20 sec / 30 sec / 40 sec</p>  |
| Device power-up delay           | <p>The maximum time the device will take before it properly reports itself to the Host Controller.</p> <p><b>Auto</b> uses default value for a Root port it is 100ms. But for a Hub port, the delay is taken from Hub descriptor.</p> <p>Options: Auto / Manual</p> |

## 4.5 Chipset Settings




### 4.5.1 SB USB Configuration




| BIOS Setting         | Description                       |
|----------------------|-----------------------------------|
| SB USB Configuration | Options for SB USB Configuration. |

#### 4.5.1.1. XHCI Ports





| BIOS Setting          | Description   |
|-----------------------|---|
| XHCI 0 & XHCI 1 Ports | Enables / Disables the XHCI0 & XHCI1 ports (XHCI/EMCI). |

## 4.6 Security Settings




| BIOS Setting           | Description   |
|------------------------|---|
| Administrator Password | Sets an administrator password for the setup utility. |
| User Password          | Sets a user password.                                 |
| Secure Boot            | Customizable Secure Boot                              |





| BIOS Setting              | Description  |
|---------------------------|--|
| Secure Boot               | Secure Boot activated when:<br>Secure Boot is enabled<br>Platform Key(PK) is enrolled, System mode is user/deployed, and CSM is disabled                   |
| Secure Boot Customization | Customizable Secure Boot mode:<br>In Custom mode, Secure Boot Policy Variables can be configured by a physically present user without full authentication. |

## 4.7 Boot Settings



| BIOS Setting                        | Description   |
|-------------------------------------|---|
| Setup Prompt Timeout                | Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting. |
| Bootup NumLock State                | Selects the keyboard NumLock state.   |
| Quiet Boot                          | Enables / Disables Quiet Boot option.   |
| Boot mode select                    | Selects a Boot mode, Legacy / UEFI.   |
| Boot Option Priorities              | Sets the system boot order.   |
| UEFI Hard Disk Drive BBS Priorities | Specifies the Boot Device Priority sequence from available UEFI Hard Disk Drivers.          |

## 4.8 Save & Exit



| BIOS Setting              | Description  |
|---------------------------|--|
| Save Changes and Exit     | Exit system setup after saving the changes.                |
| Discard Changes and Exit  | Exit system setup without saving any changes.              |
| Save Changes and Reset    | Resets the system after saving the changes.                |
| Discard Changes and Reset | Reset system setup without saving any changes.             |
| Save Changes              | Save changes done so far to any of the setup options.      |
| Discard Changes           | Discard changes done so far to any of the setup options.   |
| Restore Defaults          | Restore / Loads defaults values for all the setup options. |
| Save as User Defaults     | Save the changes done so far as User Defaults.             |
| Restore User Defaults     | Restore the user defaults to all the setup options.        |

# Appendix

This section provides the mapping addresses of peripheral devices and the sample code of watchdog timer configuration.

## A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. The following table lists the I/O port addresses used.

| Address               | Device Description                 |
|-----------------------|------------------------------------|
| 0x00000A00-0x00000A0F | Motherboard resources              |
| 0x00000A10-0x00000A1F | Motherboard resources              |
| 0x00000A20-0x00000A2F | Motherboard resources              |
| 0x00000378-0x0000037F | Printer Port (LPT1)                |
| 0x00000070-0x00000071 | System CMOS/real time clock        |
| 0x0000D000-0x0000DFFF | PCI Express Root Port              |
| 0x0000D000-0x0000DFFF | AMD Radeon(TM) Vega 8 Graphics     |
| 0x000003F8-0x000003FF | Communications Port (COM1)         |
| 0x000002F8-0x000002FF | Communications Port (COM2)         |
| 0x000003E8-0x000003EF | Communications Port (COM3)         |
| 0x000002E8-0x000002EF | Communications Port (COM4)         |
| 0x00000020-0x00000021 | Programmable interrupt controller  |
| 0x000000A0-0x000000A1 | Programmable interrupt controller  |
| 0x00000000-0x000003AF | PCI Express Root Complex           |
| 0x00000000-0x000003AF | Direct memory access controller    |
| 0x000003E0-0x00000CF7 | PCI Express Root Complex           |
| 0x000003B0-0x000003DF | PCI Express Root Complex           |
| 0x0000D000-0x0000FFFF | PCI Express Root Complex           |
| 0x0000F000-0x0000FFFF | PCI Express Root Port              |
| 0x0000E000-0x0000EFFF | PCI Express Root Port              |
| 0x0000E000-0x0000EFFF | PCI Express Upstream Switch Port   |
| 0x0000E000-0x0000EFFF | PCI Express Downstream Switch Port |
| 0x00000040-0x00000043 | System timer                       |

|                       |                       |
|-----------------------|-----------------------|
| 0x00000010-0x0000001F | Motherboard resources |
| 0x00000022-0x0000003F | Motherboard resources |
| 0x00000063-0x00000063 | Motherboard resources |
| 0x00000065-0x00000065 | Motherboard resources |
| 0x00000067-0x0000006F | Motherboard resources |
| 0x00000072-0x0000007F | Motherboard resources |
| 0x00000080-0x00000080 | Motherboard resources |
| 0x00000084-0x00000086 | Motherboard resources |
| 0x00000088-0x00000088 | Motherboard resources |
| 0x0000008C-0x0000008E | Motherboard resources |
| 0x00000090-0x0000009F | Motherboard resources |
| 0x000000A2-0x000000BF | Motherboard resources |
| 0x000000B1-0x000000B1 | Motherboard resources |
| 0x000000E0-0x000000EF | Motherboard resources |
| 0x000004D0-0x000004D1 | Motherboard resources |
| 0x0000040B-0x0000040B | Motherboard resources |
| 0x000004D6-0x000004D6 | Motherboard resources |
| 0x00000C00-0x00000C01 | Motherboard resources |
| 0x00000C14-0x00000C14 | Motherboard resources |
| 0x00000C50-0x00000C51 | Motherboard resources |
| 0x00000C52-0x00000C52 | Motherboard resources |
| 0x00000C6C-0x00000C6C | Motherboard resources |
| 0x00000C6F-0x00000C6F | Motherboard resources |
| 0x00000CD0-0x00000CD1 | Motherboard resources |
| 0x00000CD2-0x00000CD3 | Motherboard resources |
| 0x00000CD4-0x00000CD5 | Motherboard resources |
| 0x00000CD6-0x00000CD7 | Motherboard resources |
| 0x00000CD8-0x00000CDF | Motherboard resources |
| 0x00000800-0x0000089F | Motherboard resources |
| 0x00000B00-0x00000B0F | Motherboard resources |

|                       |                                 |
|-----------------------|---------------------------------|
| 0x00000B20-0x00000B3F | Motherboard resources           |
| 0x00000900-0x0000090F | Motherboard resources           |
| 0x00000910-0x0000091F | Motherboard resources           |
| 0x00000061-0x00000061 | System speaker                  |
| 0x00000081-0x00000083 | Direct memory access controller |
| 0x00000087-0x00000087 | Direct memory access controller |
| 0x00000089-0x0000008B | Direct memory access controller |
| 0x0000008F-0x0000008F | Direct memory access controller |
| 0x000000C0-0x000000DF | Direct memory access controller |

## B. Interrupt Request Lines (IRQ)

Peripheral devices use interrupt request lines to notify CPU for the service required. The following table shows the IRQ used by the devices on board.

| Level                                 | Function  |
|---------------------------------------|---|
| IRQ 0                                 | System timer  |
| IRQ 3                                 | Communications Port (COM2)                                    |
| IRQ 4                                 | Communications Port (COM1)                                    |
| IRQ 6                                 | Communications Port (COM4)                                    |
| IRQ 7                                 | AMD GPIO Controller   |
| IRQ 8                                 | High precision event timer                                    |
| IRQ 10                                | Communications Port (COM3)                                    |
| IRQ 14                                | AMD I2C Controller  |
| IRQ 53                                | High Definition Audio Controller<br>AMD Audio CoProcessor     |
| IRQ 54                                | AMD High Definition Audio Controller                          |
| IRQ 55                                | AMD SFH KMDf I2C  |
| IRQ 56 ~ IRQ 511                      | Microsoft ACPI-Compliant System                               |
| IRQ 4294967278 ~<br>4294967283        | Intel(R) I210 Gigabit Network Connection                      |
| IRQ 4294967292                        | PCI Express Root Port   |
| IRQ 4294967272~7                      | Intel(R) I211 Gigabit Network Connection                      |
| IRQ 4294967261~<br>4294967268         | AMD USB 3.10 eXtensible Host Controller -<br>1.10 (Microsoft) |
| IRQ 4294967291,3,4                    | PCI Express Root Port   |
| IRQ 4294967286                        | Standard SATA AHCI Controller                                 |
| IRQ 4294967287,88,<br>IRQ 42949672890 | PCI Express Downstream Switch Port                            |
| IRQ 4294967269~71                     | AMD Radeon(TM) Vega 8 Graphics                                |
| IRQ 4294967253~<br>4294967260         | AMD USB 3.10 eXtensible Host Controller -<br>1.10 (Microsoft) |
| IRQ 4294967288                        | PCI Express Downstream Switch Port                            |
| IRQ 4294967284~<br>4294967285         | AMD PSP 10.0 Device   |

## C. Watchdog Timer Configuration

The Watchdog Timer (WDT) is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven.

Under normal circumstance, you will need to restart the WDT at regular intervals before the timer counts to zero.

\* F81804 WDT Main Function Example \*

```
INTN
EFIAPI
ShellAppMain (
    IN UINTN Argc,
    IN CHAR16 **Argv
)
{
    int time = 10; //seconds

    if(!F81804Init()){ //Check if this SIO is F81804
        return 0;
    }
    F81804WdtEnable(time);
    //F81804WdtDisable();
}
```

**\* F81804 DIO Main Function Example**

\*

```
INTN
EFIAPI
ShellAppMain (
    IN UINTN Argc,
    IN CHAR16 **Argv
)
{
    UINT8 DIO;

    F8104EnterConfig();

    if(!F81804Init()){ //Check if this SIO is F81804
        return 0;
    }

    F81804DioInit(); //Init F81804 DIO

    F81804SetOutput(0x00); //Set out0-3 to Low
    DIO = F81804GetInput();
    if(DIO != 0x00){
        return 0;
    }

    F81804SetOutput(0x1E); //Set out0-3 to High
    DIO = F81804GetInput();
    if(DIO != 0x0F){
        return 0;
    }
}
```

\* **F81804 Related Function Define and Implement** \*

```

#define F81804_CONFIG_INDEX      0x2E
#define F81804_CONFIG_DATA      F81804_CONFIG_INDEX+1
#define F81804_CONFIG_MODE_ENTER_VALUE 0x87
#define F81804_CONFIG_MODE_EXIT_VALUE 0xAA

//Set F81804 out0-3 (BIT0: out0, BIT1: out1, BIT2: out2, BIT3: out3)
VOID F81804SetOutput(UINT8 Data){
    F8104ProgramRegister(0x07, 0x00, 0x06);
    F8104ProgramRegister(0x99, 0xE1, Data);
}

//Get F81804 into-3 (BIT0: in0, BIT1: in1, BIT2: in2, BIT3: in3)
UINT8 F81804GetInput(){
    UINT8 tmp1, tmp2, input;
    F8104ProgramRegister(0x07, 0x00, 0x06);

    IoWrite8(F81804_CONFIG_INDEX, 0xF2);
    tmp1 = IoRead8(F81804_CONFIG_DATA);
    tmp1 = tmp1 & 0x11; //BIT0: GPIO_STS BIT1: GPI1_STS
    IoWrite8(F81804_CONFIG_INDEX, 0xE2);
    tmp2 = IoRead8(F81804_CONFIG_DATA);
    tmp2 = tmp2 & 0xC0; //BIT6: GPI2_STS BIT7:GPI3_STS

    input = (tmp1 & 0x1) |
            ((tmp1 & 0x10) >> 3) |
            ((tmp2 & 0x40) >> 4) |
            ((tmp2 & 0x80) >> 4);

    return  input;
}

//Check if CHIP_ID for F81804
UINT8 F81804Init(){
    UINT8 CHIP_ID1, CHIP_ID2;
    IoWrite8(F81804_CONFIG_INDEX, 0x20);
    CHIP_ID1 = IoRead8(F81804_CONFIG_DATA);
    IoWrite8(F81804_CONFIG_INDEX, 0x21);
    CHIP_ID2 = IoRead8(F81804_CONFIG_DATA);

    if((CHIP_ID1 != 0x15) && (CHIP_ID2 != 0x02))
        return 0;
}

```

```

        return 1;
    }

//Program related DIO settings
VOID F81804DioInit(){

    F8104ProgramRegister(0x27, 0xF2, 0x00); //Set GPIO00, GPIO04 default input
    F8104ProgramRegister(0x2C, 0xEE, 0x11);
        F8104ProgramRegister(0x27, 0xF2, 0x0C); //Set GPIO16, GPIO17 default
input
        F8104ProgramRegister(0x2A, 0x88, 0);
    F8104ProgramRegister(0x07, 0x00, 0x06); //LDN=0x06
    F8104ProgramRegister(0x30, 0xFE, 0x01);
    F8104ProgramRegister(0xF0, 0xEE, 0);
    F8104ProgramRegister(0xE0, 0x3F, 0);

    F8104ProgramRegister(0x27, 0xF2, 0x0C); //GPIO91-94, Output enable and
default high
    F8104ProgramRegister(0x2C, 0xE1, 0x1E);
    F8104ProgramRegister(0x98, 0xE1, 0x1E);
}

VOID F8104ProgramRegister(
    UINT8 Register,
    UINT8 AndData,
    UINT8 OrData){

    UINT8 temp;

    IoWrite8(F81804_CONFIG_INDEX, Register);
    temp = IoRead8(F81804_CONFIG_DATA);

    temp &= AndData;
    temp |= OrData;
    IoWrite8(F81804_CONFIG_DATA, temp);
}

VOID F8104EnterConfig(){
    IoWrite8(F81804_CONFIG_INDEX,
F81804_CONFIG_MODE_ENTER_VALUE);
    IoWrite8(F81804_CONFIG_INDEX,
F81804_CONFIG_MODE_ENTER_VALUE);
}
VOID F8104ExitConfig(){
    IoWrite8(F81804_CONFIG_INDEX, F81804_CONFIG_MODE_EXIT_VALUE);
}

```

```
//Disable F81804 WDT
void F81804WdtDisable(){
    F8104EnterConfig();
    F8104ProgramRegister(0x07, 0x00, 0x07);
    F8104ProgramRegister(0x30, 0x00, 0x00);
    F8104ProgramRegister(0xF5, 0xF0, 0x52); //count mode is second
    F8104ProgramRegister(0xF6, 0x00, 0xFF); //set timer 0xFF seconds
    F8104ProgramRegister(0xFA, 0xFE, 0x00); //Disable WDTO output
    F8104ProgramRegister(0xF5, 0xDF, 0x00); //start counting
    F8104ExitConfig();
}
```

```
//Enable F81804 WDT
void F81804WdtEnable(UINT8 time){
    F8104EnterConfig();
    F8104ProgramRegister(0x27, ~(BIT3|BIT2|BIT0), BIT3);
    F8104ProgramRegister(0x2A, ~(BIT4|BIT5|BIT6), (BIT5|BIT6));
    F8104ProgramRegister(0x07, 0x00, 0x07);
    F8104ProgramRegister(0x30, 0x00, 0x01);
    F8104ProgramRegister(0xF5, 0xF0, 0x52); //count mode is second
    F8104ProgramRegister(0xF6, 0x00, time); //set timer time seconds
    F8104ProgramRegister(0xFA, 0xFE, 0x01); //enable WDTO output
    F8104ProgramRegister(0xF5, 0xFF, 0x20); //start counting
    F8104ExitConfig();
}
```